

Autonomous Surface Vehicle

Group #1

Team Members:
Michael Podel
Gor Beglaryan
Stanislaus Bernard
Christina Sylvia

April 29, 2011

Sponsored By:
Robotics Club at the University of Central
Florida

TABLE OF CONTENTS

1. AUTONOMOUS SURFACE VEHICLE OVERVIEW	3
1.1 INTRODUCTION.....	3
1.2 PURPOSE	3
1.3 AUVSI AND ONR's 4 TH INTERNATIONAL ASV COMPETITION.....	3
1.4 ASV OBJECTIVES 2011	5
1.4.1 <i>Electrical</i>	5
1.4.2 <i>Software</i>	6
1.4.3 <i>Mechanical</i>	6
2. SPECIFICATIONS, BUDGET, AND TIMELINE	6
2.1 TECHNICAL OBJECTIVES.....	7
2.1.1 <i>Goals</i>	7
2.2 BUDGET AND FINANCING	7
2.3 TIMELINE	8
2.4 TESTING SCHEDULE	8
2.5 CONSULTANTS AND SUPPLIERS	9
2.5.1 <i>ASV Team</i>	9
2.5.2 <i>Advisors</i>	9
2.5.3 <i>Suppliers</i>	9
2.6 FACILITIES AND EQUIPMENT.....	9
3. RESEARCH	10
3.1 POWER.....	10
3.1.1 <i>Emergency Stop</i>	10
3.1.2 <i>Reverse Polarity</i>	15
3.1.3 <i>Hot Swapping</i>	18
3.1.4 <i>Voltage Regulation</i>	19
3.1.5 <i>Voltage and Current Sensing</i>	26
3.2 MICROCONTROLLER.....	33
3.2.1 <i>What's Needed</i>	33
3.2.2 <i>Parts Researched</i>	35
3.2.3 <i>Comparison of Microcontrollers</i>	37
3.3 FIELD PROGRAMMABLE GATE ARRAY (FPGA).....	38
3.3.1 <i>Background</i>	38
3.3.2 <i>What's Needed</i>	39
3.3.3 <i>Part's Research</i>	39
3.3.4 <i>XC3S500E vs. EPF10K70</i>	40
3.4 COMMUNICATION	41
3.4.1 <i>Wireless</i>	42
3.4.2 <i>Wired</i>	47
3.5 SENSORS	53
3.5.1 <i>Temperature / Humidity Sensors</i>	53
3.5.2 <i>Light Sensor</i>	57
3.6 DYNAMIC FAN CONTROL.....	60
3.6.1 <i>Option 1: Cascading Regulators</i>	61
3.6.2 <i>Option 2: Adjustable Voltage Regulator</i>	61
3.6.3 <i>Option 3: Motor Controller</i>	63
3.6.4 <i>Option 4: Fan Controller IC (PWM Based)</i>	63
3.6.5 <i>Option 5: FET driven Fan</i>	64
3.7 DISPLAYS	64
3.7.1 <i>Liquid Crystal Display (LCD)</i>	65
3.7.2 <i>Twisted Nematic (TN) [4]</i>	65
3.7.3 <i>Super Twisted Nematic (STN) [36]</i>	66
3.7.4 <i>Thin-film-transistor (TFT) [4]</i>	66

3.7.5	<i>In Plane Switching (IPS) [42]</i>	67
3.7.6	<i>Vertical Alignment (VA) [42]</i>	67
3.7.7	<i>Light Emitting Diode (LED) displays</i>	68
4.	DESIGN	71
4.1	POWER.....	71
4.1.1	<i>Emergency Stop</i>	71
4.1.2	<i>Reverse Polarity</i>	82
4.1.3	<i>Hot Swapping</i>	83
4.1.4	<i>Voltage Regulation</i>	84
4.1.5	<i>Voltage Sensing</i>	92
4.1.6	<i>Current Sensing</i>	93
4.2	MICROCONTROLLER.....	100
4.2.1	<i>Power</i>	101
4.2.2	<i>Two-Wire Interface</i>	102
4.3	FPGA.....	104
4.3.1	<i>PCB Design for the FPGA</i>	104
4.3.2	<i>Implementation of Asynchronous Serial</i>	105
4.4	COMMUNICATION.....	109
4.5	SENSORS.....	110
4.5.1	<i>Temperature</i>	110
4.5.2	<i>Light</i>	112
4.6	DYNAMIC FAN CONTROL.....	112
4.7	DISPLAYS.....	113
5.	BUILDING / TEST PROCEDURE	113
5.1	POWER.....	114
5.1.1	<i>Emergency Stop</i>	114
5.1.2	<i>Reverse Polarity</i>	114
5.1.3	<i>Hot Swapping</i>	114
5.1.4	<i>Voltage Regulators</i>	114
5.1.5	<i>Voltage Sensing</i>	116
5.1.6	<i>Current Sensing</i>	117
5.2	MICROCONTROLLER.....	118
5.2.1	<i>Power and Signals</i>	118
5.2.2	<i>Software Check</i>	120
5.3	FIELD PROGRAMMABLE GATE ARRAY.....	121
5.3.1	<i>Power and Signals</i>	121
5.3.2	<i>Software Check</i>	121
5.4	COMMUNICATION.....	121
5.4.1	<i>Wireless Communication - XBee Test Procedure [5]</i>	121
5.5	SENSORS.....	124
5.5.1	<i>Temperature Sensor (1-COTS)</i>	124
5.5.2	<i>Temperature Sensor (2-Thermistor)</i>	125
5.5.3	<i>Light</i>	127
5.6	DYNAMIC FAN CONTROL.....	128
5.7	DISPLAYS.....	129
6.	USER MANUAL	129
6.1	TURNING ON THE ASV.....	129
6.1.1	<i>Connect Batteries to the ASV</i>	129
6.1.2	<i>Connect Shore Power to the ASV</i>	130
6.1.3	<i>Powering On with Batteries</i>	131
6.1.4	<i>Powering On with Shore Power</i>	131
6.2	SWITCHING BETWEEN POWER SOURCES.....	132
6.3	MONITORING ASV VITALS.....	132

6.3.1	Description of LCD Screens.....	133
6.3.2	Using the On-Board LCD Screen.....	133
6.3.3	Using the Remote LCD Screen.....	134
6.4	EMERGENCY STOP SYSTEM.....	135
6.4.1	Connecting the ESTOP Circuit.....	135
6.4.2	Resetting the ESTOP Circuit.....	136
6.4.3	Emergency Stopping the ESTOP Circuit.....	137
6.5	COMPUTER POWER.....	138
7.	EXPLICIT DESIGN SUMMARY.....	138
8.	BIBLIOGRAPHY.....	140
A	SYSTEM DIAGRAMS.....	143
A.1	PCB LAYOUT.....	143
A.2	SHORE POWER.....	143
A.3	POWER DISTRIBUTION.....	144
A.4	LOGIC DISTRIBUTION.....	144
B	TIMELINE.....	145
C	COPYRIGHTS.....	146

Table of Figures

FIGURE 1.1 - COMPETITION MAP.....	5
FIGURE 3.1 - ELECTROMECHANICAL RELAY OPERATION.....	12
FIGURE 3.2 - SOLID STATE RELAY OPERATION.....	12
FIGURE 3.3 - REVERSE POLARITY PROTECTION USING SERIES DIODE.....	15
FIGURE 3.4 - REVERSE POLARITY PROTECTION USING PARALLEL DIODE.....	16
FIGURE 3.5 - REVERSE POLARITY PROTECTION USING P-FET.....	17
FIGURE 3.6 - FULL WAVE RECTIFIER (BATTERY POLARITY IS CORRECT).....	18
FIGURE 3.7 - FULL WAVE RECTIFIER (BATTERY POLARITY IS NOT CORRECT).....	18
FIGURE 3.8 - HOT SWAPPING CIRCUIT.....	19
FIGURE 3.9 - LINEAR BUCK CONVERTER.....	23
FIGURE 3.10 - LINEAR REGULATOR NEGATIVE FEEDBACK.....	23
FIGURE 3.11 - SWITCHING BUCK CONVERTER.....	25
FIGURE 3.12 - SWITCHING BOOST CONVERTER.....	25
FIGURE 3.13 - HIGH VS. LOW SIDE CURRENT SENSE USING SHUNT RESISTOR.....	28
FIGURE 3.14 - HALL EFFECT DIAGRAM.....	30
FIGURE 3.15 - OPEN LOOP HALL EFFECT DIAGRAM.....	31
FIGURE 3.16 - CLOSED LOOP HALL EFFECT DIAGRAM.....	32
FIGURE 3.17 - ILLUSTRATION OF LOGIC CELLS.....	40
FIGURE 3.18 - UART DATA TRANSMIT FORMAT: 1 START BIT, 8 DATA BITS, 1 PARITY BIT, 1 STOP BITS... 45	45
FIGURE 3.19 - I2C MASTER/SLAVE CONFIGURATION.....	49
FIGURE 3.20 - I2C DATA TRANSFER CONFIGURATION.....	50
FIGURE 3.21 - RS-232 DATA CHARACTERISTICS.....	51
FIGURE 3.22 - BLOCK DIAGRAM OF WIRED COMMUNICATION PLATFORM,.....	53
FIGURE 3.23 - CONDITIONING SIGNAL PATH.....	56
FIGURE 3.24 - BLOCK DIAGRAM.....	59
FIGURE 3.25 - SETUP OF THE FIRST SCENARIO WITH THE EFFICIENCY FOR A CASCADE SETUP.....	61
FIGURE 3.26 - BASIC SETUP OF AN ADJUSTABLE VOLTAGE REGULATOR.....	62
FIGURE 3.27 - A MORE SPECIFIC VERSION OF THE ADJUSTABLE VOLTAGE REGULATOR.....	62
FIGURE 3.28 - MICREL'S MIC502 SETUP TO DETERMINE [28].....	63
FIGURE 3.29 - CELL OF TN LCD DISPLAY.....	66
FIGURE 3.30 - TFT TECHNOLOGY.....	67
FIGURE 3.31 - LCD DISPLAY.....	70

FIGURE 4.1 - ACTIVE E-STOP CIRCUIT-1	74
FIGURE 4.2 - POLOLU MODULE FOR E-STOP CIRCUIT.....	75
FIGURE 4.3 - POLOLU RC SWITCH WITH DIGITAL OUTPUT.....	75
FIGURE 4.4 - HIGH CURRENT DC SWITCH.....	76
FIGURE 4.5 - HIGH CURRENT DC SWITCH SCHEMATIC	77
FIGURE 4.6 - HIGH CURRENT DC SWITCH SIMULATION.....	78
FIGURE 4.7 - PASSIVE E-STOP CIRCUIT SCHEMATIC	79
FIGURE 4.8 - PASSIVE E-STOP INCLUDING EXTERNAL RELAYS.....	81
FIGURE 4.9 - SCHEMATIC FOR PASSIVE E-STOP CIRCUIT	82
FIGURE 4.10 - SCHEMATIC OF "REVERSE POLARITY PROTECTION"	83
FIGURE 4.11 - "HOT SWAPPING" CIRCUIT SCHEMATIC.....	84
FIGURE 4.12 - 5V LM2676 CHARACTERISTIC CHARTS	85
FIGURE 4.13 - 5V LM2676 SCHEMATIC.....	86
FIGURE 4.14 - 8V LM2675 CHARACTERISTIC CHARTS	87
FIGURE 4.15 - 8V LM2675 SCHEMATIC.....	88
FIGURE 4.16 - 8V LM2676 CHARACTERISTIC CHARTS	88
FIGURE 4.17 - 12V LM22677 CHARACTERISTIC CHARTS	89
FIGURE 4.18 - 12V LM22677 SCHEMATIC.....	90
FIGURE 4.19 - PTN78020W CHARACTERISTIC CHARTS.....	91
FIGURE 4.20 - 12V PTN78020W SCHEMATIC	91
FIGURE 4.21 - VOLTAGE SENSING.....	92
FIGURE 4.22 - SENSE RESISTOR CIRCUIT.....	95
FIGURE 4.23 - CURRENT SENSE MAX9920	96
FIGURE 4.24 - LEM LAH 25-NP DIMENSIONS	97
FIGURE 4.25 - LEM LAH 25-NP SCHEMATIC.....	99
FIGURE 4.26 - LEM LTS 15-NP SIZE.....	99
FIGURE 4.27 - LEM LTS 15-NP SCHEMATIC	100
FIGURE 4.28 - ILLUSTRATION OF SCHEMATIC AND BOARD LAYOUT FOR THE MICROCONTROLLER REGARDING POWER	101
FIGURE 4.29 - PROGRAM FLOW FOR A TWO-WIRE INTERFACE [14].....	103
FIGURE 4.30 - ILLUSTRATION OF THE HARDWARE SETUP NEEDED FOR A TWO-WIRE INTERFACE.....	103
FIGURE 4.31 - FOOTPRINT OF THE XILINX SPARTAN3E	104
FIGURE 4.32 - SAMPLING THE DATA STREAM FROM THE RECEIVER	106
FIGURE 4.33 - FLOW FOR DATA ON THE RECEIVING UART AT 16 TIMES THE BAUD RATE	108
FIGURE 4.34 - XBEE WIRELESS SCHEMATIC	109
FIGURE 4.35 - DS18S20 TEMPERATURE SENSOR SCHEMATIC	110
FIGURE 4.36 - THERMISTOR TEMPERATURE SENSOR SCHEMATIC	111
FIGURE 4.37 - DISPLAY, SWITCH, MICROCONTROLLER CONNECTION	113
FIGURE 5.1 - 5V LM2676 EAGLE SCHEMATIC.....	115
FIGURE 5.2 - 8V LM2676 EAGLE SCHEMATIC.....	116
FIGURE 5.3 - 12V LM22677 EAGLE SCHEMATIC.....	116
FIGURE 5.4 - MAX9920 SCHEMATIC	118
FIGURE 5.5 - X-CTU PROGRAM.....	123
FIGURE 5.6 - X-CTU RANGE TEST	124
FIGURE 6.1 - 4 CELL BATTERY	129
FIGURE 6.2 - 6 CELL BATTERY	129
FIGURE 6.3 - BOX SWITCHES	130
FIGURE 6.4 - RELAY SWITCH.....	130
FIGURE 6.5 - RHINO SHORE SUPPLY	131
FIGURE 6.6 - SHORE POWER CABLE.....	131
FIGURE 6.7 - MAIN LCD SCREEN	134
FIGURE 6.8 - REMOTE LCD SCREEN	135
FIGURE 6.9 - EXTERNAL ESTOP BUTTON	135
FIGURE 6.10 - FUTABA TRANSMITTER	136
FIGURE 6.11 - FUTABA ESTOP SWITCH	136
FIGURE 6.12 - POLOLU RC SWITCH.....	137

FIGURE 6.13 - RESET BUTTON	137
FIGURE 7.1 - SYSTEM OVERVIEW	139

Table of Tables

TABLE 1.1 - COMPETITION CHALLENGES.....	4
TABLE 2.1 - PROJECT COST.....	8
TABLE 3.1 - FEATURES THAT MUST BE CONSIDERED BEFORE BUYING RELAYS	11
TABLE 3.2 - SUMMARY OF RELAY CONTACT ARRANGEMENTS	11
TABLE 3.3 - RELAY SUMMARY: DIFFERENT TECHNOLOGIES, THEIR ADVANTAGES AND DISADVANTAGES..	13
TABLE 3.4 - MINIMUM CURRENT/VOLTAGE REQUIREMENTS THAT MUST BE PROVIDED BY THE RELAYS	14
TABLE 3.5 - CURRENT RATINGS FOR THE DIFFERENT POWER SOURCES	15
TABLE 3.6 - VOLTAGE REGULATION REQUIREMENTS	21
TABLE 3.7 - LINEAR VS. SWITCHING REGULATORS	22
TABLE 3.8 - HIGH SIDE CURRENT SENSING	28
TABLE 3.9 - LOW SIDE CURRENT SENSING	29
TABLE 3.10 - CURRENT SENSE METHOD COMPARISON	33
TABLE 3.11 - COMPARISON OF ALL THE MICROCONTROLLERS STUDIED.....	38
TABLE 3.12 - COMPARISON BETWEEN THE FPGAs CONSIDERED	41
TABLE 3.13 - XBEE KIT INDIVIDUALLY PRICED FOR COMPARISON	47
TABLE 3.14 - PRICE COMPARISON	47
TABLE 3.15 - RS-232 & RS-485 COMPARISON SUMMARY.....	52
TABLE 3.16 - HUMIDITY/TEMPERATURE SENSOR COST COMPARISON.....	57
TABLE 3.17 - LIGHT SENSOR COST COMPARISON	59
TABLE 3.18 - GENERAL DISPLAY SPECIFICATIONS.....	68
TABLE 3.19 - LCD VS. LED	69
TABLE 3.20 - LCD DISPLAY DETAILS	70
TABLE 4.1 - HIGH CURRENT DC SWITCH SPECS FOR DIFFERENT FETs	77
TABLE 4.2 - SENSE RESISTORS LTC4151	94
TABLE 4.3 - SENSE RESISTORS MAX9920	97
TABLE 4.4 - CLOSED LOOP PCB CONFIGURATION.....	98
TABLE 4.5 - ILLUSTRATION OF THE DATA SENT FOR A GIVEN PACKET	105
TABLE 4.6 - ADDRESS PINS AND SLAVE ADDRESSES FOR THE TMP100	110

Table of Equations

EQUATION 3.1 - BOOST GAIN EQUATION.....	25
EQUATION 3.2 - LINEAR REGULATOR - POWER WASTED.....	25
EQUATION 3.3 - PULL-UP RESISTOR EQUATION FOR I2C BUS.....	49
EQUATION 3.4 - EQUATION FOR RELATIONSHIP BETWEEN CAPACITANCE AND FREQUENCY	63
EQUATION 4.1 - SENSE RESISTOR SCALING LTC4151	93
EQUATION 4.2 - MAX9920 GAIN FORMULA	96
EQUATION 4.3 - LEM LTS 15-NP FORMULA.....	100
EQUATION 4.4 - SWITCHING FREQUENCY.....	101
EQUATION 4.5 - NUMBER OF SAMPLES	107
EQUATION 4.6 - SAMPLING PER CLOCK PULSE.....	107

Executive Summary

Every summer the Association for Unmanned Vehicle Systems International (AUVSI) hosts the Autonomous Surface Vehicle (ASV) competition. The Robotics Club at the University of Central Florida (UCF) annually participates in this competition which involves engineering a fully autonomous vehicle to perform the challenges set forth by AUVSI. This encompasses using students of all disciplines to create an innovative, efficient, and ergonomic platform for competition. Our senior design team, composed of electrical engineers, has come together to engineer the electronics portion of the ASV. This includes power regulation/distribution, power monitoring, vehicle safety, on-board and remote monitoring of system for vitals, and processing of some sensor data.

Power regulation will efficiently control and distribute regulated and unregulated voltage throughout the vehicle for its onboard systems. This involves controlling three input sources as well as seamlessly hot swapping between two of these input sources. The vehicle will have protection from accidental input source reverse polarity as well as excess current draw. Our goal this year is to monitor all the vitals of our system including input source voltages, input source current draw, temperature, and humidity. We will have the ability to monitor the vitals through the on-board computer, on-board LCD screen, as well as a remote LCD screen.

The ASV is comprised of numerous sensors which include multiple vision systems, a compass, a global positioning system (GPS), LIDAR, light, current, temperature, humidity, and mechanical feedback. These systems are integrated in the vehicle by using multiple devices over several communication protocols. The processing power on the ASV consists of a computer, a field programmable gate array (FPGA), and a microcontroller. They utilize USB, serial, and I2C to communicate between each other and share information gathered from sensors. All vision and some sensor processing is handled by the computer, which in turn directs the FPGA to send signals to motors/thrusters and other mechanical devices on the vehicle. In response to these signals the vehicle moves and performs specific tasks necessary for completing the overall competition.

In order to provide a more detailed diagnostic of the current condition of the ASV, light and temperature sensors have been selected to aid in achieving the utmost control over the ASV. The light sensor has been designed to assist in color identification of objects. The set of four light sensors, composing the light detection assembly pack, each occupy a different navigational direction. They will interpret the amount of ambient light available and send this information to the microcontroller where it can then be determined where the light is coming from and if it could be affecting the "true" color of the object of interest. The temperature sensors will dictate whether the electrical boxes are creating too much heat for the electrical components inside to work efficiently. The temperature obtained from these readings will then be used to control the fan speed inside the ASV electrical box. Our senior design team in conjunction with the Robotics Club have decided that being able to display the diagnostic current conditions of the ASV will be accomplished both through an on board LCD display and via remote. To realize this

task we have selected to utilize ZigBee's XBee Pro wireless modules. This form of wireless communication has proven to satisfy all of our core requirements in addition to exceeding our desired range of 900 ft.; while requiring a sufficiently small amount of power in the process.

In order to maintain a high level of safety as we work with both high voltages and high currents various layers of safety protection will be implemented. One such protection is the inclusion of an emergency stop circuit. As per competition rules, the ASV must have included in its design a method in which all power can be cut from any moveable parts on board. The E-Stop circuit we will design will be capable of cutting power to these moveable parts in three locations. Two locations will be located directly on the ASV and a third will be accessible via remote. After considering the pros and cons of the E-Stop circuit from previous years we have decided to implement an emergency stop circuit that does not require any logic components. The exclusion of logic components should offer better protection, and allow the system to be in E-Stop mode when initial power is applied to the ASV. The E-Stop circuit is designed to operate using set and reset buttons. The reset button for our design purposes will only be accessible on board. Another measure of safety protection that we will be implementing is reverse polarity protection. When an input source is connected with the wrong polarity, the circuit will ensure that the electronics of the ASV are protected from any harmful side effects.

1. Autonomous Surface Vehicle Overview

1.1 Introduction

The purpose of this project is to engineer an electrical integration system necessary for an autonomous surface vehicle (ASV) to compete in competition. Integration involves power distribution and monitoring, sensor monitoring, and communication. This project involves knowledge and implementation of electrical and computer engineering. The integration includes using analog and digital hardware along with programming to interpret sensor information and relay it to the proper devices in the system.

1.2 Purpose

The Association for Unmanned Vehicle Systems International (AUVSI) and ONR (Office of Naval Research) hosts several autonomous robotics competitions each year for students to participate in. Besides our autonomous surface vehicle competition, AUVSI also hosts competitions for ground, underwater, and aerial environments. These competitions give students the opportunity to work together with other students in multiple disciplines to engineer unmanned vehicles. With a new set of rules every year, the teams must devise a plan to engineer their autonomous vehicle to meet the specifications and requirements set forth by the competition. Fortunately, the Robotics Club at UCF has the ability to participate in many of these competitions which are incredible learning experiences for all the students involved. The club has participated in the last three ASV competitions with great success. This year the ASV team has again decided to upgrade the electrical system for a more efficient and technologically advanced system.

1.3 AUVSI and ONR's 4th International ASV Competition

AUVSI and ONR host the international ASV competition for students to gain knowledge and to participate in. For the past two years including this year, the competition has been held at The Founder's Inn and Spa in Virginia Beach, Virginia. This facility generously hosts the competition for around ten to fifteen teams. The Inn has a large lake in the back of the property where the competition is held along with tents for each team and the judges. From June 9th through the 12th the teams will compete and have several opportunities to gain points through static judging, qualifier runs, and the final competition. The static judging consists of judges reviewing the teams' paper, website, t-shirts, and overall oral presentation. From the rankings of the static judging, the teams will choose the time in which they will have their two qualifying runs. From the points in the qualifying runs, the teams that make it through qualifying will choose their times for the final competition. AUVSI sends out a set of rules about seven months before competition which describes the challenges and the rules for the upcoming competition. The teams then take these rules and engineer a vehicle that can meet the competitions challenges.


The rules list the specifications including the size, weight, and other areas in which the vehicle must adhere to. For the AUVSI competition, the ASV's are limited to a vehicle which is three feet high, three feet wide, and six feet long and must weigh within certain limits. If the vehicle is lighter the vehicle is awarded points and if the vehicle is overweight, the vehicle loses points. This is done to ensure that the vehicles can compete together and that competitors don't build vehicles that are too large or heavy and create an unfair advantage compared to other teams. The final section of the rules specifies information about point distribution/weight as well as the specifications of the obstacles used in the course. This year's missions/challenges can be found in Table 1.1.

Table 1.1 - Competition Challenges

Thrust Test	Tests the thrust of the vehicle using the vehicle's motors at full power
Speed Test	Vehicle must pass through two gates with the first gate about 15-30 feet from the dock and the second gate about 50-100 feet away from the first gate. Each gate is about six feet apart from each other.
Navigate out of the harbor	This challenge requires navigating about a dozen sets of navigational buoys with some obstacles in their way.
The Challenge Stations	<u>(Earth) Amphibious Landing:</u> The vehicle will need to be amphibious itself or devise a way to deploy another vehicle in order to retrieve an object on a landing zone out of the water.
	<u>(Fire) Find the fire and extinguish it:</u> The ASV needs to locate a ship with a red cutout in it and spray water into the cutout until the fire is out which is designated by something changing on the ship.
	<u>(Air) Find and report the 'hot' target:</u> The ASV will locate a set of four targets, determine which target is the hottest and report its GPS location back to the base station.
	<u>(Water) Turn off the waterfall:</u> The ASV will locate a waterfall, go through the waterfall, and find a button to shutdown the waterfall.
Return to the dock	After all missions have been completed, the ASV will navigate back through the harbor to the starting dock.

Figure 1.1 shows the layout of the competition for this year's challenges. The course is divided into two almost identical courses which will most likely be used as a practice course and another for the actual competition. Starting from the dock you have the speed test through the gates followed by the navigational challenge. After that you can perform as many of the other challenges as you can before returning to the dock again within the 20 minute time period.

Figure 1.1 - Competition Map



Reprinted with permission from AUVSI

1.4 ASV Objectives 2011

Our overall objective for the ASV is to improve on last year's performance. Although we have performed extremely well over the past three competitions, there is still always room for improvement. This year the electrical has improved on the overall efficiency of the vehicle as well as improved on our integration and feedback systems. This means we can test longer with fewer interruptions for electrical worries.

1.4.1 Electrical

The electrical system has been redesigned this year to house a power grid that runs as a nominal 24V DC system. This year's focus has been to make the entire system more efficient by reducing standby current and focusing power distribution to the components that are essential to the vehicles operation; any other device has the

ability to either be turned off or have its power throttled to a minimum. The power board has enhanced capabilities this year ranging from hot-swapping input sources, reverse polarity protection and many other features that help protect the board from unforeseen accidents. We have incorporated light sensors on board to help determine the location of the sun in order to facilitate the vision recognition system. There is a dynamic fan control system that varies the fan speed according to the temperature of the main box in an effort to maintain an optimal operating temperature for maximum efficiency.

1.4.2 Software

From a top view, this project has two different levels of programming; one level consists of the high level decision maker executing code from a high end computer running a debian based Linux operating system. The lower level software consists of hardware-based programming and this code is executed using a network of a single FPGA with multiple microcontrollers; they will control basic motor control and sensor integration. The higher level programming uses the Joint Architecture for Unmanned Systems (JAUS) format as its base structure and thus all communication with devices linked with the on-board decision engine also follows a subset of the JAUS standard. This subset of JAUS is governed by the Robotics Club at UCF. As this design project only encompass the electronics aspect of the Autonomous Surface Vehicle, only the hardware based programming is within the scope of this project.

1.4.3 Mechanical

This year's ASV will undergo a few mechanical design modifications. Attentively, these changes include new hulls, and a wider frame used to connect the hulls. This wider frame will reduce the amount of wobbling the ASV has demonstrated when on the water. In addition to these changes the ASV has obtained a new motor box, and a new electrical box. These boxes are mounted side by side occupying the same general space as in previous years. To extend the ASV's capabilities Crust Crawler Motors have been added for enhanced propulsion. These motors are water cooled to protect them from overheating. Of the three motors, there is a center motor which has the ability to rotate 90° so that it can be used as a forward motor as well as a lateral motor for added maneuverability.

2. Specifications, Budget, and Timeline

This section is used to specify the requirements of the Senior Design team to meet the requirements set forth with the ASV team. We are continuously looking to improve the vehicle to make sure we have a competitive edge at competition both with the actual in water competition as well as in the static judging of the ASV. Below will describe the current objectives, budget, timeline for the team, testing goals, and assistance from the Robotics Club.

2.1 Technical Objectives

This year we have strived to achieve a greater vehicle that will meet a new set of specifications. We have acquired these specifications from the AUVSI competition rules as well as the needs of the ASV team. The senior design team has met these goals to the best of their ability.

- Nominally operate using 6-cell lithium-polymer batteries at 22.2V DC
- Distribute power with an efficiency of 85% or greater
- Monitor all power sources voltage and current with an accuracy of $\pm 1.0\%$
- Integrate all vehicle electronics onto a printed circuit board (PCB) for routing to the appropriate devices and components
- Seamlessly switch from shore power to battery power
- Implement vehicle safety including an emergency stop system to physically disconnect power to all moving parts
- Monitor vehicle temperature and humidity
- Implement a wireless platform to allow feedback via remote
- Receive visual feedback from an onboard and remote display

2.1.1 Goals

The following list describes the goals the senior design team has implemented for the ASV team:

- Provide an ergonomic system for easy assembly and disassembly of electrical components
- Provide necessary information for communication protocols between devices
- Allow calibration of voltage sensing
- Add test points on PCB for easy troubleshooting
- Label all parts on the PCB for easy troubleshooting
- Generate temperature and ambient light sensing
- Provide necessary wireless communication to receive ASV vitals via remote

2.2 Budget and Financing

This project is completely and generously financed by the Robotics Club at UCF in conjunction with their sponsors. The ASV itself has made two major purchases including a new set of thrusters with a spare motor (\$3,500), and a new computer (\$1,000). In addition to this the ASV has ordered two PCBs fully populated (\$500.00), a modified hull, and new sensors. We have allocated \$5,500.00 for the overall vehicle this year which does not include the cost of traveling to Virginia. We have reused many sensors and devices from last year to reduce the cost of the vehicle including cameras, compass, GPS, LIDAR, and FPGA. Table 2.1 is a more detailed table containing the vehicles components.

Table 2.1 - Project Cost

ITEM	FINANCE	APPROXIMATE COST
FPGA	ASV Team	\$150
LIDAR	Lockheed Martin	\$5,590
Stereo Vision	Lockheed Martin	\$3,000
GPS	ASV Team	\$1,500
Camera	ASV Team	\$700
Unibrain	ASV Team	\$100
Compass	ASV Team	\$1,500
Subtotal (Already Purchased)		\$12,540
LIDAR	Sponsorship	\$3,950
HD Webcam	ASV Team	\$100
ASV Computer	Sponsorship	\$1,000
Microcontroller (X2)	ASV Team	\$20
LCD Screens (X2)	ASV Team	\$60
ZigBee Pro	ASV Team	\$150
PCB Components (X2)	ASV Team	\$500
Pelican Case	ASV Team	\$100
Connectors	ASV Team	\$100
Mechanical	ASV Team	\$500
Subtotal (New Costs)		\$6,480
Total Cost		\$19,020

2.3 Timeline

A milestone chart has been created in Appendix B which describes the way our project was distributed between our group members. We tried to distribute the work according to our preferences and at the same time we tried to ensure that all of us have approximately the same amount of research to do. The research portion of the project was the most time consuming part, which can be seen in the Gantt chart. Our work was divided into three phases or stages as shown in the chart. The first stage is the research stage followed by the circuit design stage. Each of us completed our sections by creating the schematics, which was the final stage of our work. All this can be seen in the chart.

2.4 Testing Schedule

Design of such systems for our vehicle requires good planning and testing. This was the main subject for the second semester. We began the second semester by building and testing each subsystem to confirm they perform as intended. After completing this successfully, we combined all the subsystems and made sure our overall system works as planned. Some unexpected results have occurred; therefore we had to change portions of the design and repeat the testing and tuning procedure until the desired outcome was achieved.

2.5 Consultants and Suppliers

The following few sections describe the consultants and suppliers that our senior design team and ASV team have worked with throughout the scope of this project. They included academic advisors and mentors from the university and various companies.

2.5.1 ASV Team

Our senior design group was composed of four members; two of the four members were part of the robotics club in previous years, and have remained active members of the ASV team. With the aid of previous experience our senior design group was better capable of integrating the desired design and testing techniques needed to realize a more robust ASV.

2.5.2 Advisors

The two main advisors will be Gary Stein and the robotics club academic advisor Daniel Barber. Both advisors are previous members of the robotics club and have a vast array of robotic competition experience. With the support of these advisors our group will remain on schedule and overcome any hurdles that may be presented to us.

2.5.3 Suppliers

To accommodate our design requirements many suppliers were used to supply the vast array of components that were utilized. Our specific design required the purchase of a FPGA board, microcontroller, various sensors, and etc devices. To account for the accruing financial cost, the ASV team used the existing sponsorships from Lockheed Martin, as well as the Institute for Simulation and Training (IST) and U.S. Army Research, Development, and Engineering Command (RDECOM).

2.6 Facilities and Equipment

Another benefit of having membership in the Robotics Club is the access to the Robotics Lab. Our lab is located in the Partnership II building on Research Parkway. The lab space is quite large and houses all the club's projects including the IEEE, ground, sub, and surface vehicles. The lab is also equipped with a machine shop, electronics workbench, and storage for the vehicle and its related parts.

The electronics workbench is where most of our work was performed. It houses our power supplies, oscilloscopes, function generators, and soldering stations. In addition to this, the club has a variety of tools for crimping, stripping, and cutting wire. A vast array of wire types and sizes are also available along with electrical components ranging from passive components to many active components. This saved us from making many trips out to stores for supplies.

3. Research

3.1 Power

3.1.1 Emergency Stop

One of the competition rules for this project is to have E-Stop functionality. This feature will be triggered by multiple E-Stop buttons on the boat, and also remotely. Even if this feature had not been a part of the requirements, any such scale design, with this many features and devices connected would have an E-Stop functionality. This would be triggered under certain conditions to prevent the circuit boards and the connected devices from damage. It's important to note that equipment protection comes after human protection, which is also provided by the E-Stop circuit. By designing this circuit, we assumed that the E-Stop circuit will be used very frequently; therefore it is in a location visible to everyone. For that purpose our E-Stop trigger is a big, red button. The operator has access to an E-Stop button anytime, which enables him/her to trigger it in an event that the vehicle is out of the water, or in case of danger or emergency. Taking this into consideration we have designed such a circuit. Our E-stop circuit can be triggered by 3 buttons, and also wirelessly. There are quite a few E-Stop designs that we considered, however, all the designs have one device, the relay, in common. The relay is the most important and crucial component of this circuit. When there's current through the relay and the circuit is complete, our motor controllers and motors are powered. In this state the relay must be able to provide the necessary current to meet the load needs. In the case when the E-stop is triggered any power needs to be cutoff and our motor controllers and motors need to be completely turned off. In addition to desired performance we need to consider efficiency and cost.

The great abundance of relays and applications in which they are used, makes it very difficult to choose a relay. However, we simplify this issue by considering some key factors and features that one must consider when looking for a relay. These factors and features are summarized in Table 3.1.

Table 3.1 - Features that must be considered before buying relays

Factor	Specification
Cost	As low as possible for the given specs.
Power requirements	How will the relay be powered, AC or DC? How much power will the relay dissipate?
Switching	At what voltage is the current being switched? How much current is being switched? How much total current can the relay handle?
Contact arrangement	Are we going to use type A, type B, or type C contact arrangement relays (explained later in this report)?
Switch contact arrangement	Is the relay of choice going to be: "single pole changeover (SPCO)", or "double pole changeover (DPCO)"? How many poles will the relay have, are we going to use a separate relay for each motor controller, or we can purchase a multi-pole relay.
Mounting type	This includes surface mount, printed circuit board (PCB) mount, plug-in socket, top mount, top-mount PCB, etc.

One very important technical aspect of a relay is the contact arrangement. Relays are available in three different contact arrangements. These arrangements and their operational specifications are given in Table 3.2.

Table 3.2 - Summary of Relay Contact Arrangements

Form	Description
A	This is the normally open (NO) arrangement, which means that the switch is open when the coil is not energized, and it's closed when the coil is energized.
B	This arrangement is known as normally closed (NC). When the coil is not energized the switch is closed, and the switch is open when the coil is energized.
C	This arrangement is a combination of the first two types.


The contact arrangement has been chosen based on our needs. Another factor that one must consider before buying a relay is the technology. Here we have considered 4 widely used technologies.

3.1.1.1 Electromechanical Relay (EMR) [30]

The first relay we looked into was the electromechanical relay. This device is mainly mechanical. A voltage is applied to the coil of the relay. If enough voltage is applied to the coil the core of the relay magnetizes and pulls the arm towards it. This action connects the two sides of the contacts to establish a connection as illustrated in Figure 3.1. The electromechanical relay has many advantages; it's very cheap, readily available, it's robust, and bulky, which we associate with reliability. The EMR is a cool working device and doesn't need a heat sink. Another great feature is that electromechanical relays are also available in multiple poles, which may reduce

space requirements. However, it's important to mention the fact that EMRs are big and can create difficulties to mount on PCBs, especially when space is limited. Other disadvantages include relatively slow switching speed and loud switching.

Figure 3.1 - Electromechanical Relay Operation




Reprinted with permission from National Instruments

3.1.1.2 Solid state relay (SSR) [30]

The solid state relay is another widely used relay. This device is based on transistor technology, which is not mechanical. The operation technique of the SSR can be summarized as follows: an input voltage is applied to an LED. The light of the LED is reflected within an optical dome onto an array of photo diodes. The photo diodes generate voltage which through some circuitry is used to control the gates of two MOSFETs. A picture that makes this clear is shown in Figure 3.2. Advantages of the SSR include low noise operation, virtually unlimited switching, small size, small ON resistance, approximately zero output attenuation, etc. All the factors mentioned above must be taken into consideration when buying a relay. One drawback of the SSR is that price and size increase proportionally with higher performance.

Figure 3.2 - Solid State Relay operation



Reprinted with permission from National Instruments

3.1.1.3 FET switch [30]

FET switches are another type of non-mechanical devices that can be used as relays to switch high loads. This device has all the advantages of SSRs and in addition, it's the fastest switching device, and can be smaller than all the other technologies. However, one disadvantage is that this device doesn't provide voltage isolation, which may create hazardous situations. This device is not a likely choice for our E-Stop circuit, since it doesn't provide isolation from the voltage. This would defeat the purpose of the E-Stop circuit. However, in small voltage applications this device is ideal because of its great features.

3.1.1.4 Reed relays [30]

The reed relay is another type of electromechanical relay. The advantage of this relay in contrast with the EMR is the 10 times faster switching speed and longer lifetime. This device may be useful for our low power switching needs, but it's almost of no practical use for high power operation, since the thin and small contacts melt at high voltages and currents, and may permanently weld the switch. Table 3.3 is a brief summary of all the different technologies and their details for quick referencing.

Table 3.3 - Relay summary: Different technologies, their advantages and disadvantages

Relay Summary	
Technology	Properties
Electromechanical Relay (EMR)	Cheap, no heat sink necessary, multiple poles available, 5-15 ms switching time, robust, available in all contact arrangements, relatively big in size.
Solid State Relay (SSR)	Very fast switching, very long life time, relatively small in size, cheap, heat sink may be needed.
Reed Relay	Small, fast, longer lifetime relative to the EMR, not ideal for high voltage applications.
FET switch	Fastest switching, very long lifetime, very small in size, no isolation, hence good for low voltage applications.

As we can see relays have many specifications that must be identified. Considering these technical information we identified our needs based on which we chose an appropriate relay. The devices that are being turned off as soon as E-Stop is de-energized are three Crust Crawler thrusters used to propel the boat (20A each), a water pump (1A), that is used for providing water to the motor controllers for cooling purposes, two Sabertooth motor controllers (20A max each), two servo motors (1A each); in addition there is an extra relay, or an extra pole. The thruster is the device with the biggest power rating. At maximum thrust and 24 volts this devices is rated 400 W. Simple calculation shows that the relay of our choice has to

handle at least 16.67 amps at 24 volts. However, the batteries will not be able to supply constant 24 volts, which could cause current variations. Taking this into consideration, the relay of our choice must be able to switch 25 A. All the other devices have power ratings that are considerably less than the thruster rating; therefore we should be able to use multi pole 25 A relays. As outlined above, we need at least 6 relays. We can use two 4 pole relays, or a single relay with at least 7 poles, to ensure we have at least one spare. All the requirements mentioned above and other specifications are given in Table 3.4.

Table 3.4 - Minimum current/voltage requirements that must be provided by the relays

Relay Requirements and Specifications				
Feature	Crust Crawler	Water Pump	Sabertooth Motor Controller	Servo Motors
Component Count	3	1	2	2
Cost	Less than \$100.00 per relay	Less than \$100.00 per relay	Less than \$100.00 per relay	Less than \$100.00 per relay
Coil Power requirement	12V DC powered	12V DC powered	12V DC powered	12V DC powered
Contact power Requirement	Switches at 24V, at least 60A total	Switches at 12V, at least 2A	Switches at 24V, at least 40A total	Switches at 5V, at least 1A
Contact arrangement	Form A (Normally Open)	Form A (Normally Open)	Form A (Normally Open)	Form A (Normally Open)
Poles	Capable of handling 60 A, either multiple poles with low current rating, or single pole, with at least 60A rating	Capable of handling 2A	Capable of handling 40 A, either multiple poles with low current rating, or single pole, with at least 40A rating	Capable of handling 1A,
Mounting type	Chassis mount, panel mount, socket	Chassis mount, panel mount, socket	Chassis mount, panel mount, socket	Chassis mount, panel mount, socket

3.1.2 Reverse Polarity

Throughout our report we mentioned numerous times about our power requirements, and also about our high voltage and current ratings for some of the components. Therefore it makes sense for us to use some kind of protection, in the event the batteries are connected with the wrong polarity. There are few ways to do this, and collectively these methods are called “Reverse Polarity Protection”. In this section we will discuss several of the most popular methods, and choose the method that best suits our technical specifications. All of the methods that will be discussed are effective in achieving the goal. However, since we have high current requirements, we had to ensure that the circuit we chose to complete the reverse polarity protection task was able to handle the high currents that our batteries are providing to the circuits.

Table 3.5 is included as a quick reference and a reminder of the currents that may be drawn from the respective batteries. The values in the table are maximum ratings. Even though our batteries are able to provide higher currents, our circuits should never exceed the values given in Table 3.5.


Table 3.5 - Current ratings for the different power sources

Source	Maximum current
Logic Battery	15A
Shore	30A
Motor Battery	60A

3.1.2.1 Method 1

The diode can be used to protect circuits from reverse battery polarity in two different ways. In one configuration the diode is connected in series, the second method utilizes a parallel diode. The first circuit option is shown in Figure 3.3.

Figure 3.3 - Reverse Polarity Protection using Series Diode




As described above the diode in this circuit is used in series. When the battery is not connected with the proper polarity, the diode will not conduct, basically blocking the current from flowing. A detail that we have left out is the fuse connected in series with the diode, this is an extra measure in this case, and provides another degree of protection. We have to ensure that the fuse rating is above our maximum current rating, to ensure it doesn't break unnecessarily. A disadvantage of this design is the voltage drop across the diode, which can range from 0.7 – 1.7 V [3] depending on the diode type. That means if we were to have a 10 V DC source,

using the diode in series, would reduce the battery to a 9.3 V source. In addition we could only use this battery 0.7 V above its minimum voltage rating [38]. This is a very big drawback. We most certainly could reduce the voltage drop by using a Schottky diode (0.4 V drop), or if we could use a Germanium diode. This would allow us to cut the voltage drop to 0.3 V [38]. However, using these diodes could have a very strong effect on the cost effectiveness of the circuit, by increasing the price a few times. Therefore, we considered another circuit configuration, where the diode could be used in parallel with the battery (DC voltage source).

3.1.2.2 Method 2

We have mentioned that the second design utilizes a diode that's in parallel with the battery. This circuit is given in Figure 3.4. The idea behind this circuit is a little different than the first design we discussed. When the battery is connected with the proper polarity, there's no problem, the current will flow and power will be transferred to the load. Note that for this case there's no voltage drop across the diode.

Figure 3.4 - Reverse Polarity Protection Using Parallel Diode




However, when the battery is connected with the wrong polarity, the diode will get a forward potential difference of at least 0.7 V. This will force the diode to turn on, and consequently short the branch. This will result in a closed loop consisting of the battery, diode and the fuse. The current will gradually increase and when it reaches the rating of the fuse, it will break, resulting in an open circuit. This is a very good and reliable protection. The fuse can be replaced easily if it breaks. The disappointment in this circuit is the power dissipation in the fuse, which is negligible compared to the voltage drop across the diode. However, we were trying to eliminate any unnecessary power dissipation. The third design we considered utilized a MOSFET to achieve this purpose.

3.1.2.3 Method 3

This design uses a modern transistor semiconductor switch to protect the circuit from reverse power supply [38]. The MOSFET will turn on and complete the circuit if the battery is connected properly. If the battery is not connected properly, the MOSFET will stay off. Of course, the description above is very simple. This circuit uses the inherent p-n junction that is part of any FET. Since we have a positive power supply with a ground, we could use a P-Channel FET, and could connect this FET in the "backward" configuration. This means that we could connect the drain to

the positive voltage supply. We know that for P-FET devices the source needs to have a higher potential than the drain to conduct. This is true, but there's another way of getting saturation current in the channel of the FET. When the gate voltage is much less than the potential on the drain-source channel, there will be current conducted from the drain to source. To get reverse polarity protection, it is essential to connect the FET backwards. As mentioned above, during the fabrication of any FET there's an inherent built-in diode that effectively has its anode connected to the drain, and cathode connected to the source of the FET. If we connect this device in the "right" configuration, source to positive supply, then when the battery is connected with the wrong polarity, we would have a diode that would turn on and conduct current. So there's no protection at all. On the other hand, if we connect the FET "backwards", then a negative power supply would reverse bias the diode, which would result in no current flow. Well, to be precise there will be some leakage current, which is negligible [38]. So this is a very effective way of protecting circuits from reverse polarity. People, who have utilized this circuit, say that the voltage drop from drain to source is approximately 20 mV, which is very small compared to a 0.7 V drop that we could get across a diode. One disadvantage of this method is the fact that FETs with high current ratings are expensive. A schematic for this circuit is given in Figure 3.5.

Figure 3.5 - Reverse Polarity Protection Using P-FET




Of course we can extend our discussion to N-FET devices if we use negative power supply. The analysis is very similar. As for the previous two designs, we could add a fuse in line with the positive supply of the battery. This will provide another degree of protection. However, it will increase the power dissipation of the circuit.

3.1.2.4 Method 4


The last design we considered uses 4 diodes to achieve full wave rectification [3]. In this case we would not be concerned about the polarity of the battery, since all the negative voltage will be rectified. We have seen this circuit before in our electronics classes. The first case, where the polarity of the battery is correct, we have the circuit shown in Figure 3.6. For convenience we have shown the positive and negative polarities in red and black colors respectively.

Figure 3.6 - Full Wave Rectifier (Battery polarity is correct)



However if we change the polarity of the battery, the result would be the circuit shown in Figure 3.7. In this circuit we note that our load would see the proper polarity, and there would be no damage to any circuitry. The problem with this circuit is the 0.7 V drop across each diode that is conducting. As noted there are at least two diodes conducting continuously, which represents an unacceptable 1.4 V drop just for the reverse polarity circuitry.

Figure 3.7 - Full Wave Rectifier (Battery polarity is not correct)




For our design needs we chose to implement Method 2, with a fuse and diode in parallel with the battery. This provided us with all of the requirements we needed in addition to having a simplistic design.

3.1.3 Hot Swapping

To power our boards, computer, motors, and all other devices we use different power sources. We have a battery for all our logic circuitry, another battery for the motors, and also we have shore power which comes from an 115V AC to 24V DC converter. We must be able to keep the boat powered on, at least the computer and the logic boards. For this purpose we must have a way of switching from battery to shore power without interrupting the power supply to the computer and logic boards. This is usually called “Hot swapping”, or “Hot plugging” in the industry. The additional circuitry that was implemented for hot swapping had to be able to sense the presence of the shore power, and disconnect the batteries without disrupting the

operation of the system. Although, there are several ways this could have been implemented we chose to utilize a circuit that uses relays and Molex connectors. This circuit is given in Figure 3.8.

Figure 3.8 - Hot Swapping Circuit



The functionality of the circuit in Figure 3.8 is quite straight forward. In this circuit we see two symmetric “Molex 2 x 3” connectors. Battery and shore powers are connected to these connectors as indicated in the figure. There are two Form C relays present in the circuit. These relays were used to switch the power supply between these two sources. The connector on the battery side has different batteries connected to it. As we can see in the design, pins 2 and 3 are used to share the power of the motor battery, which is 22.2V DC, and similarly pin 1 is connected to the logic battery, which is able to supply 14.4V DC. Please note that this year all batteries supply 24V DC. The coils of these two relays are connected parallel with the shore power connector, which means shore power will be used to power these relays. As soon as shore power is applied, the relay coils will be powered, since there’s a path to ground between pins 1 and 6. As soon as the coils reach the threshold currents, the switches of the corresponding relays will switch, and the batteries will be disconnected, and power will be supplied from the shore. The shore voltage may be higher than the battery voltages, however through voltage regulation the appropriate voltages will be supplied to the corresponding circuits. In addition to meeting our needs this particular design method has proven to be reliable in previous years. There were other circuits that could be implemented to accomplish the hot swapping function. Another effective way would be using special power path controllers.

3.1.4 Voltage Regulation

Several voltage regulators were incorporated into our system to provide adequate power to all electronic components on the vehicle. Using data collected we have determined the vehicle will need at least three voltage regulators. This will include one five volt regulator, one eight volt regulator, and either one or two twelve volt regulators. In the previous year’s vehicle, the power regulation section had two five volt regulators which stemmed from a safety issue. This year we have determined that this is necessary, and used an additional 12V regulator instead of the previous five volt regulator. The five volt regulator is used to power the five volt devices and

circuits on the vehicle. This includes powering the FPGA, microcontroller, display, servos, GPS, sensors, and other onboard IC's. The eight volt regulator powers the compass and cameras. One of the 12V regulators is used to power the stereo vision system, the LIDAR(s), the wireless bridge, and other components

Factors to look at when choosing a regulator:

- Topology
- Current Rating
- Input voltage range
- Output voltage range
- Efficiency
- Thermal Characteristics
- Package Type
- External Components
- Output Noise/Ripple
- Footprint

Power for the vehicle is provided by multiple sources including shore power, logic batteries, and motor batteries. While the vehicle is not undergoing testing in the water, shore power provides adequate power for the vehicle to operate for testing purposes. This gives us the advantage to test the functionality of the vehicle without consuming battery power and depleting charge cycles on the batteries. One option for shore power was using an industrial power supply capable of providing 24V DC at 25Amps to the vehicle. The second option for shore power was using one 12V DC deep cycle battery or most likely two 12V DC deep cycle batteries in series to provide 24V DC.

For testing in water the vehicle needs enough battery power to meet our requirement of two hours of run time. From previous years of competition, the Robotics Club at UCF already owns many batteries that are available. We chose to use our 4 cell lithium polymer batteries which provide a voltage of 16.8V DC charged or use our 6 cell lithium polymer batteries which provide a voltage of 25.4V DC charged. By using a combination of batteries connected in different configurations we can achieve the desired input power required for the vehicle. When the vehicle is running on batteries it receives power from logic batteries as well as motor batteries. Logic batteries power all sensors, circuitry, and processing while the motor batteries primarily power motors and related motor components. The reasoning behind two sets of batteries is that logic batteries will deliver about 100W of continuous power while the motor batteries have a constantly changing load depending on the amount of power sent to each motor. This load could vary from 0W to 1200W which would make the logic power and sensitive logic components not as stable as possible; therefore, we implemented dedicated batteries for each system. While the vehicle is on shore power, all systems on the vehicle except the main thrusters use shore power. The main thrusters are not connected to shore power as this could cause major damage to the power supplies which cannot handle the load of the motors if they were to accidentally operate at full load. In addition, the motor controllers for the main thrusters use water cooling which means that

when the vehicle is out of the water the motor controllers should never receive power to avoid damage to them from overheating.

In determining which batteries we should use for logic batteries we have used MathCAD to determine which batteries yield the greater efficiency. In general with buck converters, the higher the differential voltage between input and output the less efficient the converter becomes. But, using the general power equation of $\text{Power} = \text{Current} \times \text{Voltage}$, the higher the voltage the less current is needed. Therefore, it was necessary to see if the higher input voltage (from batteries) outweighs the higher efficiency from a lower battery input voltage. In MathCAD we used two input voltages of 24V DC and 12V DC. Then we used the efficiency values from Texas Instrument's TPS5450 buck converter given a 12V output. After solving for the current draw at these different voltages it was clear that the improved efficiency of lower voltage batteries does not compensate for the reduced current draw from using higher voltage batteries. Therefore, we have concluded to use our 6 cell lithium polymer batteries for a more efficient vehicle. In previous years we have used the lower voltage batteries and have had good run time but having more run time allows us to test for a longer time without interrupting constantly due to batteries.

Logic batteries serve many purposes. The first purpose is to regulate the input voltage to multiple output voltages using three or four regulators as discussed before. Computer power also comes directly from logic batteries as unregulated voltage, but uses its own regulator purchased with the computer for power. We have determined that the computer consumes about 60W of power while using all processing power. Table 3.6 specifies the requirements for each of the three power regulators required. The power regulators used have enough margin to add components that might need to be added at a later time. Using the proper topology for each regulator needed ensures that the components are cost efficient, power efficient, and have a small footprint on the PCB.

Table 3.6 - Voltage Regulation Requirements

Power Regulators			
#	Vout	Iout	Power
1	5.0	3	15
2	8.0	1	8
3	12.0	4	48
		Total	71W

Since our output voltages do not exceed the minimum input voltage our application only required the use of a buck converter. Since this year we will be using a voltage monitoring system we don't want to run the vehicle with an input source lower than 14V DC. If the converters don't have a duty cycle of 100% then the source will have to remain higher than 12V DC. There are many other topologies available in the industry including a buck-boost converter, a SEPIC converter, a forward converter and many others that could have been implemented. The use of a flyback or forward converter would create a converter with isolation from the input to output. Although this has its advantages it is not part of our requirements to isolate

the input sources. Using these types of converters would also introduce more magnetic components which would mean using more inductors as well as a transformer with multiple windings.

The two most commonly used regulators are linear regulators and switching regulators which each have their own set of advantages and disadvantages depending on their application. “Linear regulators provide sufficient advantages over switching regulators in simplicity, cost, and output noise, but not efficiency” [26]. Since we want the ASV to have the greatest efficiency while in operation during competition, we needed to chose the best regulator topology to satisfy the need for extending battery life. While the ASV is connected to shore power, efficiency is not as critical due to the unlimited supply of power.

Table 3.7 [26] illustrates a simple overview of the differences between a linear and switching regulator.


Table 3.7 - Linear vs. Switching Regulators

	Linear	Switching
Function	Only steps down; input voltage must be greater than output.	Steps up, steps down, or inverts
Efficiency	Low to medium , but actual battery life depends on load current and battery voltage over time; high if $V_{IN}-V_{OUT}$ difference is small.	High , except at very low load currents (μA), where switch-mode quiescent current is usually higher.
Waste Heat	High , if average load and/or input/output voltage difference are high	Low , as components usually run cool for power levels below 10W
Complexity	Low , which usually requires only the regulator and low-value bypass capacitors	Medium to high , which usually requires inductor, diode, and filter caps in addition to the IC; for high-power circuits, external FETs are needed
Size	Small to medium in portable designs, but may be larger if heatsinking is needed	Larger than linear at low power, but smaller at power levels for which linear requires a heat sink
Total Cost	Low	Medium to high , largely due to external components
Ripple/Noise	Low ; no ripple, low noise, better noise rejection.	Medium to high , due to ripple at switching rate

Copyright Maxim Integrated Products (<http://www.maxim-ic.com>). Used by Permission.


Linear regulators are limited in that they are only able to step down the output voltage from the input voltage. Figure 3.9, shows an example of a linear buck converter where the output voltage is half of the input voltage. Due to the topology in which all the circuitry is in series the excess voltage is dissipated across the linear device greatly reducing efficiency. This is similar to our application in which our nominal input voltage is 24V DC with regulated output voltages ranging from 5V DC to 12V DC.

Figure 3.9 - Linear Buck Converter



These circuits use negative feedback to regulate the output as seen in Figure 3.10 [31]. The regulator regulates using an error amplifier with negative feedback. The error amplifier's negative input terminal is a scaled voltage of the true output voltage. The error amplifier's positive input terminal is connected to a reference voltage, which according to National Semiconductors is derived from an internal bandgap reference. It uses negative feedback because as the output voltage goes to high it tries to do the opposite and bring the output voltage back down to the desired output level so that the input terminals of the error amplifier are equal in value. The error amplifier "sources current as required to provide sufficient load current to maintain the output voltage at the regulated value" [31].

Figure 3.10 - Linear Regulator Negative Feedback




These devices are generally three terminal devices which are very easy to use. Most of the time they only require the use of external capacitors to decrease ripple and increase the stability of the circuit. Since it generally uses a very small footprint it is often used in applications where there is little board space and where the voltage drop between input and output is small. Even though this footprint is small, excessive power loss in the converter can translate into needing large heat sinks to dissipate the heat. If this is the case then you have not conserved the size of the footprint and a switching regulator may be a better option.

The switching buck regulator is our choice of regulator for the ASV. Our application has the criteria of a large difference between our highest input voltage and lowest output voltage, high output current at full load, and the need for high efficiency for extended battery life. Figure 3.11, shows the basic topology for the

switching buck converter [32]. The general topology consists of two switches, an inductor, capacitor, and load resistor. The switches are realized as transistors and diodes as seen in the figure. In mode 1 when the switch is on, the diode is blocking and the current is flowing charging the inductor as well as providing output current to the load. In mode 2, the switch is off and the diode is conducting allowing the current flow to continue providing current to the load. The length of time for which the switch is on and off is determined by the duty cycle. The duty cycle is determined by using feedback from a compensator, comparator, and an oscillator. The compensator could be a second order operational amplifier which has an output of gain as well as shifts the phase of the circuit. The inputs to the operational amplifier include a scaled version of the regulated voltage and a reference voltage with the output being the difference of the two inputs of the amplifier. The compensator also adjusts the phase of the circuit to have a phase margin of about 50 degrees at the desired crossover frequency to ensure stability of the circuit. If a system is unstable then it is not critically damped and can begin oscillating and not recover to a stable operating point. After that, the compensator then outputs the signal to a comparator which compares the signal to a ramp function. The comparison of these values determines the duty cycle provided to the switch. Comparators output either a high or low signal depending on the condition of the inputs. Basically, if the voltage drops below the regulation point the duty cycle will increase to compensate for the drop in output voltage meaning the comparator outputs a high until the system realizes the circuit is back to its regulation point. The duty cycle, therefore, is recognized as a square wave with a value ranging from zero to one. If a device is operating with a 30% duty cycle then it means that the switch is on for 30% of the switching period and off for the remaining 70% of the switching period. If you calculate the ideal transfer function you will see that the duty cycle is equal to the gain of the converter and therefore the $Gain = \frac{V_o}{V_i} = D$.

Switching regulators run in either continuous conduction mode (CCM) or discontinuous conduction mode (DCM). In Figure 3.11 [32], when the switch is on, the inductor is being energized and has a certain level of current flowing through it. If, when the switch is off and the current is decreasing in the inductor but the inductor current never reaches zero it is said that the converter is running in CCM. If, when the switch is off, there is a period of time for which the inductor current is zero the converter is said to be operating in DCM. "Overall performance is usually better using continuous mode, and it allows maximum output power to be obtained from a given input voltage and switch current rating" [32]. National Semiconductor's also claims that "discontinuous mode operation at lower load current values is generally harmless" [32]. This is where our decision to use two 12V DC regulators arises from. Even though it is "generally harmless" we have designed for only one 12V regulator. We felt that the worst thing that would happen is that the emergency stop circuit would not receive power; which would only cause the motors to not work. There are very few times in which the vehicle would experience such low loads that the regulator would fall into DCM mode. Therefore, we used only one regulator conserving valuable board space.


Figure 3.11 - Switching Buck Converter



Reprinted with permission of National Semiconductor Corporation

Figure 3.12 [32] illustrates an inverting boost converter which also consists of a switch, inductor, diode, and capacitor. With the switching regulator in mode 1, the switch is on and the diode is blocking which is therefore energizing the inductor by the source. After the switch is turned off, the inductor's voltage is forward biased and looks like another voltage source in series with V_{in} causing a boost in voltage as the diode is now conducting. This circuit also uses a similar technique for controlling the duty cycles (PWM signal) as before. Equation 3.1 shows the gain of the circuit as found through calculating the ideal transfer function. With a low duty cycle there is practically zero gain in the device and the input voltage is equal to the output voltage. As you increase the duty cycle it creates a value less than one on the denominator causing the gain in the converter to increase.

Figure 3.12 - Switching Boost Converter



Reprinted with permission of National Semiconductor Corporation

Equation 3.1 - Boost Gain Equation

$$Gain = \frac{V_o}{V_i} = \frac{1}{1 - D}$$

The goal of the ASV is to run off of a 24V DC system to decrease the current draw on the batteries while power from the 24V DC batteries will regulate to voltages of 5V DC, 8V DC, and 12V DC. This difference in input to output voltages is the first indicator that a linear regulator would not be the best option. Linear regulators work best when the input to output voltage differential is small. The power losses on a linear regulator can be calculated using Equation 3.2 where you can see that as the output voltage becomes lower the power wasted increases. For our application an input voltage of 25V DC with an output voltage of 5V DC at 3 Amps would result in a waste of 60 Watts which is a large waste of power and would require a large heat sink. Therefore we have designed the system to use multiple switching regulators.

Equation 3.2 - Linear Regulator - Power Wasted

$$Power\ Wasted = (Input\ Voltage - Output\ Voltage) * Load\ Current$$

3.1.5 Voltage and Current Sensing

In order to monitor the power consumption of the vehicle the ASV has incorporated voltage and current sensing. This enables the system to know the total power consumption by using the microcontroller to read and multiply these values together. The information collected is then displayed on the external displays and is also available to the main computer. Knowing our power consumption under different loads enables the team to determine an approximate run-time for the ASV. Each power source has its own monitoring. Therefore, shore power, logic batteries, and motor batteries are all individually monitored. The technology for accomplishing this task is quite simple and is often used in many applications.

3.1.5.1 Voltage Sensing

One method for sensing voltage is by connecting the positive terminal of the power source to an analog to digital converter (ADC). There are many factors that must be considered when using this method. The first limit is that analog to digital converters can only compare voltages up to their input or reference voltage. For our application we would use an ADC with a reference voltage of 5V DC. This means that we would need to bring all three of the power source voltages down to a safe level for the ADC. A simple voltage divider using two resistors would allow for this. The logic power on the vehicle can operate using a wide voltage range of about 14V DC to 30V DC meaning that dividing this voltage by a factor of six would give the ADC an input range of about 2V to 5V DC. Our goal was to sense the voltage accurately and view the voltage with at least two digits before and after the decimal (XX.XX). In addition, the voltage on the source shouldn't change rapidly so the need for a super high sampling rate is unnecessary. The sampling rate determines the number of times per second in which the signal is measured and a conversion from analog to digital occurs. Most sampling rates are very high and it would seem unnecessary for a very high rate. In fact, according to the software team, using a higher than necessary sampling rate allows software to filter the data and reduce fluctuations of the value. The accuracy of the value depends on the number of bits the ADC converts the number into. For example, using an ADC with a reference voltage of 5V DC and 12-bits of resolution while ignoring the two least significant bits would result in voltage increments of .0048V DC which is acceptable for our application. Using a zener diode we can protect the input to the ADC's from voltages that might exceed its rated input limit. By placing about a 5V zener diode between the input signal and ground will help protect the circuit by allowing current to flow to ground instead of into the ADC in the case that the voltage after scaling is above 5 volts and could damage the ADC.

The reason that sensing this voltage is crucial to the vehicle is for battery protection. Our major source of battery power comes from lithium polymer batteries. We have chosen these batteries because of their proven high energy to weight ratio. The way these batteries are manufactured and sold is by the number of cells per battery pack. Each lithium polymer cell can range from 2.7V DC discharged to a full

charge of 4.23V DC with the nominal voltage at 3.6V DC [23]. It is also recommended that if the battery reaches 3V DC that they should be recharged as soon as possible to avoid serious damage. Given these limits, it is very important to monitor the voltages from a personal safety standpoint as well as a battery/vehicle safety standpoint. This type of battery can easily catch fire if not maintained and handled properly. Therefore, by monitoring their voltages we can continue testing without worrying about battery voltages and checking them manually on a regular basis. The second source of power comes from shore power which can consist of an AC to DC power supply with a known voltage or using one or more deep cycle batteries. In the case that the vehicle is running on one 12V DC deep cycle battery during vehicle transportation it is critical that the voltage stay about 12V DC so that our 12V DC devices and regulators maintain proper operation. We normally never operate with a single deep cycle battery to avoid power regulator malfunctions. Again, it is easier to monitor its voltage with our voltage sensing system to ensure proper vehicle operation as well as ensure proper battery safety.

3.1.5.2 Current Sensing

Current, the other half of the power equation, can be measured in more than one way. After research was collected, we implemented the best choice as described further in the design section.

Factors in choosing a current monitoring system:


- Accuracy
- Cost
- Ease of Use
- Footprint
- Output Signal Type
- Additional Components
- Printed Circuit Board Layout
- Size
- Power Dissipation

Current Transformer: The first method involves using a transformer to find the current flowing in a circuit. By using a transformer you create isolation between the active circuit and the sensing circuit. Although that can be useful for some applications it is not very useful in our application as using transformers requires the use of alternating current (AC) whereas our system is all direct current (DC). The current transformer would work just like most transformers where the current on the secondary is proportional to the current on the primary. This is great for very high current applications like industrial power monitoring where 500 amps can reduce to 5 amps with a turns ratio of 100:1 on the transformer. Low cost models are generally designed to only work at low frequencies. Two of the advantages are that it does not require an external power source nor does it have an offset voltage when no current is present.

Shunt Resistor: The next option for current sensing uses an inline shunt resistor together with an integrated circuit to measure current. An example of this is illustrated in

Figure 3.13 where the shunt resistor is attached to a device that measures the voltage drop across the resistor. Most integrated circuits used for detecting the voltage drop across the shunt resistor are operational amplifiers configured to be used as difference amplifiers. The sense resistor usually measures a few milliohms to reduce the voltage drop across the resistor and minimize power losses. Even though the resistor chosen is small the sensing works by measuring the voltage drop across this resistor. For example, if the current through the sense resistor varies from 0.1 amps to 10 amps and the sense resistor is 0.004 ohms, then the voltage drop across the resistor would range from 0.0004V DC to 0.04V DC. The IC generally amplifies this voltage so that an ADC can determine the voltage drop without needing excessive resolution.

Figure 3.13 also illustrates the difference between measuring current on the high side of the circuit versus the low side of the circuit. Although it appears that there is not much of a difference there are actually many advantages and disadvantages of using each method.



High Side Current Sensing: High side current sensing, as seen in Figure 3.13, involves placing the sense resistor close to the voltage source and before the load of the circuit. Advantages and disadvantages include can be seen in Table 3.8

Table 3.8 - High Side Current Sensing

Advantages	Disadvantages
Since the current sense resistor is connected close to the power source it enables the user to detect any downstream failure and trigger appropriate corrective action if necessary [44]	When on the high side it is very important to ensure that you pay attention to resistor matching. This ensures an acceptable common-mode rejection ration (CMRR) [44]
The high side sense resistor won't create the unwanted extra ground disturbance that is inherent when using a low side current sensing design	When using amplifiers, it's important to ensure it can withstand high common-mode voltages that are often outside the rails of the amplifiers implemented [44]
Using the high side simplifies the layout when placing components on the printed	

circuit board [44]	
Improves overall circuit performance when compared to using low side sensing [27]	

Low Side Current Sensing: Low side current sensing, as seen in Figure 3.13, is configured in such a way that the sense resistor is located between the load and ground. This also has its advantages and disadvantages but low side current sensing is not as widely used as high side current sensing. The fact that using low side current-sense amplifiers splits the ground plane, causes adverse effects on noise immunity and ground loops as seen in Table 3.9 [27].

Table 3.9 - Low Side Current Sensing

Advantages	Disadvantages
According to Texas Instruments the low side setup is straightforward, easy, and rarely requires more than an op-amp to implement in addition to being inexpensive and precise	This setup adds undesirable resistance in the ground path [44]
Low input common mode voltage [20]	It may also require the use of an additional wire to the load that could otherwise be omitted [44]
Ground referenced output voltage [20]	Load is lifted from direct ground connection [20]
	High load current caused by a short is not detected [20]


Linear Technology's LTC4151 IC uses high side power sensing with a 12-bit ADC for conversion. The datasheet states that the maximum full scale voltage meaning the maximum voltage drop across the sense resistor is 81.92mV. This translates into the least significant bit of the ADC conversion having a step size of 500 μ V. Before the ADC reads the analog voltage the difference amplifier increases the signal using a gain of 25. Although you could create your own difference amplifier the tolerance on the resistors connected to the amplifier need to be extremely close in value otherwise the output will lose its accuracy quickly. Resistors used in the differential amplifier circuitry must be very well matched to obtain an acceptable common-mode rejection ratio (CMRR): A 0.01% deviation in any resistor value lowers the CMRR to 86dB, a 0.1% deviation lowers it to 66dB, and a 1% deviation lowers it to 46dB [27]. This is considered to be one of the major disadvantages of using the high-side current sense circuitry.

The footprint for a printed circuit board using the sense resistor method is comprised of the sense resistor itself with an integrated circuit to measure the differential voltage and amplify the signal. Physically, the footprint for this is small and there would be no problem with putting this on the PCB. The integrated circuit generally needs power, ground, and output signals as well as optional input capacitors. The price for the resistors is relatively inexpensive as well as the integrated circuit. If we only use this method we would need three sets of sense resistors with integrated circuits. The IC's generally output an analog voltage, analog current, digital signal, or I2C signal which will all work for our application.

With the proper resistors and IC's this method can be very accurate at above 95% which is very acceptable.

Hall Effect Sensors: The last viable option was using a Hall Effect sensor for measuring the current through a wire. This option is generally less invasive as the sensor detects the magnetic field created by the current in the wire passing through it as seen in Figure 3.14 [41] where the wire would go through the opening. With the Hall Effect sensor you have the ability to not break the circuit in order to detect the current nor cause a voltage drop or extra power losses caused by using the sense resistor as described earlier. Some of the common uses for Hall Effect sensors include use in production equipment, home appliances, public appliances, transportation, power, and medical. In these fields they are used to measure current, position, and motion as well as automotive applications, wheel rotation, and electrical motor control. With the Hall Effect sensors it is important to take into consideration their frequency range, cost, DC offset, and external power requirements which can be disadvantageous compared to current sensing using resistors.

“When a current-carrying conductor is placed into a magnetic field, a voltage will be generated perpendicular to both the current and the field; which is known as the Hall Effect” [12]. This is illustrated as a simple diagram in Figure 3.14 [15] where when there is no current and therefore no magnetic field on the hall chip, the output voltage is zero. When a magnetic field is sensed there is a voltage generated due to the change on the sensor. Hall Effect sensors are manufactured as either Open Loop Hall Effect Sensors or Closed Loop Hall Effect Sensors with each having their similarities and differences.



Reprinted with pending permission from Tamura


Open Loop Hall Effect Sensor: The Open Loop Hall Effect sensors use a magnetic field to sense the current in a wire passing through it. The magnetic field is sensed using the Hall Effect Sensor located in a precise air gap in the magnetic core. When a magnetic field is generated due to the current in a wire the field disrupts the uniform current distribution and creates a potential difference across the output. This output would then be amplified by the device itself as a potential difference which is typically a very low voltage. The output of the amplifier would then be read by another device which in our case would be the microcontroller.

Figure 3.15 [40] illustrates an open loop Hall Effect sensor where the primary current flows through the magnetic core. The magnetic field from the wire alters the normal current flow on the Hall Sensor which creates a differential voltage realized by the difference amplifier with gain 'A' resulting in an output voltage.

Features/Benefits:

- Low power consumption
- Voltage output
- Compact packaging size
- Low weight
- No insertion losses

Figure 3.15 - Open Loop Hall Effect Diagram



Reprinted with pending permission from Tamura


Closed Loop Hall Effect Sensor: With the Closed Loop Hall Effect sensor there is a secondary coil wound around the magnetic core. Once the Hall Effect sensor detects the current it amplifies the signal and drives the secondary coil. By driving the secondary coil it creates an opposing magnetic field which in turn makes the flux in the magnetic core equal to zero. This secondary coil is actually used as the output of the sensor. Therefore the output is a current proportional to the aperture current multiplied by the number of turns on the coil. Figure 3.16 [40] is similar to the open loop Hall Effect sensor as seen in

Figure 3.15 but the output of the difference amplifier is connected to the secondary coil around the magnetic core. The output of the secondary coil would be connected to a resistor and then to ground. The voltage output is connected to the high side of the resistor and then to the microcontroller. We can adjust this resistor to scale the output voltage levels for our application.

Features/Benefits:

- Good overall accuracy
- Fast response times
- Low temperature drift
- Excellent linearity
- No insertion losses.

Figure 3.16 - Closed Loop Hall Effect Diagram



Reprinted with pending permission from Tamura

After gathering information on current sensing methods from multiple sources, we have found that there are multiple options commercially available with each having their advantages and disadvantages. For current sensing using current sense resistors we found that the parts are inexpensive, the footprint is small, and the accuracy is very high. This method has the disadvantage of wasted energy with its insertion losses due to the resistor itself, lowering the efficiency of the system. Overall it is a very common and reliable method given that you choose the proper resistor and layout the printed circuit board properly. Current transformers, which need AC current to operate, are needed for some particular applications. They do provide circuit isolation but create insertion losses and are very expensive. This choice was easy to eliminate since it clearly will not work for our all DC application. The next two options both involve the method of using Hall Effect sensors. This method is great for higher current applications as they do not have any insertion

losses as compared to using sense resistors which have high losses at high current. The Hall Effect method also provides us with circuit isolation but does require external power to operate. The open-loop devices have good accuracy but not as great as compared to the close-loop devices. This accuracy is reflected in the cost of the devices as closed-loop is more expensive than open-loop devices. The Hall Effect sensors in general are more expensive to implement than the resistive sensing methods. In the design section we explore the most practical solution for our application.

Table 3.10 [34] from Allegro MicroSystems compares the difference between the different sensors used with some of their characteristics.

Table 3.10 - Current Sense Method Comparison

Comparison of Commonplace, Inexpensive Current-Sensing Techniques							
Widely Used Sensors	Insertion Loss	Circuit Isolation	External Power	Frequency Range	Offset (Zero I)	Accuracy (Est.)*	Rel. Cost
Resistive DC	Yes	None	None	<100 kHz	None	>99%	Lowest
Resistive AC	Yes	None	None	>500 kHz	None	>99%	Low
Hall-Effect Open-Loop	None	Yes	Yes	≥20 kHz †	Yes	90-95%	Med.
Hall-Effect Closed-Loop	None	Yes	Yes	≥150 kHz	None	>95%	High
Current Transformers	Yes (AC)	Yes	None	Constant ‡	None	>95% §	Highest

* (Estimated): accuracy and precision very dependent upon design implementation.
† 20 kHz to 25 kHz represents (typical) usable frequency limit.
‡ Current transformers (usually) designed for limited frequency range.
§ Accuracy very contingent upon component and cost factors.

Reprinted with permission of Allegro MicroSystems

3.2 Microcontroller

The design of our project requires that we be able to constantly monitor battery voltages, light intensity and temperature; processing these various inputs requires some low level computing. To choose the microcontroller that would fit our needs well we had to parse through the feature set of the most common microcontrollers on the market. Among the features most common to microcontrollers, we chose to compare products using clock frequency, core bit resolution, package type, Analog to Digital (A2D) input resolution, number of A2Ds, number of digital Input/Outputs (I/Os), program memory type, supply voltage, external/internal oscillator and operating temperature.

3.2.1 What's Needed

The clock frequency is critical to our project due the fact that a faster rate allows us to monitor vitals closer to real time. However the clock speed of the microcontroller should match the other embedded processors on the board. We also utilized an FPGA. We need to make sure that we don't incur any unintentional bottlenecks. If

we cannot get the speeds to match exactly, they should at least be factor of each other. For example, if the FPGA is clocked at 50 MHz the microcontroller should be at 25 MHz with the FPGA triggering code on every other rising edge on the oscillating frequency. Core bit resolution is critical to the project as it plays a huge role in how accurate our sensory is. We would like to achieve at least 10 bit resolution for our A2D converters as we anticipate some level of noise in the system, thereby giving us 8 bits of true resolution. With this in mind, should cost ever become an issue, we can afford to choose a microcontroller with 8 bits of core resolution.

Package type also bears significant weight as it determines how much real estate on our board is dedicated to signal processing. The ideal situation would involve the package being as small as possible, therefore we would prefer the Quad Flat No leads (QFN) or Small Outline Packages (SOP) packages, Dual In-Line packages have been considered as well, but more as a secondary option as they generally require a larger footprint. It should be noted that if we went with a QFN package, that sockets would be required as we do not bear the capability to solder leadless package. Due to the nature of sockets therefore we need a chip with internal oscillators for core frequency as the inherent inductance cause by the socket's long leads will lead to slower transition times with regards to the oscillator.

Our project specifications require us to be able to monitor two different battery voltages at any given moment along with 4 light sensors. Thus we need at least 6 A2D converters on a given microcontroller. There are also 3 temperature sensors and 1 humidity sensor; there are several options on the market that integrate temperature sensors with humidity sensors, therefore we can possibly cut our required number of inputs in half. We are also using integrated circuits to monitor current draw from our two batteries and shore power. With this in mind we require between 5-7 digital inputs, but as we took the worst case scenario into account, we assumed that temperature and humidity sensors are independent of each other.

A few memory types that we have considered for program storage include EEPROM, EPROM, PROM, RAM and Flash (which is a subset of EEPROM). We would prefer an Electrically Erasable Programmable Read-Only Memory Device (EEPROM) as it proves much easier to work with during our testing phase. Flash memory does seem to work well for our setup as well as it generally works out cheaper than EEPROM. The down side to flash memory comes with its limited program/erase cycles, but seeing as we probably won't ever get close to 100,000 program/erase cycles I doubt this is an issue for us. EPROM memory requires UV light to erase the program stored on the chip but as the EEPROM chips are not too expensive in comparison and can be erased with the click of a button, we didn't consider the EPROM. PROM memory would work great for a final setup but not now as we would need to perform several test runs before approving the program for the final vehicle.

For the operating temperature of the device, we expect the electronics of the boat to function anywhere between 0°C and 70°C. As the final test for the autonomous surface vehicle will be in Virginia Beach, Virginia during the peak of summer, we do not expect to ever get near the extremes of our operating temperature. With a peak summer temperature of 95°F (which is 35°C) we should be

well within temperature bounds for all our on-board electrical components and integrated circuits.

3.2.2 Parts Researched

3.2.2.1 NXP Semiconductors: P89C664HBBD

The P89C664 was designed by Philips Semiconductor (now known as NXP Semiconductors). Its core processing unit is that of their 80C51 microcontroller product line and can be programmed using the 87C51 programming interface. Its core clock rate can reach up to 20MHz with 6 clock cycle per every machine cycle or 33MHz with 12 clock cycles per machine cycle, the conventional standard. The device has 8 digital input/output ports on the board with 8 bits of resolution dedicated to each channel. It boasts 3 16 bit counters with a multi-source 4 priority level interrupt structure and an on-chip oscillator with non-volatile 64KB of flash memory. The P89C664HBBD has an operating temperature of 0°C to 70°C, which is exactly our specified operating temperature. It comes in a Low Profile Quad Flat No-Lead plastic (LQFN) package which is extremely small vertically and doesn't require a large PCB footprint reservation on the motherboard.

There are no dual in-line package options for this chip; however, other options do exist in the form of the Plastic Leaded Chip Carrier (PLCC), which essentially looks like the quad flat pack package but with the minor difference being that the leads have a "J" like appearance. This usually works well for socketed boards. As we will consider using sockets on our board, this particular feature is definitely a plus. Even with its compact nature, this particular chip does not seem to bear any Analog to Digital Converters (ADC) and thus might prove to be unusable in this design project. Especially since analog signal processing plays a large role in this design project.

3.2.2.2 Atmel: ATmega644/ATmega328P

The Atmega644 chip is not really any different than the ATmega328P in terms of the features it presents. The only advantage it bears is the increased programmable flash memory, compared to the ATmega328P. The ATmega644 has literally twice as much memory as the 328P. All other features are common to both chips. They have 8 ports defined as analog to digital converters with 10 bits of resolution. As mentioned above, a couple of bits will be disregarded due to noise or hysteresis, therefore we will only be looking at anywhere from 6 to 8 bits of true resolution. The very fact that this chip provides ADCs is a huge plus for our project in comparison to the P89C664. With 8 channels, we will have as much bandwidth as we need for signal processing and then have some left over for use should the need arise. The core speed of the ATmega644 is at 20 MHz with a total throughput of 20 MIPS. It also boasts a true read-while-write feature that definitely speeds up a lot of time during the actual operation of the chip.

3.2.2.3 STMicro: STM32F103

This particular chip utilizes an amazing clock speed of 60MHz and can achieve 72MHz by using an external crystal oscillator. With an ARM Cortex-M3 core that uses a 32-bit architecture. There is a lot of widespread adoption of this particular branch of microcontrollers therefore, there is quite a bit of literature available for reference. This was made especially for embedded systems and contains a timer dedicated for emergency stop itself. Compared to its fellow processors on the market that bear the ARM cores, it seems to be the best for signal processing on a system with power constraints. It has better interrupt handling while being more efficient in terms of power usage. It has a plethora of communication interfaces supported on the hardware level and several of the communication ports can be remapped to other pins; as all the pins have default locations on the chip itself. According to the datasheet for this part, it uses has 2 I²C ports, 2 SPI ports and 2 USART ports along with 1 USB port. The USB port on this chip can achieve the full USB 2.0 speed of 480Mbps/s. However we will not be using the USB function of this chip. It utilizes a certain instruction set called thumb2 that increases the instruction execution speed by using a reduced the program memory footprint. Using the external clock option, you can achieve the 72MHz clock speed and process 90 MIPS which is better than most embedded processors on the market.

It also has a 7 channel DMA that can transfer data from the peripheral inputs straight into memory or straight to another peripheral. This feature allows data to be moved into memory and be usable without rely on the processing power of the core; each of the 7 channels can be assigned to groups of peripherals at a time. This feature works great in the sense that, some of our sensors already process data and transmit voltage or current values using their pre-programmed communication ports. Using the DMA feature, we can bypass the processor and use the chip as more of an information relay or hub. This frees up the core to analyze other important vitals for our vehicle.

This microprocessor uses a moderate 20-36 mA which is quite respectable, but of course this depends on how many peripherals are attached to it at any given time. This chip also has an abundance of ADCs on board with 12 bit accuracy. It has 2 physical ADCs that can monitor up to 10 channels each. The documentation also states that if we were to utilize the ADCs on board, we will need to connect it to a voltage source between 2.4V and 3.6V. This will not be a problem for us as our voltage sources go all the way up to 24V and we have voltage regulators that can buck the voltage down to our required levels. Though this feature is really needed for this project, the STM32 has a group of interfaces known as the advanced timer circuits which can generate PWM signals with duty ratios of anywhere between zero to 100%.

The interesting thing about the STM32 is that it has 128KB of on board flash memory and 20KB of SRAM memory, the program loaded from the SRAM has the benefit of being processed at the same rate as the core clock, while if the program were loaded from flash, there would be some delay as we would have to wait for some hardware based error. This way if the program could be kept under 20KB, it

could be stored on the flash due to its non-volatile nature and once turn on it can be loaded onto the SRAM.

3.2.2.4 Microchip Technology: DSPIC30F4011

The DSPIC30F4011 is very similar to the ATmega644 in that it has the same processing core speed of 20 MHz however it does use a 16 bit architecture that allows it process twice as much data as the ATmega644 at any given time. The chip can process 30 MIPS at 40 MHz as an option which also works great for our application. It has quite a few communication ports built into it on the hardware level that consist of SPI, UART and I²C. It has five timers that can control 6 pulse width modulated channels with 16 bit accuracy. We probably won't be using this feature however as we have other methods of creating PWM signals; most likely with the use of an FPGA. The DSPIC has 48KB of flash memory and 2KB of volatile SRAM. It uses an operating voltage of 5V and consumes about 132mA of current, which is considerable considering the other options on the market.

3.2.3 Comparison of Microcontrollers

Here is a table comparing the microcontrollers discussed above. It seems that the best option for us is the Atmega644. Should we require more UARTs than the chip can provide, we can always emulate more UARTs using pre-defined libraries by assigning the digital I/O ports to emulate any sort of communication standard we need. The STMicro chip is great with features but most of them could be considered as overkill for our needs, especially the 72 MHz clock speed. The widespread adoption of the Atmel chips allows for multiple sources of information that will allow us to easily implement our specific needs. On another note, either of the chip mentioned in the table below, save for the P89C664HBBD which does not include any ADCs; external ADCs would have to be used if that option were to be used. Should the need arise, we will also use a hardware based dedicated analog to digital converter to provide more inputs. The option to use a dedicated analog to digital converter that's located near the sources of power (in the voltage and current sensing applications) and transmitting one stream of digital data that represents the battery voltages and current draw would be the best way to maintain a high level of accuracy. Opting not to do so would require us to calculate the voltage drop across the traces. This might not seem like a huge problem with low current draw, however as we anticipate 10A in current draw for the motors, even a small resistance in the traces could cause a large enough voltage drop to affect our accuracy.

Table 3.11 - Comparison of all the microcontrollers studied

	P89C664HBB	ATMega644	DSPIC30F4011	STM32F103CBT6
Data Bus Width	8-bit	8-bit	16-bit	32-bit
Clock Speed	20 MHz	20 MHz	40 MHz	72 MHz
Execution Speed	-	20 MIPS	30 MIPS	90 MIPS
Operating Voltage	5V	5 V	5 V	2.4-3.6 V
Current Consumption	64 mA	Not Provided	132 mA	36 mA
ADCs	-	8 Channels (10-bit)	9 Channels (10-bit)	10 Channels (12-bit) (x2)
Communication	UART	USART	UART (x2)	USART (x2)
	I2C	I2C	I2C	I2C
		SPI	SPI	SPI
Timers	16-bit (x3)	8-bit (x2)	16-bit (x5)	16-bit (x4)
		16-bit		
Memory Flash	64 KB	64 KB	48 KB	128 KB
Memory SRAM	2 KB	4 KB	2 KB	20 KB
Price	Not Listed	\$6-9	\$7-8	\$10-\$12

We have chosen to go with an ATmega 328P DIP as it is easy to replace and provides us with the necessary I/O's. We have employed additional external I2C A2D converters to aid in 12bit resolution readings of most of the main sensors. We have utilized the software serial capabilities but have found that software serial with the FPGA causes major conflicts. Therefore, we are now making the FPGA the master and the microcontroller and the A2D converters slave devices.

3.3 Field Programmable Gate Array (FPGA)

3.3.1 Background

We decided to incorporate a field programmable gate array due to its flexible nature. By using an FPGA we can emulate an infinite number of applications using a low cost platform. Should the need ever arise; we could re-create the new device in software on an FPGA. For this project, we are emulating a motor controller that accepts either pulse width modulated signals and 8-bit numbers that can translate to pulse width modulated signals on the output. At any given time both signals would be processed by the FPGA, however, there is a multiplexer (mux) at the end which decides which signal actually leaves the FPGA. The pulse width modulated signal stems from a remote control that is controlled by a person (one of the team members) while the 8 bit number that's later converted to a pulse width modulated signal will originate from the on-board computer. This will be discussed in detail in the "What's Needed" paragraph. Apart from acting as a pulse width modulated generator it will transmit any information that the computer requires.

3.3.2 What's Needed

Our choice in FPGA relied solely on the fact of price and simplicity. Our designs did not require too much complexity therefore an academic version of any given manufacture's FPGA would suffice. We needed the FPGA to be able to create its own pulse width modulated signals from an 8 bit number and mux those generated signals with pulse width modulated signals from a radio controlled remote that we will be controlling. The digitally generated pulse width modulated signals are driven by the on-board computer that will send the FPGA digital hex values anywhere between h0x00 and h0xFF, in this case, h0x80 represents the 1.5ms pulse width for servo controllers that indicates the state of doing nothing. For servos that do not have a reverse option (not used in this project), the 0x80 value will mean half power. The 0x00 and 0xFF represent the other two extremes of the scale. Where 0x00 is full reverse and 0xFF is full forward or for a servo without reverse capability, it goes from powered off to full power.

Another function of our FPGA is to control any on-board indicator LEDs. These include an LED to indicate which signal is being muxed to the outputs, the digitally generated signal or the output from the radio controlled remote, another to indicate if the artificial intelligence is running and another to indicate if the system is in e-stop mode. It should be noted however, that the FPGA will not have direct control over if the emergency stop LED is lit or not, it will simply query the status of the LED and report it back to the computer.


Other than the signal processing mentioned above, the FPGA is the direct connection between the computer and the hardware. When the computer sends a request for the status of a particular element, the FPGA, if the value is at its disposal, will immediately send the information back. If it's not, it will then request the attached microcontroller to provide the information being asked for. As it can be seen the requirements for an FPGA in our design isn't too stringent. Therefore in an effort to save cost, we looked for FPGAs being promoted for educational purposes. The two companies that provide excellent education support are Xilinx and Altera, so we elaborated on the options they provide.

3.3.3 Part's Research

3.3.3.1 Xilinx vs. Altera: Difference in Design

Xilinx's methods of determining its logic capability is to use logic cells which in the Spartan 3E is illustrated in Figure 3.17; it uses two lookup tables (LUT) with three inputs which is quite modest compared to their Virtex family which uses 4 LUTs with 4 inputs and 2 LUTs with 3 inputs. It is difficult to gauge the advantage and disadvantages of logic cells to logic elements (Altera's method). This is currently a hot topic in the commercial world and nobody seems to be able to come up with a real answer, other than synthesize your program on both and then analyze your memory utilization. It seems that Xilinx uses its LUTs for memory as well, while Altera does not. Whether or not this plays a key role all depends on the application

of the design. With this in mind it is a better gauge to use RAM bits to determine how “beefy” a particular FPGA is.



Reprinted with permission from Paul Kallstrom, copyright owner of the design. [35]

3.3.3.2 Xilinx: Spartan 3E XC3S500E

The Spartan 3E uses logic cells as a measure of its logic capacity and has 10476 logic cells at its disposal. It has 1164 Logic Array Blocks and Configurable Array blocks. When it comes to RAM bits, it has 368640 bits and can support up to 158 configurable inputs and outputs. With 500,000 logic gates built in, it definitely stands up from the rest. The input voltage it requires to turn on must be in the range of 1.14V to 1.26V. Its operating temperature goes from 0 °C to 85 °C which sits very well with our given specifications which ranges from 0 °C to 70 °C. It comes in a 208 pin QFP package and costs \$24.90 per chip.

3.3.3.3 Altera: FLEX-10K EPF10K70

The FLEX-10K is Altera's student version of an FPGA and comes with 3744 logic elements, which is Altera's preferred method of determining logic capability. It has 468 Logic and Configurable Array Blocks and 18432 bits of RAM. It has 189 programmable input and output ports and has 118000 logic gates built into it. Its voltage supply must be in the range of 4.75V to 5.25V and is considered a surface mountable part. Like the Spartan 3E, it operates from 0 °C to 85 °C. It comes in a 240 lead QFP package and cost around \$361.00 per chip.

3.3.4 XC3S500E vs. EPF10K70

Table 3.12 (below) summarizes all the features that were mentioned above. It can be seen that just merely on the price difference between the two parts, Xilinx is the clear winner. In almost every category, the Spartan 3E has better specifications expect in the number if input and output pins. It has more Logic and Configurable

Array Blocks, more RAM bits and more logic gates. It uses fewer pins therefore it has a smaller form factor. It requires less voltage to be powered on; therefore it will be more energy efficient.

Table 3.12 - Comparison between the FPGAs considered

	Spartan 3E		FLEX-10K	
	Min	Max	Min	Max
Manufacturer	Xilinx		Altera	
Logic Elements/Cells	10476		3744	
Logic/Config. Array Blocks	1164		468	
RAM Bits	368640		18432	
I/Os	158		189	
Logic Gates	500000		118000	
Voltage Supply	1.14 V	1.26 V	4.75 V	5.25 V
Mounting Type	Surface		Surface	
Operating Temperature	0 °C	85 °C	0 °C	85 °C
Packaging	208-BFQFP		240-RQFP	
Price (for device only)	\$24.90		\$361.00	

The logic cells used in the Spartan 3E by Xilinx is depicted in Figure 3.17. It uses to lookup tables with 3 inputs which is quite modest compared to their Virtex family that use at least 4 LUTs with 4 inputs and 2 LUTs with 3 inputs.

3.4 Communication

The Autonomous Surface Vehicle (ASV) consists of a number of sensors, motors, microcontrollers, a computer, and other devices that need to communicate with each other reliably. It is highly desirable to use a communication system that is both simple and reliable. Any failure in the communication system would result in an ASV that is performing subpar or not performing at all. To make matters worse, the ASV operates in a high humidity environment. Extra care must be taken to ensure that the humidity does not promote oxidation, which would be another possible failure point in the system.

The communications system requirement for the ASV is to establish a communication system encompassing both a wired platform and a wireless platform. Both platforms must be compatible with other Commercial off the Shelf modules (COTS) that are pre-existing on the ASV. In order for the system to work most efficiently it is common practice that the communication device include a clock output unit and a modulator; and for the wired communication device to include a clock extracting unit, a signal extracting unit, and a processing unit. In addition to these standards our ASV communication system must meet all of our additional requirements for the upcoming competition.

The existing communication systems on the ASV consists of an onboard 802.11G wireless transceiver that is part of the onboard computer, and a FUTABA

FASST 7C seven channel R/C Transmitter and Receiver that is used to control the ASV in non-autonomous mode. The need to communicate over a longer distance has led to the addition of another wireless communication platform.

3.4.1 Wireless

Implementing a long range wireless form of communication, to transfer various sensor activities within the ASV, is crucial in gaining the utmost control and understanding of the ASV status. Many considerations must be taken when choosing the right platform of wireless communication to meet our specific needs. The implementation of a wireless protocol provides a way for the sensors to communicate through the microcontrollers to an LCD display both on board and via remote. The wireless communication platform chosen must be capable of maintaining compatibility with the other pre-existing COTS modules on the ASV, have low power consumption, fit within our desired voltage ranges, and satisfy our minimum of 900 feet, given an “open-line-of-sight,” range. With today’s advances in wireless communication a basic understanding between the most prevalent forms (Infrared communication, RF communication, 802.11, Bluetooth, and ZigBee) must first be established, in order to decide which platform will work best for our desired specifications.

3.4.1.1 Comparison of Relevant Technologies

Radio frequency (RF) communication is the most commonly used source of wireless communications. The radio frequency spectrum consists of signals from extremely low frequency to the terahertz frequencies. The RF devices that are being compared in this section typically operate in the L band (around 2 GHz) and the UHF band (300 MHz to 1000 MHz). RF communication modules have been in production for a number of years and have developed to the point that they are extremely reliable and use very little power. A number of factors need to be considered when selecting an RF transceiver: power consumption, range, sensitivity, reliability, and transmission rate, security, price and antenna type to name a few. Most of these factors are interrelated and changing one will affect the other. A balance has to be sought that will meet the criteria of our project.

The infrared communication (IR) is highly dependent on the strength of the LED used for data transmission. The more powerful the LED the stronger and broader the signal, thus increasing the data transmission distance. However, even a very powerful LED will not be sufficient enough to reach 50 feet from source, even with an open line of sight. Another disadvantage with using infrared communications is its susceptibility to interferences from other IR sources (i.e. the sun). For these reasons it is excluded from consideration.

Bluetooth’s wireless communication was designed to eliminate the use of cords. Bluetooth utilizes the master/slave technology associated with wired communication by connecting all devices to a shared radio channel. All devices on this shared channel share the same clock allowing for the devices to be synchronized. Although, this wireless communication protocol has low power

consumption its maximum range is restricted to 300 feet. For our specific range needs of 900 feet this excludes Bluetooth technology from consideration [6].

Based on our specific needs we have narrowed our wireless communications research to RF transceivers. Among the protocols and vendors we decided to look at are: Linx Technologies radio controlled transceivers, 802.11, and Digi international's XBee-Pro RF modules (ZigBee 802.15.4). The Linx Technologies long range, 8 button RF transmitter is capable at operating at frequencies of 418 MHz or 433MHz. This specific wireless technology when paired with the RXLC-434-LR series receiver and Holtek HT648L decoder IC is designed to reach a maximum distance of 1000 ft. This 1000 ft range is based on an open line of sight. Although, this protocol meets our desired range specifications of 900 feet it is frequency sensitive. The Linx protocol only allows for one transmitter to transmit at any given time within the same general air space. Disturbance from another remote operating at the same frequency would interfere with the data transmission and the decoder would not recognize a valid transmission, and thus do nothing [22]. For this reason it has been excluded from consideration.

IEEE 802.11 (b, g, or n) is another RF wireless communication protocol that must be considered. The 802.11 protocol was created to implement a wireless LAN in the 2.4 GHz frequency range. It typically consists of a collection of devices utilizing 802.11 modems that are interconnected via an 802.11 router. This protocol has built-in security and uses spread spectrum signal transmission over numerous frequencies to avoid interference, so in this aspect it meets many of our criteria. The ASV currently has an onboard computer with an 802.11 modem. It is currently being used to communicate with the onboard computer during testing and system programming. 802.11 was not designed as a point-to-point protocol. Implementing it for use with a microprocessor or an FPGA would present a number of challenges. This protocol has an outdoor operating range of approximately 460 feet. Due to its limited range it is inadequate for use in long-range system monitoring. For this reason this protocol is also excluded as a choice.

ZigBee is a data communications protocol that is built on top of the IEEE 802.15.4 standard, designed to address remote monitoring for sensory network applications. This protocol is designed to create ad hoc wireless networks using short range radios which require very small power consumption. In particular ZigBee offers an array of modules that in addition to meeting our specified range of 900 feet also provide "access up to 16 different 5 MHz channels within the 2.4 GHz band. Many of these channels do not overlap those of 802.11 and Wi-Fi technologies," thus greatly limiting interference from other wireless equipment [5]. In addition to these advantages ZigBee is capable of connecting serially to other COTS modules (i.e. microcontrollers) on the ASV and is easy to include in our design. The only disadvantage to this protocol is its slow data transmission in comparison to other wireless communication platforms. However, for our specific design the speed of transmission is still well within the desired range. For these reasons we have chosen to use ZigBee for our wireless communications platform. The particular ZigBee device that we have chosen is the XBee Pro RF module.

3.4.1.2 Comparison of XBee Modes

ZigBee has many wireless modules available. The XBee modules satisfied a majority of our specifications. In order to narrow down which XBee module would be most beneficial to our design we needed to first determine which networking mode offered would most suit our design requirements. The three networking modes, mesh network, point-to-point, and point-to-multipoint, were compared to provide a better understanding of which mode we could optimize.

The mesh networking mode expands the transmission range by frequency hopping from node to node. Frequency hopping allows the system to “self-heal” or readjust its data path if a node fails, thus increasing the networks reliability. In general, this networking method is used by larger systems that need the flexibility within the network to expand, or for modules with intermittent functionality. In a point-to-multipoint network the data transmission no longer frequency hops. Instead this system introduces a coordinator that becomes the ‘central hub’ for communication. All devices within the network connect to the coordinator, who then coordinates data transmission. This method allows for range expansion but not for network expansion. Although, this mode would work for our design it does not have the benefits and simplicity of a point-to-point form. The point-to-point form is the fastest data transmission networking topology. It allows for direct data transmission between two devices, in our case the ASV and the remote. Of the three possible networking types, the point-to-point mode is most advantageous to our specific design [7].

3.4.1.3 ZigBee’s XBee PRO Module

Although ZigBee has a variety of modules available to the open market, the modules that satisfied our requirements were the XBee PRO (radio processor) modules. This specific protocol is based around sending packetized information between devices sharing the same interface, which for our module will use the point-to-point. “By default the XBee/XBee PRO modules are configured to support non-beacon communication,” for this reason the systems operate in a peer-to-peer network topology [7]. The advantage of working in a peer-to-peer network is the elimination of the “master/slave” relationships. The devices within this topology can simultaneously share the position of master or slave.


3.4.1.4 XBee Interface UART

UART, the XBee module has a built in Universal Asynchronous Receiver/Transmitter (UART) interface. The UART controller is an important component in serial communication. “The UART controller takes the parallel output of the computer's system bus and transforms it into an asynchronous serial form [10].” In addition to transferring data from parallel to serial the UART signals other devices on the bus to communicate with each other. A major disadvantage to UART is its inability to receive or transmit signals from the bus directly. Instead this protocol depends on separate devices to convert the logic level signals. These external voltage signals

are commonly provided by the wired communication being used, such as the RS-232 or RS-485.

Data bytes are transmitted through the UART in a sequential bit by bit sequence. These bits are then picked up by another UART at the chosen design destination and reconfigured into their original byte representation. The asynchronous serial form of the UART requires the data for transmission to be in a specific order. Figure 3.18 illustrates the typical sequence of bits for transmission. Transmission is always initiated with a START bit (always a logic 0), followed by 6 to 8 data bits followed by a STOP bit (always a logic 1). The UART communicates using TTL voltages of +5V and 0V, or LVTTTL, depending on specified microcontrollers VCC voltage. In order for serial communication to take place between the two UART controllers the settings for both controllers must be configured identically. These settings include baud rate, parity bit, start bits, and stop bits and data bits and exhibit the same speed for successful data transmission [10]. To simplify the design process and ensure a working and compatible system the microcontroller specified for our design incorporated a UART interface. This allows for an easy connection to the XBee wireless communication protocol.

Figure 3.18 - UART data transmit format: 1 start bit, 8 data bits, 1 parity bit, 1 stop bits.



Reprinted with permission pending from Hurda

3.4.1.5 USART

Typically, a UART controller is connected to another UART controller via a separate wired communication protocol, such as the RS-232 or RS-485. However, many newer microcontrollers utilize a USART controller. For our specific design we have selected a microcontroller with this feature, therefore a comparison between the two controllers has been established. The USART has the added option of communicating both asynchronously or synchronously, in addition to supporting an array of software programmable baud rates. Although this controller has the ability to work in either asynchronous or synchronous mode it is most commonly used in the asynchronous mode. In this mode it has the capability of communicating full

duplex using two signals (transmit/receive), since there is no clock signal. When the USART is chosen to operate in synchronous mode it uses three signal lines for communication, the transmit line, the receive line and the clock line. The most common use of using asynchronous USART is to connect to another wired communication protocol. However, for our design purposes we were able to forego having to utilize a wired communication protocol and connected both USART /UART devices directly together. The pins from the microcontroller were directly tied to the controller pins of the XBee module.

Similar to the data transfer for the UART, the data bytes are transmitted in a sequential bit by bit sequence. Data Transmission is always initiated with a START bit (always a logic 0), followed by 6 to 8 data bits followed by a STOP bit (always a logic 1). The 6 to 8 bits of data are sent Least Significant Byte (LSB) first such that the bit pattern appears backward. One key advantage to connecting the two UART/USART controllers directly is that the data no longer needs to be inverted; as it would if we required the use of a wired communication protocol. The USART has two optional clock modes dependent on the devices desired use. To operate in the asynchronous mode, or as a master in a synchronized mode it uses an internal clock whereas when operating in a synchronized mode as a slave it uses an external clock [10].

3.4.1.6 Configuring XBee Module Parameters

The XBee module offers three modes of operation that define its parameters; these are Transparent mode (AT), Command mode and Application Programming Interface (API). The three command modes address how the information comes out of the XBee's UART. It is the protocol in which the XBee communicates to the user. Initially, the XBee mode is in transparent mode, which is this modules default setting. "By default this mode allows the module to act as a serial cable replacement. All data received from the DIN pin is transmitted, and when RF data is being received, it is sent out on the DOUT pin". The Command mode is where all changes in the settings are made. The command mode is also the most power consuming mode. The settings that can be modified in this mode include the baud rate, and destination address. The Transparent mode is ideally used in a point-to-point topology where you are connecting two devices. For a network consisting of multiple devices the API mode is most often employed. The API mode is a frame based method of data transmission between UARTS. It is the most powerful but also the most complicated mode to use. The advantage of using the API mode is that this mode allows the user to receive data transmission confirmation, and change parameters without entering the command mode. A side advantage to this mode is that by not having to enter into the Command mode you conserve more power [5].

3.4.1.7 Cost Analysis

It has been determined that purchasing the XBee-PRO Starter Kit would be most cost efficient. The XBee-PRO starter kit, from the Digi online store, includes:

- (2) XBee-PRO OEM RF Modules with integrated whip antenna.
- (1) RS-232 development board
- (1) RS-232 cable
- (1) USB development board
- (1) USB cable
- (1) 9V 1A power adapter
- (1) 9V battery clip
- (1) Serial loopback adapter
- (1) Quick Start Guide
- (1) CD (Testing and configuration software and documentation)
- (2) Antenna clips with pins

Currently, the robotics club has a previously used XBee development kit, minus the modules that satisfy our range requirements. The working condition of this equipment is unknown. We were contemplating if it would be more cost effective to purchase another kit, or to buy two XBee modules and buy what we need as needed. Table 3.13 and Table 3.14 displays a price comparison to determine the financial benefits of either method. The development kit listed above retails for about \$180.00. Whereas, the same kit below would cost about \$150.00 (including shipping estimates). Therefore, it would be more financially conservative to buy the parts we need as needed. For this reason we have opted to utilize the existing XBee module.

Table 3.13 - XBee kit individually priced for comparison

Unit	Components	Distributor	Cost
2	XBee Modules (with wire antenna)	Trossen Robotics	\$76.00
1	RS-232 development board	AWC	\$18.00
1	RS-232 cable	Office Depot	\$10.00
1	USB development board	Ebay	\$20.00
1	9V 1A power adapter	Radio Shack	\$5.00
1	9V battery clip	Radio Shack	\$3.00
1	Serial loopback adapter	Ebay	\$10.00

Table 3.14 - Price comparison

	Distributor	Cost
XBee-PRO starter kit	Digi	\$180.00
Table 3.13 Total	Mix	+/- \$150.00

3.4.2 Wired

A goal of the ASV group was to establish a system capable of communicating with other pre-existing COTS modules on the ASV, while still maintaining the capability of incorporating a compatible wired platform. Wired communication refers to the “transmission of data over a wire-based communication technology.” With today’s advances in wired communication a basic understanding between the most prevalent forms (I2C, RS-232, and RS-485) had to first be established, in order to decide which platform would work best for our desired specifications. The wired

platform chosen dictates the telecommunications within the network. “This includes the voltage levels to be used, what connectors are to be used, what pins on those connectors are to be used for each function, and also recommends maximum distances over which this technology can be reliably used[33].” In addition to determining which form of technology would be applicable to our design, specific consideration was made with regards to the devices already on the ASV and how to create a method of communication that will work together. This required the use of one or more forms of technology combined to reach our desired specifications.

3.4.2.1 Synchronous or Asynchronous

There are two modes of wired communication and they are synchronous and asynchronous. Synchronous communication relies on the sender and receiver to be in sync with a shared clock. This allows for the receiver to know when to read or send data. This form of communication normally allows for a higher data rate of transmission.

Asynchronous Communication does not rely on a clock to keep the two devices in sync. Instead the data is sent with designated STOP and START bits attached to each byte. Each form of communication has its advantages and disadvantages and could both be equally engaged to create a vigorous wired communication platform for our design.

3.4.2.2 Comparison of Relevant Technologies (I2C, RS-232, and RS-485)

I2C (Synchronous communication), Inter-Integrated Circuit Bus (I2C) is a wired communication protocol that allows for connection to subsystem peripherals. This specific protocol allows for synchronous serial communication with other master/slave I2C peripherals, sharing the same interface. Each device on the I2C bus is assigned a unique address whether it is a microcontroller, LED driver, or a FPGA board. These peripherals can then operate as either a transmitter or receiver, depending on the function of the device. The specific design of our network required our microcontrollers to communicate with our A2D's. For the remote, the I2C bus would allow the A2D's to act only as a receiver, while allowing the microcontroller to act as both transmitter and receiver (refer to Figure 3.19). In addition to receiving and or transmitting data, each peripheral can assume the position of master/slave. Using the master/slave technology gives the I2C bus the additional benefit of connecting one master with up to device assigned slaves. The master initiates data transfer on the bus and creates the clock signal. The slaves then receive the clock signal and address from the master and complete the instruction given to them. The slaves within this protocol do not communicate amongst themselves; all communication is granted by the master.

I2C is composed of two bi-directional serial bus lines, a Serial Data Line (SDL) and a Serial Clock Line (SCL), which are used to carry information. The SDA and SCL are connected to a positive voltage supply via a pull-up resistor. When the bus is free, both lines are HIGH. The output stages of devices connected to the bus must have an open-drain or open-collector to perform the wired-AND function. The figures


below depict how these two resistors are used to pull up the bus lines, and displays how the master/slave configuration will be used for both the main portion and remote portion of the bus [1]. The I2C has the added benefit of not being limited to a set voltage. This allows for multiple device connections encompassing different voltage characteristics. To account for these fluctuations the logic levels are based off of design specific VDD value(s). Equation 3.3 is used to determine the pull-up resistors values for the I2C bus.

- Logic level LOW ('0') = V_{IL} is $0.3V_{DD}$
- Logic level HIGH ('1') = V_{IH} is $0.7V_{DD}$

Equation 3.3 - Pull-up resistor equation for I2C bus

$$R_p < \frac{T_{rise}}{2} * C_{bus}$$

Figure 3.19 - I2C Master/Slave configuration




Multi-Master Mode: In addition to the I2C bus utilizing master/slave mode it has the added benefit of allowing multiple devices within the network to act as masters. This multi-master mode includes collision detection and arbitration to prevent data loss if two or more masters simultaneously initiate data transfer. This feature of the I2C bus is especially advantageous to our main system design. It allows our microcontroller to simultaneously take the master role in our network. In order for us to encompass this mode into our design special attention was given to selecting the right devices for our specific network. All devices designed to carry the master role within our network were chosen having multi-master capabilities. When the I2C bus is configured to work in multi-master mode additional attention is provided through the I2C bus when two masters attempt to initiate a data transfer at the same time. In order to prevent bus collisions and miscommunication an arbitration procedure is implemented. The arbitration process relies on the wired-AND connection of all I2C interfaces to the I2C bus [1]. When multiple masters initiate data transfer simultaneously the master role is given to the device that first produces a 'one' when

the other device produces a 'zero'. During arbitration the clock signal become a synchronized combination of the clocks participating in the arbitration process.

Data Transfer: The data communications on the I2C bus is initiated with a START (S) and terminated with a STOP (P). A START condition is defined with "a HIGH to LOW transition on the SDA line, while SCL is HIGH; whereas, a STOP condition is defined with "a LOW to HIGH transition on the SDA line, while SCL is HIGH. The Most Significant Bit (MSB) is the first bit in the data transmission for the I2C protocol. Although the number of bytes that can be transmitted per transfer is unrestricted every byte put on the SDA line must be 8 bits long. In addition to the aforementioned requirements each byte has to be followed by an Acknowledge bit (ACK). The standard data characteristics can be seen in Figure 3.20 [1].


Figure 3.20 - I2C Data transfer configuration.



Reprinted with permission from ARC Technologies

RS-232 (Asynchronous Communication), the Recommended Standard RS-232 is a standard asynchronous, two wire, full duplex communication protocol. It allows for communication between devices using serial ports. The specific serial ports are defined as being either the Data Terminal Equipment (DTE) or the Data Communication Equipment (DCE). The RS-232 protocol was taken over by the Electronic Industries Alliance. Therefore, all RS devices are currently replaced with EIA. However, for the purpose of this paper they will be referred to as RS-232 and RS-485. Typically, communication between devices falls into one of two categories, single ended or differential. This protocol falls into the single ended category which allows for 1 driver and 1 receiver. As with all wired communications, cable considerations must be made. For the RS-232 the wiring distances are restricted to 200 hundred feet for asynchronous communications. For our specific needs this was not a concern because our length of cable runs is much less than this maximum value. The voltage levels associated with the data transmission signals are used to indicate various states for this protocol (refer to Figure 3.21). A voltage level in the range of +3 to +12 volts represents an "ON" state (MARK) condition, while a voltage level falling in the range of -3 to -12 volts indicates an "OFF" state (SPACE); this assumes a common ground between the DTE and DCE [13].

Figure 3.21 - RS-232 Data characteristics.



Reprinted with permission pending from Extreme Electronics

RS-485 (Asynchronous communication), the RS-485 is a standard two-wire communication protocol based on the RS-232. This particular protocol allows for bi-directional communication, using half duplex, over twisted pairs. Bi-directional refers to the method in which the bus determines its ground value by comparing the voltage difference between the SIG+ line and the SIG- line. This also reduces the amount of noise. A disadvantage of the RS-485 is that each interface connected to the RS-485 is required to have 2 conductors, in order to transmit data [1].

As with the RS-232, the RS-485 is recognized by an array of serial devices including FPGA boards, and microcontrollers. The interconnections between these serial devices are made using a crossover connection of the transmitted data line and the received data line, both sharing a common ground. The RS-232 allowed for communication between two devices on a network. Whereas, the RS-485 is designed to be a multi-point network capable of connecting communication between more than two devices. Due to the nature of asynchronous communication the devices communicating do not share a common clock, and thus each device must be configured to a specific baud rate. The true advantage of using RS-485 is most notably seen in larger networks where communications must occur over further distances and at higher data rates. The effects of "ground shifts and induced noise signals can be nullified" using this protocol [13]. In general, electronic telecommunications between devices fall into two categories, single ended or differential. The RS-485 protocol falls into the differential category, allowing for 32 drivers and 32 receivers.

The RS-485 allows for two different configuration arrangements, each encompassing its own advantages and disadvantages. The 2 configurations are "2 wire" and "4 wire." The 2 wire configuration uses the twisted pair to connect directly from one device to another in a half duplex method. This method produces less cable clutter but induces a delay at the end of data transmission. The 4 wire configuration is set up to use 1 twisted pair to connect the master transmitter to the slave receivers, and a second twisted pair to connect the slave transmitters to the master receiver. The 4 wire configuration allows for full duplex communication but utilizes the master/slave interdependencies. The main advantage to this configuration is the lack of time delay induced by using the 2 wire set up [13].

Table 3.15 - RS-232 & RS-485 Comparison summary

Characteristic	RS-232	RS-485
Differential	No	Yes
Max number of drivers	1	32
Max number of receivers	1	32
Modes of operation	Half-duplex Full-duplex	Half-duplex
Network topology	Point-to-point	Multi-point
Max distance (acc. standard)	15m	1200m
Max speed at 12m	20kbs	35kbs
Max speed at 1200m	1kbs	100kbs
Max slew rate	30 V/ μ s	n/a
Receiver input resistance	3.7k Ω	2.12k Ω
Driver load impedance	3.7k Ω	53k Ω
Receiver input sensitivity	+/-3v	+/-2000mv
Receiver input range	+/-15v	-7..12v
Max driver output voltage	+/-25v	-7..12v
Max driver output voltage (with load)	+/-5v	+/-1.5v

Reprinted with permission pending from IDC Technologies


3.4.2.3 Wired Communications Choice

For the wired communications platform, we have chosen to employ both the I2C and RS-232 protocol. The I2C interconnect our microcontroller to our A2D's and the RS-232 protocol allowed for communication from our microcontroller to both our LCD displays and our FPGA. All devices connecting to the I2C bus have been chosen to satisfy the base requirement of having an I2C interface. In addition the choice of our microcontroller has allowed us to eliminate the need for an RS-232 connection. The microcontroller selected offers multiple USART ports, which can be tied directly to the UART of the XBee module.

3.4.3 Summary of Communications Platform

A summary of the communications platform is illustrated in Figure 3.22. As can be seen the system was divided between the ASV electronics case and the remote. The remote consists of a microcontroller with built-in UART, an XBee Pro module and an LCD display. The ASV electronics case contains a built-in computer, the FPGA, the microcontroller, an XBee, an LCD display and numerous sensors. The XBee module is used to communicate between the ASV and the remote. UART is used to communicate between the XBee modules and microcontrollers. The microcontroller communicates with the LCD displays and the FPGA using the RS-232 protocol. The I2C protocol is then used to connect our A2D's with our microcontroller.

Figure 3.22 - Block diagram of wired communication platform,



3.5 Sensors

Sensors have been included into our design to provide various ASV feedback. The AUVSI rules dictate that the ASV operates autonomously. To accomplish this a number of sensors were used to determine the position of the ASV, its orientation, ambient light levels, temperature, power consumption and speed of the thrusters. There are also two cameras used for visual detection. Most of the sensors and both cameras were previously incorporated into the ASV. The group felt it was necessary to add temperature, humidity, and light sensors for increased reliability.

3.5.1 Temperature / Humidity Sensors

The monitoring and supervision of both temperatures on the ASV is crucial in maintaining the longevity and accuracy of the electrical design enclosed. The adverse effects of humidity and temperature, including current leakage, capacitor capacitance changes and connector degradation, give rise to the importance of monitoring these values and protecting the electrical circuitry from these effects. In order to avoid such adverse effects on-board the ASV, the robotics club has previously installed a fan to the electrical house. The fan currently operates at its full potential throughout the competitions. Realizing that this is not the most power conservative technique we have employed a method that will regulate the power of the fan based off the temperature/humidity sensor readings gathered. By installing temperature and humidity sensors to the ASV it has provided a more robust ASV capable of long term reliability, and greater power conservation. In order to achieve the most optimal readings the temperature sensors needed to satisfy the specific requirements for their location. We have provided temperature sensing for two different electrical boxes within the ASV, the MAIN box and the MOTOR box

The first box we researched is our MAIN box. This box contains all of the electrical circuitry for the ASV. For the MAIN box we feel it would be more advantageous to implement a COTS product into our design. To determine which

COTS product would be most beneficial to our design various technologies are compared. These technologies include temperature sensors capable of sensing both temperature and humidity, and independently sensing temperature and or humidity. The second box is our MOTOR box. This box as the name indicates, houses the ASV motors. The specific motors selected for the ASV require water cooling thus requiring the need of a temperature sensor that is water resistant. The sensors researched for the MOTOR box include thermistors, thermocouples, and a compatible COTS product.

3.5.1.1 Product Comparison

There are many advantages of using COTS products. For the MAIN electrical box we have determined that a COTS product would offer us the ability to not only measure temperature, but to measure humidity and possibly the dew point within our electrical house(s). The advantage of using a COTS product resides in the products ability to plug and play. These products reduce the amount of hardware needed on our boards, thus reducing our margin of error associated with adding additional components. The data obtained could then be used to monitor and control the fan to the electrical house(s). The manipulation of fan power established a more power efficient design. The sensors researched for the MAIN box include the HYT271, SHT1x, SHT11, TMP100, and Maxim's DS18S20.

The HYT271 is an all in one humidity and temperature sensor. The values are processed and displayed through the I2C interface. This specific protocol measures humidity from 0-100% RH with an overall accuracy of $\pm 2.8\%$ RH. The temperature/humidity sensor operates within the voltage range of 2.7-5.5 V, which meets are supply of 5 V. Our design criteria include placing 2 temperature/humidity sensors on different boards. The sensors were placed on opposite corners of the PCB to establish a more accurate temperature reading by averaging these values.

Sensirion's SHT1x is an all in one, surface mounted humidity and temperature sensor. This particular sensor integrates the two sensor elements with signal processing to provide a digital output. A capacitive sensor element is used for measuring relative humidity while the temperature is measured by a band-gap sensor. Both the temperature and humidity sensor are coupled to a 14 bit analog to digital convertor and a serial interface circuit. The two wire serial interface (I2C) and internal voltage regulator provides for quick integration and easy integration into the design of the ASV. In addition to being compatible with our design it has low power consumption. The only disadvantage of this device is the extra precautions needed when handling the device, and ensuring adequate ventilation for the device when enclosed.

Sensirion's SHT11, in addition to reading temperature and humidity values this protocol reads the dew point. The dew point is the temperature at which the surrounding humid air must be cooled in order for water vapor to condense into water. This condensed water vapor is known as dew. Knowing the dew point within the electrical house has its advantages but is not necessarily a feature we need to have. This protocol provides results with relative humidity accuracy of $\pm 3\%$ RH, and a temperature accuracy of $\pm 0.4^{\circ}\text{C}$ at 25°C . Although, the features of this

protocol initially seemed to be exactly what we were looking for, after further research it was discovered that this protocol does not have a true I2C interface; but is I2C compatible. Each of these devices is assigned the same address and would be seen by the bus master as one device. This immediately removes the protocol as an option.


The TMP100 is an I2C temperature sensor. Unlike the previously discussed sensors this one does not have the capability of reading both temperature and humidity, but only temperature. However, with its many advantages we feel that it would be the most beneficial, of all the sensors researched. This specific protocol has a 0.625°C with an accuracy of 2°C. In addition to these features it works on our available voltage supply of 5V, and is the most power conservative. The TMP100 has the added benefit of allowing up to 6 TMP100 sensors to be attached to any one I2Cbus. It also satisfied our minimum requirement of having at least two requirements.

Maxim's DS18S20 is the temperature sensor we opted to utilize. This one wire temperature sensor has a unique 64 bit code that allows for multiple devices to be connected to the same microcontroller. It also features an operational range of -55°C to 125°C, works within our desired voltage range. Researching a temperature sensor that would work efficiently and accurately, within the MOTOR box, given the location, narrowed the possible options greatly. With the MOTOR box having water enclosed it immediately eliminated any I2C device as a possibility. We instead researched the possibility of waterproofing a COTS product (such as the LM353), and compared the advantage of this option versus using a thermistor or a thermocouple. Thermistors use temperature to control that devices electrical resistance. They come in two standard types, the Negative Thermal Coefficient (NTC) and the Positive Thermal Coefficient (PTC). The main difference between the two types of thermistors is how they resist changes in temperature. The NTC thermistor is inversely proportional to temperature, whereas the PTC is directly proportional to temperature. The key difference between the two types of thermistors is in their specific design advantage. The NTC thermistor has a distinct design advantage that could be useful in our fan control; the resistance of the NTC thermistors varies gradually with temperature. This has the added benefit of providing circuit protection from power surges often associated with initial start up conditions. The PTC thermistor has the design advantage of acting like a switch, unlike the NTC that varies gradually with temperature. The switching capability of the PTC would be most advantageous to circuits "where equipment can be damaged by easily definable events" [16]. Honeywell Sensing and Control offers an NTC thermistor (480-3161-ND) that satisfies all of our basic temperature requirements. This specific protocol has a 3kΩ resistance, a tolerance of +/- 0.2°C, and operates within our electrical house temperature range. This protocol has an operating temperature range of -60 °C to 150 °C. It is small and is power conservative.

Thermocouples have considerable advantages and disadvantages that must be taken into consideration when including them into a design. They are essential a twisted pair, with the twisted pair composed of 2 different metals. The soldered tip of the two metals is placed in the region of temporal interest. The thermocouple's voltage drop occurs along the temperature gradient down the length of the two

dissimilar metals (refer to Figure 3.23) [29]. The open ends of the thermocouple are attached to a copper plate; where the voltage difference between the two wires can be obtained from the absolute temperature junction. Microchip's AN684 thermocouple has many features that could be useful to our design requirements; it has a fast-response time, requires no external voltage or current, and is enclosed within a corrosion resistant sheath. In addition, the AN684 probe could be easily mounted to our MOTOR box via a small drill hole. Once in place the hole could be sealed with an epoxy to ensure a water tight seal. The disadvantage of using a thermocouple is that it typically produces a voltage that range in the milli to nano volt range, this voltage is repeatable but not linear. To overcome this disadvantage both the hardware and software must reflect the necessary changes that would allow for its use in our design. With the voltage level produced by the thermocouple being so low the voltage must be amplified, at the absolute temperature junction, to compensate for the voltage differences between the thermocouple and the A/D convertor. In addition to a voltage amplifier, analog gain stages will also need to be included in the design algorithms [33]. With the additional circuit components and need of extensive algorithms to decipher the voltage to temperature scale our senior design group has opted not to use this method of temperature reading.

Figure 3.23 - Conditioning signal path



Reprinted with permission pending from Microchip

After researching the various methods we found it to be much simpler to incorporate Maxim's DS18S20 into this box as well.

3.5.1.2 Cost Analysis

The cost for the various temperature/humidity sensors was found to be comparable within their own technology. For an overall summary of product comparison refer to Table 3.16.

Table 3.16 - Humidity/Temperature sensor cost comparison

Product	Manufacturer	Distributor	Unit Size	Cost
480-3161-ND	Honeywell Sensing and Control	DigiKey	1	\$3.60
SHT1x	DF Robot	Robot Shop	1	\$24.00
HYT271	-	Servoflo	1	\$24.00
SHT11	DF Robot	Newark	1	\$25.19
TMP100	TI	TI	1	-
Transistors	Universal	EBay	10	\$2.00

3.5.1.3 Conclusion

After researching the various options available in temperature sensing we have determined a COTS product for the MAIN box is most advantageous to our design needs. The DS18S20 is used in the both the MAIN box and the MOTOR box. This particular sensor met all of our design needs and allows for possible additions.

3.5.2 Light Sensor

In previous competitions the ASV was required to locate a colored buoy and navigate around this object. However, the amount of ambient light has been determined to play an important role in color identification. If there is less light the color appears darker than if there was a significant amount of light; in which the color would take on a lighter shade. To avoid the possibility of misreading a color we would have implemented a method in which the true color can be properly established. We are considering the use of photo-resistors to determine light intensity or purchasing a COTS ambient light sensor. The first method is cheaper for the photo resistor, but requires separate circuitry for voltage regulation, a circuit for voltage detection based on the resistive photo couple. This can be accomplished using a voltage divider circuit with a stable voltage supply. An analog to digital converter and circuitry to implement the I2C protocol would have to be included using this method.

3.5.2.1 Comparison of Relevant Technologies


A photo-resistor is a light-dependent resistor (LDR) that covers the spectral sensitivity similar to that of the human eye. The amount of ambient light available to the photo-resistor affects the photo-resistor's resistance. The basic composition of a photo-resistor is Cadmium Sulfide (CdS). Under normal situations the photo-resistor acts as an insulator. When the photo-resistor is exposed to light, and the light provides enough energy to move the electrons through it, it produces free charge carriers (aka acts like a conductor). In return these free charge carriers produce an electrical resistance to these carriers. This resistance is inversely proportional to the

illumination intensity. Therefore, if the photo-resistor is exposed to more light, less resistance will be found than if the photo-resistor was exposed to dark light. As the photo-resistor's resistance changes with the amount of light exposure, so does the voltage. The resistance increases the voltage decreases, and as the resistance decreases the voltage increases. It is this change in voltage that can be used to determine the amount of light effecting the perception of an objects "true" color. With regards to our specific design needs the light intensity information obtained could be used to employ any necessary navigational decisions. The ASV has been equipped with 4 photo-resistors, one in each of the four navigational directions. This allows for shadow detection when the ambient lighting isn't ideal, and identifies the direction of the strongest sunlight. During the time frame when the ASV will be object seeking, the ASV will use the photo-resistor to indicate adequate light intensity.

In addition to photo-resistors there are available on the market numerous color/light intensity sensors. To determine if a COTS product would be more beneficial to our design different color/light sensors were reviewed, and of those explored two in particular reached a point of serious consideration. The first light sensor that showed promise was the ADJD-S371-Sparkfun Color Light Sensor Evaluation Board. This 2 wire serial light sensor allows for direct communication to the microcontroller, and offers an illumination range from 100 to 100,000 Lux. The evaluation board comes with all the required additional circuitry reducing installation time set. The big disadvantage to this sensor was its adverse side effects to temperature. In order for this sensor to work efficiently it is not to be exposed to temperatures in excess of 86°F. For our specific design this would be unachievable. The second light sensor researched was the NOA1302, by ON Semiconductors. This particular Ambient Light Sensor (ALS) uses the I2C interface (which would fit nicely into our design). The sensor is intended to interpret ambient light in a method similar to the way the human eye perceives light. The light sensor achieves this by acting as a band pass filter on the incident wave front of incoming photons. The filter only allows the passing of photons in the visible spectrum. In doing so the NOA1302 is able to detect illumination ranges from 0 (full moonlight) to 100,000 (direct sunlight) Lux.

The ambient light signal which is detected by the photo diode is converted to a digital signal using a variable slope integrating Analog-to-Digital Convertor (ADC) with a resolution of 16 bits, unsigned. This is further explained in Figure 3.24. Unlike the Sparks color sensor this ALS is not temperature sensitive and in addition to the above mentioned qualities it also adheres to our voltage supply range, and has very low power consumption. The sensor could be easily mounted to the ASV and would only require waterproofing from the 2 wire run to the microcontroller, the addition of a pull-up resistor, and a small amount of programming to allow the I2C bus to designate the device a Slave.

Figure 3.24 - Block diagram



Reprinted with permission pending from On Semiconductors

For our purposes we selected to utilize the 4 photo resistors into our design. The photo resistors were a cost effect means of accomplishing our goals.

3.5.2.2 Cost Analysis and Selection

For an overall summary of product comparison refer to Table 3.17. Based on the above criteria we have chosen to use the ON semiconductor NOA1302. The SparkFun light sensor would have been a good choice if it was not for the operating temperature range limitation.

Table 3.17 - Light Sensor Cost Comparison

Product	Manufacturer	Unit Size	Cost
Photo resistors (G14025)	Electronic Goldmine	1(bag)	\$3.00
SparkFun	Avago Technologies	1	\$9.95
NOA1302	ON Semiconductors	1	\$1.37

3.5.2.3 Light Intensity Investigation

An investigation of the light intensity was performed prior to programming. Currently there are two cameras mounted on the ASV. These cameras are used for object detection and object recognition. It has been determined that recognizing the object will be simplified if the ambient intensity of the light is known. A correlation will have to be determined by the Software team between ambient light levels, and color recognition used by the onboard computer. In previous competitions the ASV was required to identify an object of a certain color and navigate around this object. Shadows from this object can complicate the detection. If the ASV approaches an object from the sun side the registered color will be different than if the ASV approaches an object from the shadow side. With the aid of light sensors an algorithm encompassing the values obtained from the GPS, compass and light

sensors can be established to determine if the color being detected is in shadow or full sunlight.

To determine the correlation, measurements of the light levels throughout the day were taken. When the measurements were being taken the photo sensor assembly was rotated incrementally over a 90° arc to determine the difference in illumination based on a full sun, partial sun, and full shadow configuration. We believed it would be sufficient to take measurements once an hour over an eight hour day. We also discussed completing the measurements twice: once on a sunny day and once on a cloudy day. This allows a comparison of the illumination levels in the two extremes. This gives us an idea of how a color changes based on time of day and direction of measurement.

What complicates matters further is the fact that the measurements were being taken in the winter in Florida, and the competition will be during the summer in Virginia. To compensate for this we will use data obtained from the National Renewable Energy Laboratory (NREL). NREL is a government agency which belongs to the US Department of Energy. The agency has a project called PVWatts that was created to assist in the placement of solar panels. Its purpose is to allow designers of solar systems to accurately gauge the production of electricity, based on standard solar panel configurations. NREL has placed solar panels in every city and county throughout the United States. They employ a 40km grid resolution, to measure average solar intensity throughout the year. Using this data we can extrapolate the solar intensity in Virginia based on measurements taken in Florida. We theorize that the variations in levels throughout the day should be similar in both locations. To account for differences in latitude, an algorithm will have to be established and programmed into the onboard computer. The difference in latitude will create shadows of different lengths and will have to be taken into account. Based on GPS position of the ASV, the object of interest, and compass measurement, the orientation of the ASV with respect to this object can be determined. Dependent on the time of day, the latitude and the orientation of the ASV with respect to the object, a computation can be made to determine whether the camera is viewing the buoy in shadow or direct sunlight. Previous measurements of sunlight with respect to time of day will assist in the determination of illumination and color. The information in subsection 3.5.2.3 is based on research only and has not been implemented.

3.6 Dynamic Fan Control

The need to control our fan speed is primarily driven by our need to reduce our power consumption as much as possible. In previous designs of the vehicle, fan speed was set to run at full blast regardless of the temperature within the system. This induces a significant current draw on the system and thus is a location in which we can definitely cut back on power usage. There are several methods of controlling fan speed. The current fan being used is a high power and high airflow fan that can take up to 20V at a given time with a max current draw near 2A. This fan operates much like a DC motor and thus can be controlled by a regular motor controller. Another option to consider is to use a variable output voltage regulator in which the


output is generally controlled by a potentiometer. In our case, it could be a digitally controlled potentiometer (DCP) controlled via a microcontroller.

3.6.1 Option 1: Cascading Regulators

The digitally controlled potentiometers generally have several types of interfaces to control their resistance; some involve actual UARTs, push button switches and even I²C in some cases. The best option that makes the most sense is basically the digitally controlled potentiometer that function via the push buttons as the simpler the design the easier it is to debug problems. Although for the sake of research we will discuss all the options concerning how to deliver appropriate voltages to the fan.

The first option is to utilize one of the 12V regulators on board to power a 30V output boost regulator which then drives a variable output buck regulator. The output of the buck regulator is determined by a digitally controlled potentiometer that is controlled via the microcontroller. In this case, the microcontroller gets feedback from a temperature sensor on board (most likely a thermistor) which then determines the digitally controlled potentiometer's position. This option is definitely viable but not completely energy efficient as it involves cascading two voltage regulators one after another. Under this circumstance, the efficiency of the system is defined as the product of the two individual regulator's efficiencies; the product of the efficiencies will always result in a much lower efficiency rating, as illustrated in Figure 3.25.


Figure 3.25 - Setup of the first scenario with the efficiency for a cascade setup



3.6.2 Option 2: Adjustable Voltage Regulator


The next option to consider is to use a voltage regulator with adjustable output voltage; the illustration in Figure 3.26 below illustrates this operation by using National's LP2915 MicroPower Series Voltage Regulator and a DS1809 which is a digitally controlled potentiometer from Maxim IC.

Figure 3.26 - Basic setup of an adjustable voltage regulator



For a better understanding of how this setup actually works, Figure 3.26 shows the general setup for an adjustable voltage regulator to contrast the setup on Figure 3.27 [24]. The circuit shown in Figure 3.27 can provide up to 1A of continuous current draw.

Figure 3.27 - A more specific version of the adjustable voltage regulator



Copyright Maxim Integrated Products (<http://www.maxim-ic.com>). Used by Permission.

3.6.3 Option 3: Motor Controller

Another and more practical option is to use a motor controller itself to control the fan. Due to its nature of behaving exactly like a DC motor, it should be able to be controlled via a motor controller. This is essentially a motor driver coupled with an H-bridge that allows the high current motor drive. However this option won't seem practical as it would mean that this system is power along with the motors, thus if "E-Stop" was ever triggered, it would turn off the power to our fans.


3.6.4 Option 4: Fan Controller IC (PWM Based)

Micrel, a company based out of San Jose, California, makes a few fan controller integrated circuits that automatically generates a pulse width modulated signal that turns a FET on or off automatically based on a thermistor. The thermistor's voltage value generally has value in the nanovolt range therefore it requires a bit more circuitry to assess its value via an analog to digital converter. This setup for the MIC 502 is beneficial because it isolates the power for the fan itself, the control circuitry by itself is being run of 5V while the fan runs on its own voltage.

This particular setup is quite convenient due to the fact that it has several indicative measures built into it. There's an over-temperature signal that can get set if the temperature crosses a user pre-defined limit. In the example below the frequency of the pulse width modulated signal is adjusted based on the capacitive value of C_F . Equation 3.4 highlights the relationship between the capacitor and the frequency.

Equation 3.4 - Equation for relationship between capacitance and frequency

$$C = \frac{3}{f}$$



3.6.5 Option 5: FET driven Fan

Having a dedicated circuit that controls the fan does not allow us much flexibility in how the fan's speed is varied across the temperature spectrum. Therefore it would greatly benefit our design if our microcontroller or field programmable gate array (FPGA) could control the fan. This can be achieved by connecting one of the outputs of the microcontroller or FPGA to a FET driver which then controls a FET. The on to off ratio of the DC power to the fan can thus be controlled by monitoring the thermistor and adjusting the fan speed based on the efficiency of the entire system. In this setup we would have to establish a baseline operating temperature in which the system operates efficiently. The requirement for having a system deemed "efficient" is when the temperature at which the entire system can achieve 80% to 85% efficiency. Any percentage over 85% is obviously considered great but we don't foresee this as being a reality. Thus in reality the fan speed is being altered primarily on the efficiency of the system and then basing those results over a temperature range.

The voltage being supplied to the fan stems from board power itself. This is unregulated power that is fed to the fan. The regulation of the fan speed is determined by making sure that regardless of what the input voltage to the fan from board power is, the fan speed will remain constant. This is monitored by using the voltage sensors strategically placed throughout the board to monitor board power itself. By figuring out what voltage the board power is really at, the microcontroller can adjust the duty cycle appropriately.

The voltage conversion in this case is a step down DC to DC conversion and hence this type of configuration however can only act as a buck converter, and in turn only produce voltages lower than board power itself. This might pose somewhat of a challenge as the fan speed is now entirely dependent of the voltage of the batteries. In this circumstance the voltage for board power can range all the way up to 26V and down to 22V. Thus a 100% fan speed can vary depending on the runtime of the system.

3.7 Displays

Many times throughout this project we have mentioned safety, efficiency, and low power consumption. We have tried to lower the power consumption as much as possible, at the same time increasing the efficiency of our system. To be able to monitor the currents and voltages in our system as well as the inner temperature of the box where all the circuits and computer will be enclosed, we have decided to use displays. We will have two displays, one on the box and another remote display. These displays allow monitoring power consumption at any time. Consequently we can predict the remaining battery lifetime to an approximate value. The temperature sensors, as mentioned above, are used to monitor the temperature on the apparatus box. We use this information to control the fan speed. When the box is not too hot, we don't need to run the fan at high speed, which will in effect conserve power. There are many different technologies available that we can consider. These major technologies include LCD, LED, CRT, and Plasma. However, we will limit our

discussion to LCD and LED displays, since all the other technologies are of no practical use for our purpose, since we want two small displays. The LCD and LED technologies themselves are divided into different technologies, which are many. We will have a brief description of each technology, however our purpose is not to give a detailed report on how these displays work. So we have limited our discussion to the advantages and disadvantages of each technology.

3.7.1 Liquid Crystal Display (LCD)

LCD displays use the light modulating properties of liquid crystals. The theory behind this is very intensive and not required here. All the LCD screens displays that we have in our gadgets, watches, phones have thousands, if not millions pixels. Each of these pixels represents a picture element that is made up of liquid crystals. All these individual pixels are arranged in a grid pattern. The light source is behind this grid. There's a misconception that the LCDs themselves emit light, but as we can see that is not the case. The way it works is when there's an electric field applied to the pixel grid through cathodes, these pixels can realign themselves in patterns which we can recognize as numbers, letters or graphs. This is a little more complicated than it can be inferred from the previous section. The pixels by aligning, are able to polarize the light from the background, which we then see as a color (if we have a color LED), or as black. This alignment and picture formation depends on the different LCD technologies that we discuss. A brief description of the major LCD technologies is given below.

3.7.2 Twisted Nematic (TN) [4]

This is the most commonly used LCD technology, because it is very cheap to manufacture and it's abundant. The shortcoming of this technology is the default position of the pixels in this screen. By default this technology passes light through, that means we can't see very intensive black colors, and the pictures therefore have a very low contrast. When there's an electric field applied in across the grid, the individual pixels can rotate up to 90 degrees. This polarizes light and makes it invisible to the human eye. Another shortcoming of this screen is the viewing angle, which are typically less than 170 degrees horizontally and vertically. The major advantage of the TN technology is the refresh rate. By this we mean the speed at which the crystals can realign themselves. TN is the fastest technology available. A picture of the TN cell is given in Figure 3.29.




Figure 3.29 is a very good representation of the TN technology. We can see that in the “off” state the pixels have a random orientation. However as soon as there’s an electric field applied to the cell, the pixels align themselves in a way, that will let light through.


3.7.3 Super Twisted Nematic (STN) [36]

The STN is an advanced version of the TN display. The key behind the STN is the rotation angle of the pixel. Each individual cell can rotate through 270 degrees, allowing more images to be displayed.

3.7.4 Thin-film-transistor (TFT) [4]

The technology behind TFT LCDs is that each pixel has an associated transistor with it, which acts as an electrical switch for that unit. This changes the passive array into an active matrix of pixels. This technology has advantages, such as increased viewing angle, better saturation, and contrast. However this is by far not the best technology, also not the cheapest technology. That’s the reason why this technology is not produced in large scale. However, the density that can be achieved using this TFT technology makes it very appealing for small displays. Figure 3.30 illustrates the TFT technology.

Figure 3.30 - TFT technology



© 2010 Encyclopædia Britannica, Inc.

Reprinted with permission from Encyclopedia Britannica.com

3.7.5 In Plane Switching (IPS) [42]

This technology is superior to all the other technologies. Each IPS display pixel has two transistor controllers and offers best control and accuracy for the picture. In IPS screens a switching voltage is applied to the electrodes to untwist the pixels. The added complexity of this circuit makes it very expensive to fabricate, and also suffers from slightly smaller saturated colors than other technologies. However, the viewing angle for this screens is the best available and is not distorted even at wide angles. Two IPS technologies are available: S-IPS, H-IPS. These displays are used in the best and most expensive applications.

3.7.6 Vertical Alignment (VA) [42]

VA technology is better than TN, and not as good as IPS technology. The key difference between VA and TFT displays is that the liquid crystal in the VA screen has a naturally vertical alignment, which by default doesn't let light through. So, when there's a field applied to this display, the cells tilt allowing light to pass through. Therefore VA displays have a sharp black level. VA displays themselves are divided into different types, such as S-PVA, MVA. So far we have discussed the major types of displays. However, the list is not limited to the displays technologies mentioned above, there are many other advanced technologies available, such as the Zero-Power display, which only dissipates power when changing the picture on the screen, otherwise this screen doesn't need power. Another important classification of LCD screens is the display mode. We need to have understanding about the different modes, to choose the proper display. LCD displays come in 3 different modes.

3.7.6.1 Reflective Mode

Reflective displays are unique in the sense that they don't have a backlight. The sole light source is the ambient light which is reflected back and acts as a source. This reduced the power consumption by 60% compared to other types. The disadvantage of reflective displays is that they are almost useless if used indoors.

3.7.6.2 Transmissive mode

Contrary to reflective displays, transmissive displays use a backlight as the source. These types of displays are great when used indoors, however their contrast decreases with increased sunlight.

3.7.6.3 Transflective mode

Transflective mode displays are the best available. These displays adjust depending on the surrounding. The features described above are two very important features one must consider before choosing an LCD display. Of course there are more features that must be taken into consideration. Some of these features are self explanatory and are summarized in Table 3.18 [11]. Completing the key points about LCDs, we would like to outline some key features of Light Emitting Diode (LED) displays.

Table 3.18 - General Display Specifications

General Specification displays	
Display type	Alphanumeric, graphic
Technology	TN, TFT, IPS, VA, etc.
Backlight	Florescent, LED, electro luminescent
Mode	Reflective, transflective, transmissive
Viewing area	Height, width
Interface	Serial, I ² C, RS232, UART, USB
Application	Automotive, Computer, Military, etc.
Character specs	Number of characters per line, number of lines

3.7.7 Light Emitting Diode (LED) displays

LED displays came along quite later than LCDs. The basis of an LED screen is the individual light emitting diode. LED panels are small displays, and can be used individually or these panels can be part of a bigger screen. A single color pixel in an LED screen consist of 3 different color (red, blue, green) tiny LEDs driven individually. LEDs are mainly used in destination signs, store signs, billboards. Quite frequently LEDs are used as a light source for lighting purposes. There are two major LED panels. The first one is the conventional, which uses discrete LEDs. The

second type is the surface mounted devices (SMD). Table 3.19 compares LED and LCD displays, through comparison of key features [8].

Table 3.19 - LCD vs. LED

Feature	LED	LCD
Background light	LED lighting	Florescent light source. LED backlight LCD displays are also increasingly available.
Outdoor/Indoor use	LED displays become washed out under direct sunlight	Retain much better quality under sunlight compared to LED
Contrast	LED backlight can be turned off behind the black areas on the screen	Backlight interference will always have some degree of interference
Angle View	LED displays have a better viewing angle	Depends on the technology. However cannot achieve LED display
Power consumption	40% less power consumption than LCD displays	Costs may reach \$150-200 per year
Cost	Relatively high cost	Good quality screens are readily available for
Availability	High cost makes it harder to find. LEDs are mostly available in screens bigger than 46 inches.	Abundant
Eco friendliness	No mercury used	Mercury used for production

From Table 3.19 there's no doubt that LED screens are superior. However for our application LCD screens provide more options. We have a wide range of sizes, character display formats. Also these monitors are relatively cheaper than the LED counterparts. We should also add that the variety for LED displays is not as big. These are the general features that we needed to have on the display of choice and based on that we will pick the appropriate LCD display. Based on a team decision we choose the following specs from Table 3.18:

- *Display type*: Alphanumeric
- *Backlight*: LED
- *Character specs*: 4 lines, 20 characters each line (80 total characters)
- *Interface*: Serial (RS232), I²C

Considering the discussion and the specs mentioned above, we chose an appropriate LCD display, which is affordable and exceeds our specifications. This

LCD is shown in Figure 3.31, which has many of the great features outlined above, such as STN technology, transfective mode, and 20x4 character format. According to the data sheet, this display also has several interface options, such as I²C, and RS232. To ensure that the display is getting power only when we need to read measurements, we are able to control the backlight power, as well the main display power. Fortunately this display has designated I/O pins for this purpose, so we can control these settings using the microcontroller. We are using this display mainly to monitor power consumption and to keep track of the time the boat has been running of the batteries. Taking these into consideration our LCDs display current, voltage, and power values. We have organized this information to display it in a manner that is legible and not confusing. Our screen displays multiple sets of information. This is summarized in Table 3.20.

Figure 3.31 - LCD Display



Reprinted with permission from Digi-Key Corporation

Table 3.20 - LCD Display details

Screen	Display
1) Shore power details	Shore: xx.xx V xx.xx A xx.xx W System: _xx_ _xxx_ min
2) Logic battery power details	Logic: xx.xx V xx.xx A xx.xx W System: _xx_ _xxx_ min
3) Motor battery power details	Motor: xx.xx V xx.xx A xx.xx W System: _xx_ _xxx_ min
4) Temperature and humidity	T1:xxx.x°C H1:xx.x% T2:xxx.x°C H1:xx.x% T:xxx.x°C - H:xx.x% System: _xx_ _xxx_ min
5) Test	N/A

The first row in the Table 3.20 describes how the shore power measurements is displayed on the screen. The first line begins with an indication that this is shore power, than the line continues to show the voltage in four digit format. The second

line shows the current in four digit format. The third line is achieved through simple calculation, and it shows the power dissipation at the measured instance in 4 digit format. The fourth line shows the system status in two digit format. This indicates that the communication with the microcontroller is ok; to ensure us the information we are getting is recent and not old. We are using these two characters for this purpose. When the system status is good, the screen displays “:)” a smiley face, if the status is bad, and no communication has been established with the microcontroller, we display “:(“ a frown face. This line displays the time the boat has been running of batteries and not shore power. This is displayed in three digit minute format. The discussion above spreads also to line items 2 and 3, since the format is the same. The only difference is in the first line, where instead of “Shore” it will read “Logic” or “Motor”, depending on what we want to see at that instant. Row #4 in Table 3.20 may need further explanation. This year we are including two temperature sensors in the circuit/computer box. We use the temperature measurements to control the speed of the cooling fan. More information on this can be found in the appropriate section of this report. Now we will show how the temperature readings will be displayed on the screen. Row 4 in Table 3.20 indicates that the first line shows the reading of the first temperature sensor in °C. The temperature is displayed in 4 digit format. We also can see “H1”. The temperature sensors that we use also measure humidity, so “H1” fill is followed by the humidity measurement in 3 digit format. The second line shows the same information as in line 1 but for the second temperature sensor. The third line is the average of the first two lines. The fourth line shows the system status as described before. The last item in the table is the “Test” mode. In this mode we display intermediate calculations, and states of the microcontroller.

4. Design

4.1 Power

4.1.1 Emergency Stop

It is appropriate to define a few features on the E-Stop circuit:

- Green light indicating that the E-Stop circuit is active. (We define active as the state when E-Stop is on and current is provided to the relay coils. In this state all the motor controllers and servo motors are powered.)
- Red light indicating that E-Stop is not active
- E-Stop is able to switch off power to all devices mentioned in Table 3.4
- E-Stop has appropriate modules that enable remote triggering of the circuit
- E-Stop is triggered remotely, but it cannot be reset remotely.

The desired design specifications are mentioned above. To achieve our goal we made a decision based on the following few designs for our emergency stop circuit.

- *Active E-Stop circuit-1.* This circuit consists of relays, latches, and transistors that are used to amplify intermediate signals. This E-Stop design was implemented during last year's competition.
- *Active E-Stop circuit-2.* This circuit is similar to the one described above. However, in this design we considered to use high power FET switches instead of the relays.
- *Passive circuit.* This design doesn't have any active components, and it's completely passive.

In the sections following we considered each of the three prospective circuits and identified the advantages and disadvantages of each design. This enabled us to make an educated choice that fits our needs, is reliable and is within the means of our budget.

4.1.1.1 Active E-Stop Circuit-1

The first E-Stop design that was considered was implemented on the boat in 2010. This design is given in

Figure 4.1. Overall this circuit functioned as intended. However we had some minor difficulties, which we will clarify when we get into the details. At first sight this circuit seems to be complicated, however the operation is very simple, and we can begin the analysis of this design from the left upper corner, where we can see a 5V voltage regulator. This regulator is used to power on the logic components in this circuit. In Figure 4.1 one can locate the logic component on the right upper corner, where we see a 74LS279 quad set-reset latch. This logic component is an active low device. Please note that

Figure 4.1 is not the complete design of last year's design. In the previous year the E-Stop circuit consisted of two E-stop designs as the one shown in the figure. The purpose of this was to divide the high load by sharing the current between the two latches. Also, using two TTL devices was beneficial in the sense that we could expand on it if needed. However, to make the design clear and less twisted we are presenting only one section as shown in

Figure 4.1. The operation of this circuit is quite straightforward. The latch is powered on by the 5V voltage regulator. We have defined the "S" and "R" ports of the latch as "reset" and "set" respectively. As we can see the E-Stop net is connected to the "R" port and the Reset net is connected to the "S" port. Please note that by default both ports were connected to the output of the 5V voltage regulator output. This doesn't mean both were high at the same time, but depending on the state of the switches ("E-Stop" and "Reset" switches) any of these ports could get a high signal and set the appropriate "Q" value. According to the datasheet of this particular latch, the output in the event both inputs are high/low must be the previous state of the latch. We initially assumed that this state would be low, in which case the E-Stop circuit would cut off any power to the motor controllers and servo motors. However, the actual

output was high, which resulted in some undesired effects. We will discuss these effects in detail later in the report. Now, assuming that when there's power applied to the emergency stop circuit, the output of the latch goes high, in which case current is supplied to the relay coils, which in turn connects the motor controllers and servo motors to the main power source. As it can be seen in

Figure 4.1 transistors U5 and U6 are used to amplify the output of the latch, to insure minimum power requirements of the relay coils are met. Also to eliminate any switch bouncing effects we have inserted a few capacitors between the signals and grounds. This way we are reducing the bouncing effect when the E-Stop switch is pressed, or when the relays switch. We most certainly are not eliminating the bounce effect and this is a very simple way of fixing this problem. There are many other ways to handle de-bouncing, such as additional circuitry, or software de-bouncing. However, for our application, the capacitor between the signal and ground works just fine and keeps the signal very stable. In addition, the capacitors reduce any ripple present in the signals. Even though our signals are DC, we don't expect a constant voltage. This undesirable effect can be caused by minor variations in the voltage source. Another component that we can see on the circuit design is the diode. Our design as can be seen contains several diodes. These diodes are the so called protection diodes, which protect the contacts of the relay. Relay contacts create a spark when they switch, which decrease the life of the contacts. These protection diodes reduce this negative effect and extend the number of switches the relay can perform. In many cases this protection diodes come installed on the relays. However, if we change our design and purchase relays that don't have this protection, we have to manually install them. In

Figure 4.1 we can only see one E-Stop trigger, but there were 3 triggers total. As mentioned above, one trigger came from the circuit in

Figure 4.1, and since we had two identical such circuits, the total number of E-Stop buttons on the boat was two. The third trigger was remote. A picture of the module that enabled us to have a remote trigger is shown in Figure 4.2. We were only able to engage the E-Stop circuit remotely, but we were not able to reset it remotely. This feature was mandated by the competition rules.

Figure 4.1 - Active E-Stop Circuit-1






Figure 4.2 - Pololu Module for E-Stop Circuit



The big box in Figure 4.2 is the wireless switching module, which is a “Pololu RC Switch with Digital Output”. The Pololu switch [37] receives and converts radio control pulses to digital low/high signals that can be used in RC switch and RC adapter applications. A picture of this switch is given in Figure 4.3. This figure includes pictures of both sides of the Pololu board. The “OUT” terminal is apparently the output of this little circuit, and the “GOOD” terminal is used to check whether the pulse width is above or below the 1.6 ms threshold. The RC signal is connected to the “IN” terminal of the board and the VRC is directly connected to the VCC power supply as can be seen in Figure 4.2. The connection between these two power terminals means that the RC receiver will be powered on by the digital system. The output range for the Pololu RC switch ranges from 2-5.5V. When the RC signal has been received and verified that it is a “GOOD” signal, the primary output “OUT” of this board will be able to source or sink 20mA. We can conclude that in order to be able to “drive” a relay coil, we must amplify the Pololu output signal using a transistor, as indicated in Figure 4.2.

Figure 4.3 - Pololu RC switch with Digital Output



Reprinted with permission from Pololu Corporation

The Pololu board has a LED status indicator. The LED has 3 different modes. First, when there's no valid signal detected the LED flashes with a duty cycle of 50%. When there's valid signal detect, but the signal pulse width is below the 1.6mm threshold, the LED flashes at a very low duty cycle, which means the flashes are


very small. The third state is when the LED is on, and it's not flashing, this occurs when a good signal is detected at "IN" and the pulse width threshold is met.

This concludes our brief summary about the E-Stop circuit, its operation and properties. The aforementioned discourse validates that this E-Stop circuit can shut down power to all motor controllers and servo motors, however, to make it useful for the ASV 2011 competition we will have to make some minor changes to the circuit. From Figure 4.1 we remember that initially there was no definite low input to the set-reset latch. According to the datasheet of this component our output should have been low, which would still keep the circuit in E-Stop mode, meaning that all power should have been cut off from the motor controllers and the servo motors. To our surprise, when we powered the E-Stop circuit, the output of the logic was high, and the mechanical arm of the Boat swung. The team was able to disable this motors by pushing the E-Stop button, however, we would like to avoid such a scenario. Therefore our new design includes minor changes in its design to ensure the initial state of the Boat is E-Stop triggered. Second change we made to the existing design is adding two LED indicators, showing the state of the emergency stop circuit.

4.1.1.2 Active E-Stop Circuit-2


The design that will follow is almost identical to the design in Figure 4.1. The difference is that we intend to use high power FET switches instead of the relays. This way we would be able to design our own switching device by buying a few relays. A typical picture [17] that helps to visualize this switching device is given in Figure 4.4.

Figure 4.4 - High Current DC switch



Reprinted with permission from Jim
(No Scale Available)

The circuit schematic for the high current DC switch is given in Figure 4.5. To clarify the analysis of this switch, we will also try to go through the circuit and explain its operation to ensure clarity.



The circuit schematic shown in Figure 4.5 is very easy to understand. When the switch (S1) is closed there's a path to ground, and we will get an output. For a 24V power supply we would use 10k Ω for R3. The voltage drop across the FET is less than 0.5V, depending on the model. The voltage drop mentioned is insignificant and therefore this switching circuit can be used in our design for high power switching.

Table 4.1 is a small summary for the high current DC switch, and contains the current and voltage characteristics for two different FETs [17].

Table 4.1 - High current DC switch specs for different FETs

FET Type (Q_2)	Voltage drop @ 12A	R_3 value (28V supply)	R_3 value (13.8V supply)
FQP47P06	0.24V	3.3k Ω	500 ohms
STP80PF55	0.16V	10k Ω	1k Ω

We mentioned above, also it can be seen in the table that the voltage drop across the FET is very small, and should not affect the performance or the voltage at the output. According to the values shown in


Table 4.1, for a 24 V supply and 12A load we should expect an output voltage no less than 23.5 Voltage. At these conditions we would have a reliable switch that can provide the necessary currents to meet the requirements described in Table 3.4. Let's simulate the high current switch in Figure 4.5, and see what the output is and whether this circuit is reliable. A simulation of the switch is given in Figure 4.6. As we can see the P-FET used for the simulation is not included in

Table 4.1. We have tried to use another power FET, and most of these FETs will have similar characteristics. This simulation is just used to give us a basic understanding of the voltage drop that will occur at the drain-source terminals of the FET. After the gate voltage is sufficient enough, and the channel is created, than a certain voltage drop from the drain to source gates creates a conducting path. In

order to be feasible to be used for the project, the voltage drop across the FET cannot be bigger than the values shown in

Table 4.1. According to the simulation results that one can see in Figure 4.6, at a load of 500 ohms, the voltage drop is already 0.4 V. We also used some other load values. We tried to increase the load current, but the voltage drop across the FET kept on increasing, making this switch not very reliable, since we cannot afford to lose 0.5 volts across the FET. Another drawback of the high current switch is the fact that it is not isolated. Switching 20A at 24 V can be dangerous if not isolated. Let's take a look at our last E-Stop design.

Figure 4.6 - High current DC switch simulation




4.1.1.3 Passive E-Stop circuit

We named our final design “passive”, since there are no active components in this circuit. To clarify, we can say that in this design we have avoided using any logic components, such as the set-reset latches used in the first design (See Figure 4.1). This way we are confident that the reliability of the E-Stop circuit is improved since no logic failure is possible. For this final design our reliability depended on choosing the proper components, and making sure they are connected properly. The basic building block of this circuit is the relay, the rest is a simple but rather smart design that eliminates all logic components, and only uses lumped elements. We know that the lumped elements are very reliable and have clearly defined tolerances. This gives us confidence to predict the outcome within very tight margins and rely on these predictions. We base this result on a few preliminary needs, which may change in the future. A simple diagram of our Passive E-Stop design is given in Figure 4.7. We have implemented the following:

- Four E-Stop buttons (this includes one remote E-Stop trigger)
- 2 Reset buttons
- Red LED, indicating no power is being supplied to the servo motors and motor controllers
- Green LED, indicating that power is being supplied to the motor controllers and servo motors.

Figure 4.7 - Passive E-Stop circuit schematic




As mentioned above, Figure 4.7 is a simple representation for the passive E-Stop design. There are no values included for the components; we will get into those details later, when we explain the logic behind this circuit in detail. So Figure 4.7 is just a simple representation of the passive circuit. After we complete the discussion on the circuit, we will have a schematic with all the component values. First we should note that the passive circuit shown meets the requirement stated above. We can see there are two LEDs in the circuit, there are three E-Stop buttons and one Pololu remote control switch. We also can see two reset buttons. The operation of the circuit in Figure 4.7 is not complicated, but it is rather simple. We can begin the discussion with the DC source, which is a 12V supply. The first Relay on the left side is a normally open (NO) relay. We have connected the coil of the relay and the switch in series. Please note that this is a single pole double throw (SPDT) relay. One of the contacts is connected to an LED. This is the red LED. As we can see, this LED will be turned on when there is no current in the relay coil. This indicates an inactive E-Stop circuit, and as we know from previous discussions, in this state no motor controllers or servo motors are powered. The second contact of the SPDT relay is connected in parallel with two switches. These switches represent the "RESET" buttons. When one of the switches is pressed it will complete the circuit, and there is a path to ground (we assume that the E-Stop buttons are closed and the

circuit has a path to ground). This allows current to flow in the relay coil. In the case of sufficient current in the coil the switch flips to the other position, which creates a path to ground independent of the reset switches. Through additional programming, we can also stop the computer from compiling any software if the E-Stop is off and the machine is not doing anything. Continuing with the analysis, we see a resistor and another LED (green). When the circuit is complete, and there's current through the LED branch, it turns on. This green indicator means that the E-Stop circuit is on, and all motor controllers and servo motors are on. Towards the end of the branch we see 4 switches. Three of the switches seen at the end of the circuit are "pushbutton break" switches. If any of these switches is pushed, it will break the path to ground, and E-Stop circuit will turn off. This forces the first relay switch to move to the LED position, and the red LED will turn on, indicating that E-Stop is inactive. Similarly the E-Stop circuit can be turned off by the Pololu remote control switch. From the discussion about Figure 4.2 & Figure 4.3 we know that the output of the Pololu can range anywhere from 2 – 5.5 V, and a maximum current of 20 mA. We use the output of the Pololu to drive another small relay coil. This can be seen in Figure 4.7, where the output of the Pololu is connected to the relay coil series with a resistor. This relay is a normally closed relay. This ensures that initially the circuit has a path to ground. However, when the Pololu output goes high, current will flow through the coil, which will flip the switch and break the circuit.


From the discussion above we see that this circuit is very simple, no tricks, or complicated circuitry, no logic components. This means that this circuit is safe and reliable circuits that meets all the design requirements and perform the E-Stop function. At this point it's necessary to show how the motor controller and servo motor relays are connected to this circuit. The answer is simple. The coils of the mentioned components are connected in parallel with the first relay. This can be seen in Figure 4.8. This is a very convenient way of realizing the E-Stop. Of course we may think about loading effect that may be created by each additional relay; however we know that at low frequencies the inductor can be considered a short. This means that the equivalent resistance will decrease, resulting in higher current. This current, however, is an additional 100 mA per relay, which our circuit can provide. Another change that appears in Figure 4.8 compared to Figure 4.7 is the location of the t-section and the LED. We moved this to ensure that the switches are at a high potential (12V).

Figure 4.8 - Passive E-Stop including external relays



A final schematic of the passive E-Stop circuit is given in Figure 4.9. This schematic has been designed in Eagle, and represents the design we would like to implement. The relays used for the schematic were general use relays. We used this for convenience. In case the actual relays we buy have different foot prints then the ones currently shown, can be swapped easily. The same is also true for the LEDs used in the schematic. They are general LEDs and can be replaced by another type of LED. In the schematic we can see two connectors, SV1 and SV2. As we can see the pins of SV2 are connected in a serial configuration. We have connected E-Stop buttons to the pins, and it will function as intended. As an example; if there's a break-button connected between pins 4 and 3, then pulling it, would create an open circuit and turn of the E-Stop circuit. This is what we have described in the discussions above. Similarly, for the reset buttons we use SV2. The pins of this connector are connected in a parallel configuration. To confirm that it will function as intended, we imagine a make button between pins 4 and 3, then pushing this button would create a short across the switch, and a path to ground will be created. As described above, current flows through the coil of the inductor, which will force the switch to change its orientation. These connectors help us to organize the switches, and we can trace all the switches back to one location, the connector. Another addition to this circuit is the capacitor across the connectors. These capacitors are included to ensure there are no voltage spikes (highs and lows) when the switches are engaged or disengaged.

Figure 4.9 - Schematic for Passive E-Stop Circuit




Comparing Figure 4.8 and Figure 4.9, the last difference we notice is the absence of the parallel relays that will be used to control power to the servo motors and motor controllers. These relays as indicated earlier are independent of the E-Stop schematic. Well, by independent we mean that as long as the E-Stop circuit is functioning properly, then we can connect the parallel relays safely and without any difficulties. We also would like to mention that we have chosen the relays that will be used in the schematic shown in Figure 4.9. For the parallel relays shown in Figure 4.8 we most likely are using the same relays that we have used last year, since they performed without problems, and we have hand on experience with them. Another advantage of using the same relays is that we know for a fact that we have these relays in the software libraries that we use to create these schematics.

Examining the schematic in Figure 4.9 we know it functions as intended. However, there's a worry regarding the LED after the voltage divider "T-section". As a rule of thumb we assume that we will need 10 mA to drive the LED. We realized this limits the overall current that the circuit can provide to the parallel relays as shown in Figure 4.8. However, if we limit the LED branch current to 10 mA, then the rest of the current would probably have flowed through the branch with R_3 (see Figure 4.8). Therefore we have removed the t-network and have moved the led with a transistor to the main E-Stop relay switch.

4.1.2 Reverse Polarity

We have discussed the most common reverse polarity protection methods in section 3.1.2. In addition we would like to mention that there is another way to accomplish this task, by using a relay, however we are not using a relay for this task, since we have many relays in the system, and we don't want to introduce additional power dissipation would result from relays. No doubt that any reverse polarity protection


method described previously would introduce power loss, but these are relatively smaller compared to the power dissipation of relays. Out of all the protection methods discussed, we will choose the second design, which was described in 3.1.2.2. This method uses a parallel diode and a series fuse. We believe that this circuit will dissipate the least power and is a convenient way of doing it. Also, we have many fuses available to us from last year's competition; this reduced our expenses. The schematic of the reverse polarity protection circuit to be implemented is shown in Figure 4.10.



4.1.3 Hot Swapping

In Section 18 we briefly described the meaning of hot swapping. We also mentioned that there are several circuits that can accomplish this task. The circuit that we discussed in detail is given in Figure 3.8. Another method that we mentioned about was the IC controller method. However, we ruled out the possibility of the IC controller, since, as mentioned previously, we don't want to have ICs involved in this circuit. The circuit that we will implement is the circuit in Figure 3.8. A schematic for this circuit can be found in Figure 4.11. Our concern with this design was the power dissipation, since relay coils can present an extra load, and decrease source life time. However, we should note that the circuits are set up in a way that no power is dissipated in the relays, when batteries are connected. The relay coils only dissipate power when the shore power is applied. We can consider shore power a relatively constant source of power, and neglect the quiescent power dissipation of the relay coils. We should mention that shore power provides 24V, and that the batteries have a 22.2 V rating. Please note that all voltage sources go through regulation before reaching the appropriate circuits, and that the connectors are rated for approximately 24V and 50 A of load. Another concern with the current design is the voltage rating of the relays. Our relays are rated for 12V sources, however needed to find 24V rated relays that have the same foot print as the 12V relays. As of right now our design is the one shown in Figure 4.11.

Figure 4.11 - "Hot Swapping" Circuit Schematic



4.1.4 Voltage Regulation


For the design process we used the most efficient components that were well balanced for our application. This includes price, efficiency, number of components required, as well as many other factors. We preferred to try to use as much surface mount parts as possible compared to through-hole components. This is due to the idea that we needed at least a four layer board and surface mount parts would only use one of the those layers instead of all four by using through-hole parts. Using surface mount components does limit which parts we were able to use due to the difficulty of actually soldering the components down. If we needed a microscope to see the part it's deemed way too small. Although we could use an oven to flow parts we are forced to think ahead to the competition where parts need to be easily fixed should a problem occur during a critical moment. Typical DC/DC converters consist of choosing an IC and then choosing the external components that go with it. This typically allows you to choose specific values so that the regulator works best given the users requirements. The other method of using DC/DC regulators is by buying prebuilt modules which already have most external components on its own PCB. There are some external components needed but this usually consists of input and output capacitors and some resistors. These are very easy to replace and come in many package types.

There are many distributors of DC/DC power supplies and some have their own software that we used to assist in the research and purchasing process. Using WEBENCH by National Semiconductor it was very easy and simple to simulate the

regulator's behavior at difference voltage and current levels. From the application we were able to extract efficiency data as well as projected output voltage ripple. A very nice feature of the software was that it also lists the exact components needed, an idea on the area the regulator will consume, a bill of materials (BOM), and the overall cost. This lead to fast decisions while choosing a suitable regulator which meets our requirements. The following paragraphs go through the process of choosing the proper switching regulators.

5 Volt Regulator: Last year the Robotics Club tried to implement our first surface mounted part, a National Semiconductor 5V DC 3 Amp simple switching regulator. We browsed the internet looking for a better and more efficient switching regulator. After searching and simulating we landed on the LM2686, another simple switcher which is also a 5V DC fixed output regulator capable of delivering 3 amps maximum. We setup the application so that it assumed a maximum voltage of 26V DC which is about what our six cell lithium polymer batteries will charge up to. The focus when we chose this part was overall PCB layout size, cost, overall efficiency, efficiency at low loads, and output voltage ripple. The overall efficiency of National's simple switchers is usually very high with this regulator averaging around 90% with 26V DC input. If the source was our 4 cell lithium polymer batteries at 16V DC the efficiency increases slightly but we are ok with this efficiency difference because the input current with the higher voltage is about half of the current if using the lower voltage source. The next critical factor was the efficiency at low load. This can cause the converter to enter DCM mode and have a very low duty cycle. Knowing the components that use 5V it was clear that we could test the vehicle with limited components powered and therefore would realize a low load condition. We needed to ensure that the regulator would work efficiently and stay in CCM mode. Using the application we determined that at 0.4 amps the regulator maintains CCM mode with an efficiency of 86.3% which is much better than most other switching regulators. Figure 4.12 shows the efficiency of the device, the average input current, as well as the output voltage ripple.


Figure 4.12 - 5V LM2676 Characteristic Charts



Reprinted with permission of National Semiconductor Corporation

Getting this efficiency came at a price for layout size. Using the application to squeeze out some more efficiency, the output inductor size almost tripled. If board space was an issue we could have reduced the inductor for the less efficient inductor. When the vehicle is on, the microcontroller is most likely always on. This brings up the next specification of output voltage ripple as seen in Figure 4.12. The device, at a maximum output current of 3 amps at 26V DC input only has a 16mVp-p output ripple. This is advantageous because the microcontroller has on-board analog to digital converters that will use this voltage as a reference voltage. The microcontroller might also output many pulse width modulated (PWM) signals and other digital signals. It is important that the input voltage to the microcontroller is as ripple free as possible to ensure good signals in and out of the microcontroller. Figure 4.13 is the schematic generated by the application showing the desired values needed. The datasheet for the part does specify some layout specifications for the printed circuit board as well for increased efficiency and reduced noise.


Figure 4.13 - 5V LM2676 Schematic



Reprinted with permission of National Semiconductor Corporation

8 Volt Regulator: The eight volt regulator powers multiple sensors including the compass, video camera, and the firewire camera. This voltage is not a typical voltage so we had to search for an adjustable regulator that we could trim to eight volts. This regulator does not need a high power rating as these devices do not require much power. We have calculated that the maximum current the regulator needs to deliver is about 0.5 amps. Therefore, we searched for a 1 amp regulator which is enough for our application. This leaves some margin should the design change and need to use more power from this regulator. Again we used surface mounted components where possible and used as small of a footprint as possible. We found a regulator similar to the LM2676-5.0 used above but has a 1 amp current rating and is adjustable. An LM2675 is a possible choice for this regulator. Using the analysis tools through WEBENCH, the regulator is capable of delivering 0.2 amps while staying in CCM mode. At 0.2 amps with an input voltage of 26V DC, the regulator reaches an efficiency of almost 90%. At 0.5Amps, which is our calculated


typical current draw, the regulator reaches its peak efficiency of almost 92% as seen in Figure 4.14. Although these sensors are not very specific on input voltage ripple, the regulators maximum output voltage ripple is an impressive 4.8mVp-p which is also seen in Figure 4.14.



Reprinted with permission of National Semiconductor Corporation

The footprint of this regulator is very small. Various package types are available for the regulator including a surface mount as well as a dual inline package. The surface mount part has dimensions that are slightly difficult to solder so due to the competition we felt more comfortable with the dual inline package in case it needed to be replaced quickly. The price of the components is relatively inexpensive at about \$3.00. From this the IC was sampled from the website further reducing the cost. The entire schematic consists of only nine additional components which the WEBENCH software has found and calculated the proper values for. Figure 4.15 shows the final schematic for using this regulator.


Figure 4.15 - 8V LM2675 Schematic



Reprinted with permission of National Semiconductor Corporation

Although this part is rated for 1 amp, it didn't necessarily mean it was the only part that would have worked. In fact we could have reused the same 5V regulator above but configure it for 8V DC output. Typically a regulator rated for 3 amps that would nominally only need about 0.5 amps is not the best option but using the WEBENCH application it configured the regulator for a nominal current rating lower than its maximum current rating. Therefore, by setting the application to 8V DC output with 1.5 amps of current the regulators operating point, efficiency, and output voltage ripple are close to the LM2675 characteristics. Therefore, from a manufacturing/building perspective it was better for us to use as many parts as possible that were the same. By using the same part we had similar schematics, PCB layouts, and building methods. As you can see in Figure 4.16, the efficiency and output voltage ripple are very good with similar efficiency as with the LM2675. The schematic layout is almost identical to Figure 4.15 except for a few minor component value changes.

Figure 4.16 - 8V LM2676 Characteristic Charts




Reprinted with permission of National Semiconductor Corporation

12 Volt Regulator: The ASV uses two 12V regulators to power the emergency stop system, the wireless bridge for the vehicle, and either one or two LIDAR sensors. The emergency stop system is a very critical system in the vehicle which ensures the users safety as well as the safety of the batteries and other components on the vehicle. We had to ensure that when the vehicle has minimal load on the regulator the regulator is still operating properly. During testing of the vehicle it is common to test parts of the vehicle without using the onboard computer and its related components. This is when we would experience low load scenarios. When the vehicle is fully operational the regulator is in full regulation mode and no concerns arise. The power requirement for the current LIDAR sensor (same as used last year) is 12V DC \pm 10%. From previous experience, it seemed that the tolerance on the input voltage was tighter. Therefore we needed a regulator in which the output voltage can be adjusted to ensure the sensor has enough input voltage to operate continuously. From this we determined that we needed to try to keep the vehicle operating with an input voltage of no less than 14V DC. In previous years we used a LM2596 which had an output voltage of 12V DC with the capabilities of 100% duty cycle according to the datasheet. This is actually only achievable if you design the duty to always be on in which chase any voltage input above or below 12V DC would not be regulated properly.

Staying with the National Semiconductor family of regulators WEBENCH found a LM22677 adjustable regulator. This regulator is capable of delivering up to 5 amps of current which exceeds our requirements. Our requirements only needed a maximum of 4 amps peak with a nominal current rating of about 3 amps. Therefore we setup the application to create the regulator based on a maximum current rating of 4 amps. The efficiency numbers as seen in Figure 4.17 are impressive as expected. At low load the regulator should be producing 93% efficiency with a peak efficiency of almost 95%. Along with this great efficiency comes the desired output voltage ripple. At the maximum input voltage the regulator is able to maintain about 30mVp-p ripple which is within the tolerances we would like to have.


Figure 4.17 - 12V LM22677 Characteristic Charts



Reprinted with permission of National Semiconductor Corporation

This device has a preferred package type which we were able to solder without any problems. With only 9 additional compact components the footprint was small and the cost of the regulator all together was not very expensive. The IC was also sampled so we reduced some of the cost there. Figure 4.18 illustrates the schematic of the regulator with its appropriate additional components.


Figure 4.18 - 12V LM22677 Schematic



Reprinted with permission of National Semiconductor Corporation

Texas Instruments designed a very compact and easy to use regulator, a PGN78020W module. This module is efficient and accepts a wide range of input voltages as well has an adjustable output voltage with a wide range. This device has many advantages to it. According to the datasheet, the output voltage of the regulator module needs to be at least 2V higher than the input voltage which will work for our configuration. The regulators output can be adjusted to range from 2.5V DC to 12.6V DC given an input voltage range of 7V DC to 36V DC. We chose external component values to adjust the output voltage to be around 12V DC to ensure that it never drops below 12V DC anywhere on the vehicle and all sensors and circuits remain in operation. Along with its great voltage range, this module delivers up to 6Amps of output current which easily met all requirements for power. This initially had us concerned with the regulation and efficiency at low loads. After looking at the charts in Figure 4.19 [43] the efficiency at 0.5 amps still remains at about 80% with a 24V DC input. The ripple in the regulator is also reasonable with a range of 40mVp-p to 55mVp-p.


Figure 4.19 - PTN78020W Characteristic Charts



Reprinted with Courtesy of Texas Instruments

This device comes in either a through-hole package or a surface mount package as seen in. The regulator is quite small and being a module has most of the necessary components on board. Even with this it still required external components to produce the necessary regulation since it is an adjustable converter. The datasheet has many configurations of the device depending on how much current you plan to draw through the regulator. Figure 4.20 [43] illustrates the typical schematic for this configuration of using the regulator with an output current higher than 2 amps. This schematic has eight additional components which is almost as much as before. It also requires you to take time going through the datasheet to calculate the appropriate values for the components for proper operation. Texas Instrument's application does not have this part in its database for easy building. In addition, the efficiency is less and the output voltage ripple is greater than the National Semiconductor regulator. Therefore, we realized this regulator required more board space as well as not performing as well as other options so we didn't use it.

Figure 4.20 - 12V PTN78020W Schematic




Reprinted with Courtesy of Texas Instruments

4.1.5 Voltage Sensing

Our vehicle monitors the three voltage inputs from Motor Batteries, Logic Batteries, and Shore Power. The Robotics Club has many batteries that are available for the vehicle. Depending on which batteries we use, the maximum voltage that would ever be supplied by batteries is 30V DC at the absolute maximum and the minimum voltage the batteries could safely discharge to is 13V DC. Given that our microcontroller's reference voltage is 5V DC, the input voltage from each source needed to be scaled properly in order to ensure that microcontroller can read each voltage. This design includes a resistive divider network, a diode, and a zener diode.

The voltage divider scales the voltage down by a factor of about six. To fine tune the value, a potentiometer is used to adjust the resistive network to the expected voltage. This part is a very small surface mountable part with a turn screw. This resistor has multiple turns to allow for greater precision. We added test points to be able to easily probe the signals for tuning. Assuming the microcontroller has an analog to digital converter with a resolution of 10-bits, then, as calculated in the research above, the microcontroller reads the voltage in steps of 0.0048V DC. The microcontroller then scales the voltage back up by about six in software so that the information can be relayed to the display as well as the computer. A 4.7V zener diode protects the microcontroller inputs from exceeding 5V DC. Figure 4.21 shows the schematic for voltage sensing including the voltage divider and the zener diode. We again used surface mount parts as power dissipation is very low and it saved board space. Please note that the zener diode was removed, since the current leakage at high voltages set off our readings by a considerable value.

Figure 4.21 - Voltage Sensing



4.1.6 Current Sensing

As per the research above, we concluded that the two most viable options were using sense resistors and/or close-loop Hall Effect sensors. In this section we illustrate the multiple ways that these can be implemented.

Sense Resistor – I2C Current and Voltage Monitor: The first design is using a sense resistor with Linear Technology's LTC4151 High Side Current and Voltage Monitor [21]. One feature is the I2C interface which would allow us to have multiple IC's communicating to the microcontroller along a single buss. In addition to this it features an extra analog input that is fed into its onboard analog to digital converter. We could utilize this input to sense additional sensors that might be close to it on the PCB. This could also free some analog inputs on the microcontroller if we utilize them. Using three of these devices would allow transfer of up to nine points of data using only the two wires necessary for I2C communication. This IC operates using the voltage coming directly from the source so no additional external source is required. Taking a closer look at the datasheet leads us to some more advantages as well as disadvantages. The on-board 12-bit resolution analog to digital converter is a great advantage as this resolution easily meets our requirements for accuracy. Interestingly enough, even with a minimum input voltage of 7V DC to the IC, the A2D only has a reference voltage of 2.048V DC. We would have liked to see a higher reference voltage for increased range. The amplifier across the sense resistor has a fixed gain of 25. This means that since the A2D compares up to 2.048V that the maximum voltage drop across the resistor is $\frac{2.048V}{25} = 0.08192V$ which matches the datasheet. This means that when choosing the resistor it is very important to use Ohm's Law in order to ensure that your expected maximum current draw does not exceed the limits of the IC. The accuracy of the voltage reading across the sense resistor is an acceptable $\pm 1.25\%$. The microcontroller was programmed to convert the digital data in the voltage across the resistor, scale it down by a factor of 25, and then divide it by the resistor value being used as seen in Equation 4.1. The microcontroller also converts the digital data for the input voltage into a value and then scales it up by a factor of 50 due to the internal voltage divider.

Equation 4.1 - Sense Resistor Scaling LTC4151

$$Current = A2DVoltage / (25 / Resistor)$$

Each IC has a hardware programmable I2C address by tying each of the two address pins high, low, or open. This way by only using two address lines allows for up to nine of these IC's on a single buss. This should give us enough possibilities for addresses to not cause conflicts with other devices on the buss if some addresses are already being used by other peripheral devices/sensors. If necessary we could overcome by implementing a simple I2C multiplexing circuit.

Table 4.2 is a simple representation of the resistors needed when using this particular IC. The values listed in the max current column appear very large. Although the currents should never reach those levels, we wanted to rate them this

way to protect the resistors against current spikes or accidental full load. Remember that our motors at full load could potentially pull 1200W. Also, shore power is connected to the motor controllers which are capable of driving 40 Amps. Granted they should never be run at these current ratings but we want to protect the circuit from any accidental high loads during testing/troubleshooting. We know the maximum voltage drop across the resistor can be 81.92mV. Therefore we used this information to tweak the resistor value to a commonly manufactured value so that given the maximum current the voltage drop would not be exceeded. Since our maximum currents are multiples of each other it was easy to see that for shore power, with double the current, we need to put two of the same resistors in parallel to share the current between the two resistors. For the full motor battery load of 60 amps, we would need to put four resistors in parallel. Choosing the same resistor makes ordering and assembling simpler and faster. We were able to find this resistor online without a problem.


Table 4.2 - Sense Resistors LTC4151

Input Source	Max Current	Optimal Resistor	Resistor Realization	Max Voltage Drop	Max Power Loss	Gain	Step Size Per 0.5A
Logic Battery	15Amps	0.005 Ω	(1) 0.005 Ω	0.075Volts	1.125Watts	25	.03125V
Shore Power	30Amps	0.0025 Ω	(2) 0.005 Ω	0.075Volts	2.25Watts	25	.0625V
Motor Battery	60Amps	0.00125 Ω	(4) 0.005 Ω	0.075Volts	4.5Watts	25	.016V

Now that we see mathematically that this method would work, let's try to look realistically at this solution. The obvious drawback as found through research is the power losses involved with this method. If the vehicle was running at full load on logic and motor batteries we would have a loss of over five watts which would reduce the efficiency of the vehicle as well as create additional heat in the vehicle. As far as shore power is concerned we are not very interested in efficiency or thermal drawbacks as during competition the vehicle will not use shore power. The voltage drop across all sources at full load is very insignificant and would barely affect efficiency. This voltage drop in conjunction with other drops in the overall design could eventually add up to significant voltage drop. We do have to keep in mind that these are the extreme cases as the vehicle will nominally never reach these values. If the vehicle was to reach any of these values it would be for an extremely short duration. Another important consideration is that each sense resistor is in series with the circuit and the IC has physical traces to it, therefore it is susceptible to current and voltage spikes and in turn is not isolated. This is especially possible on current sensing off of the motor batteries as current draw will be constantly changing. Figure 4.22 shows the schematic for the LTC4151 as used to measure current flow. You can see in the circuit there is a sense resistor of 0.02ohm which we would replace with the proper value resistor(s) per

Table 4.2. This amplifier is measuring the voltage drop across the resistor(s), amplifying it by 25, and converting the analog signal to a digital signal to be sent out across I2C. The “Vin” for the device conveniently uses the unregulated battery voltage for its supply power. It has an internal voltage divider which allows the input voltage to also be converted from analog to digital using the onboard ADC. It features a shutdown pin to disable the device if necessary; else it is internally pulled high for normal operation. Again, this device uses hardware to configure the I2C address for the device. The current configuration as seen in Figure 4.22 has the address of 1100111 in binary or CE in hex per the datasheet. For our design we used a three position jumper for each address pin so that we could change the address easily if need be. An added benefit is the use of the additional ADC seen as pin ADIN. We could use this for converting additional voltages that may be in the area of the PCB or additional sensors like a using a thermistor to measure temperature. The device is able to measure multiple signals using an internal multiplexing circuit for current, input voltage, and the additional analog input. Again the drawback with this was the limited realized step size as the ADC only has a Vref of 2.048V. Figure 4.22 also shows the device connected to the microcontroller using 2kohm pull up resistors to 3.3V. Since our vehicle does not have 3.3V we would have to pull up to 5V using a different value resistor. This resistor has been calculated in the communication section.

Figure 4.22 - Sense Resistor Circuit
High Side Power Sensing with Onboard ADC and I²C




Reprinted with permission pending from Linear

There were other criteria that need to be considered about this part. First was the accuracy of the part and determining if it was acceptable. According to the datasheet, the total unadjusted error due to the ADC is $\pm 1.25\%$ for current sensing and $\pm 1\%$ for sensing Vin and ADIN. This in turn means that our maximum battery voltage of 30V DC could read $\pm 0.3V$ DC higher or lower than the true voltage. At maximum current of 60amps for full power on motors the reading would be ± 0.75 amps higher or lower than the true current. The part itself also comes in a variety of package types which gives us options for placing the component. For

ease of soldering we would use the S Package with 16 leads. The price of the component is reasonable at around \$5.00 per unit.

Sense Resistor – Analog Voltage Output: This design involves using the MAX9920 engineered by Maxim as seen in Figure 4.23 [25]. This current sense IC was great for our application for multiple reasons. The IC is powered from 5V DC, comes in a very reasonable package size, has great accuracy, and has an adjustable gain. By having 5V DC input, the output can be adjusted so that the maximum output reaches almost 5V DC to give the analog to digital comparator the full range of values. The IC itself requires minimal current to operate the operation amplifiers in the IC reducing power losses.

Figure 4.23 - Current Sense MAX9920



Copyright Maxim Integrated Products (<http://www.maxim-ic.com>). Used by Permission.

We also configured the device for unidirectional operation as we had no need for bidirectional current sensing. It accepts a common-mode input voltage range of up to +70V which easily satisfies our requirements. The maximum sense voltage, or the maximum voltage drop across the sense resistor, is 200mV which allows the sense resistor to be smaller in size if we choose it to be giving us more range and smaller step values. We could also adjust the gain by using Equation 4.2 which gave us flexibility when choosing the proper resistor.

Equation 4.2 - MAX9920 Gain Formula

$$G = \left(\frac{1 + \frac{R2}{R1}}{4} \right)$$

The IC has a typical input offset voltage of $\pm 0.10\text{mV}$ which was very insignificant and didn't affect the results. This device outputs an analog voltage which can be read easily by the microcontroller or other analog to digital converter. We adjusted the gain so that the maximum voltage output at maximum current was

no larger than 4.7V DC. The SHDN (shutdown) pin needed to be tied to ground in order for the IC to be active and operating.

Table 4.3 is a table showing the realization of the circuit with sense resistors chosen. The values for choosing the resistors are identical to


Table 4.2 but the difference came from the gain and step size. Due to the larger reference voltage we were able to use the same voltage drop across the sense resistor while more than doubling the amount of data points. This was because between intervals there was a wider gap allowing for more increments to be seen by the analog to digital converter.

Table 4.3 - Sense Resistors MAX9920

Input Source	Max Current	Optimal Resistor	Resistor Realization	Max Voltage Drop	Max Power Loss	Gain	Step Size Per 0.5A
Logic Battery	15Amps	0.005Ω	(1) 0.005Ω	0.075Volts	1.125Watts	60	0.15V
Shore Power	30Amps	0.0025Ω	(2) 0.005Ω	0.075Volts	2.25Watts	60	0.075V
Motor Battery	60Amps	0.00125Ω	(4) 0.005Ω	0.075Volts	4.5Watts	60	0.038V

Closed Loop Hall Effect: This method of current sensing uses sensors which measure the magnetic field and therefore can sense much higher currents than using the sense resistor method. For this section we will discuss the LEM Current Transducer LAH 25-NP [18] for sensing the high current used by the motors from the motor batteries. As discussed before, this sensor needed to be capable of handling almost 60 amps of current. Although the vehicle should never actually be running these motors near full power, we still needed to spec a sensor that could handle the high current for some short period of time in the event that full power is reached. For this reason the LEM part that we found has a nominal current rating of 25 amps. Figure 4.24 shows that this part is only 21mm tall which is within our limits for component height on the PCB.

Figure 4.24 - LEM LAH 25-NP Dimensions





Reprinted with Permission of LEM

Starting with its design we were able to mount it on a PCB using through holes. Due to the high current it was unreasonable to push a possible 60amps through the PCB without using very large traces. Because of this we soldered the battery power wires to the leads itself on the back side of the PCB eliminating the need for traces. The footprint for the sensor was larger than the footprint for the current sense resistors but it was still within reasonable limits given our PCB size constraints. This sensor requires an external power of $\pm 12\text{V DC}$ of which we can only provide the $+12\text{V DC}$. Because the sensor is bidirectional, meaning that it could sense positive and negative currents, it needs the -12V DC to output for negative currents. Since we will never encounter negative current the need to supply -12V is unnecessary. The accuracy of the sensor is as expected very high with an error of only $\pm 0.3\%$. This is much better than the sense resistor method as with the sense resistor method we have to consider the accuracy of the IC as well as the components being used.

Most sensors like this are able to be configured for different nominal and maximum current ratings. Table 4.4 [18] shows that for our configuration with a nominal primary current of 25 amps and a maximum primary current of 55 amps we configured the device with the number of primary turns equal to one. Therefore we shorted the input terminals (1,2,3) together and also shorted the output terminals (4,5,6) together. If we wanted to configure the device for shore power we would use the configuration for the number of primary turns equal to two.


Table 4.4 - Closed Loop PCB Configuration

Number of primary turns	Primary current		Nominal output current I_{SN} [mA]	Turns ratio K_N	Primary resistance R_p [m Ω]	Primary insertion inductance L_p [μH]	Recommended PCB connections
	nominal I_{PN} [A]	maximum I_p [A]					
1	25	55	25	1 : 1000	0.18	0.012	
2	12	27	24	2 : 1000	0.81	0.054	

Reprinted with Permission of LEM

Figure 4.25 [18] illustrates the schematic of the device as well as the pin outs of the sensor. The three input pins and three output pins are most likely there to share the current through the device as a single pin could not carry the full current load. In the figure you can see how the Hall Effect sensor is the input into an amplifier which then outputs the appropriate current to drive enough current through the secondary coil to cancel the field generated in the primary coil. The output is connected to a resistor and then to ground where the voltage is measured across the resistor (R_m). $+V_c$ has been connected to our 12V DC regulator and $-V_c$ has been connected to ground as we cannot provide -12V DC nor is it necessary for our unidirectional application.

Figure 4.25 - LEM LAH 25-NP Schematic




Reprinted with Permission of LEM

After some more hunting for similar devices we found the LEM LTS 15-NP [19]. This is close to the LAH25-NP but is more suited for our application for many reasons. The nominal current rating on this device is 15 Amps which is hopefully closer to our current draw. In addition, it is capable of measuring up to 48 Amps with the device capable of withstanding currents up to 250 Amps meaning if the vehicle draws above 48 Amps we are not damaging the device. Another benefit is that it takes a standard 5V DC input so there is no need to worry about providing a second negative power source to it.

The LEM LTS-15NP has exposed leads on both sides. This is a huge benefit for our application. Since we are not running these traces through the PCB due to the high current we soldered the wires directly to it. With the LEM LTS 15-NP, we soldered the part to the PCB so that the part stays secure to the board while allowing the output signal, input voltage, and ground to be securely routed through the PCB. Since the leads are still exposed it leaves us enough room to solder the wire to them. This part also uses a Hall Effect sensor internally which is accurate to $\pm 0.2\%$. The physical size as depicted in Figure 4.26 [M18] is a very reasonable size and didn't crowd the printed circuit board. From the dimensions we can see that at only 24mm tall, the part doesn't interfere with the contents in the box due to its size. There are many more in the market that are larger and more bulky.

Figure 4.26 - LEM LTS 15-NP Size




Reprinted with Permission of LEM

Figure 4.27 [M18] represents the schematic layout for the device. In reality the device has three pins for the input current and another three pins for output current as only one pin in and out would not be enough to handle the current this device could measure. The power for the device is very simple and uses standard positive 5V input and ground. The output is already a voltage which makes using it with our analog to digital converters very easy. There are two other versions of this component which include access to internal reference pin and another with this feature plus a current output. Neither of these were beneficial for our purpose so we eliminated choosing them. Using Equation 4.3 we can determine the output voltage of the device which ranges from 2.5V to about 4.5V which is an acceptable range for the analog to digital converter. I_p is the current in the device and I_{pn} is the nominal current of the device which is 15 amps.

Equation 4.3 - LEM LTS 15-NP Formula

$$V_{out} = 2.5 + .625 * \frac{I_p}{I_{pn}}$$

Figure 4.27 - LEM LTS 15-NP Schematic



Reprinted with Permission of LEM

After careful consideration of all the options we chose to use the sense resistor method for logic and shore power as their nominal current ratings are within reason of the sense resistors. These were implemented using the MAX1920 with the adjustable gain and analog output. Having the analog output reduces the amount of communication needed. For the high current application, the best option was using the LEM LTS 15-NP which has good characteristics and small form factor.

4.2 Microcontroller

We chose to use the JTAG interface to program all our embedded systems as it provides us more debugging options. Also the programmer to be used already exists in the Robotics Laboratory, which is where all our testing took place. With JTAG, we were able to program our chips while they are in the system; this flexibility gave us the opportunity to fix any given bugs that we found in the code. For the microcontroller, all that was required to provide for in-system programming was a 2 by 3 (6 pin) header that plugged into a regular JTAG programmer.

4.2.1 Power

For power, it is important to provide clean power to the ATmega644. This included feeding it with regulated 5V as power and a steady voltage for its ADC reference voltage as well. The 5V power line on the chip is not completely susceptible to small variations in the line but however as the ADC reference voltage is detrimental to the conversion of our analog signals, any perturbation on the line could potentially throw off the sensor readings. The perturbations on the reference line include the switching noise from the voltage regulators. Assuming that our regulators have a switching frequency of 200 kHz, we needed to implement a 1st order low pass filter between V_{CC} and ground to filter out the noise. Following the equation in illustration in Equation 4.4 which was derived from a first order RC filter's time constant equation, we calculated the necessary components needed to filter out the switching noise from the voltage regulator.


Equation 4.4 - Switching Frequency

$$f_c = \frac{1}{2 * \pi * R * C}$$

From this we can see that if we picked a capacitor of 8kΩ, we would require a capacitor with a value of 0.1nF. The resistor would be inline on the voltage line and the capacitor would be in between the voltage line and ground. This applies to the power pins and the analog voltage reference lines.

Figure 4.28 shows the illustrated how the switching noise has been filtered out from the power and reference lines of the Atmega644.

Figure 4.28 - Illustration of schematic and board layout for the microcontroller regarding power



4.2.2 Two-Wire Interface

The two-wire interface is the software implementation of the I²C bus and is generally used when the microcontroller being utilized does not have any hardware-based I²C ports or all of its hardware-based ports have been assigned to other buses. The number of devices that can actually be hooked up on a given bus is determined by how each device on the bus is addressed. Some devices only have 2 bit addresses which allows for only 4 devices on that bus, while others have 4 bit addresses that can allow 16 devices on a given bus.

Figure 4.29 and Figure 4.30 show the hardware setup for any ports that will be used as a two-wire interface. In the figure, R_P is usually in the range of 1.8k Ω to 2.2k Ω . The reason for tying the lines high is due to the nature of the hardware. The outputs for this interface are “open-drain” drivers, which mean that it can drive its output low but not high. For that reason, one generally ties the outputs to V_{CC} via a resistor for a normally “high” output.

Our reasoning for requiring a two-wire interface setup was based on the fact that we have more than 4 devices on the network communicating via I²C and since their addressing won't allow for more than 2 bit addresses, we needed to split them onto separate busses. As our chosen microcontroller has only 1 I²C port, it needed a Two Wire Interface programmed in. The figure below illustrates the program flow needed for a two-wire interface to emulate the I²C setup.

Figure 4.29 - Program Flow for a Two-Wire interface [14]





Figure 4.30 - Illustration of the hardware setup needed for a two-wire interface.




4.3 FPGA

We chose to use an FPGA as part of the design due to the flexibility it adds to the system. We implemented a microcontroller on the FPGA in this case. The basis behind this decision was how the device actually executes code; it executes all lines of code at the exact same time, therefore our response time for our motors can be quite fast. Also our chosen FPGA is clocked at 50MHz which gave us ample leg room in terms of how much data we actually process; thus we can implement filters to avoid collecting erroneous data. The operations of our FPGA include sensing analog pulse width modulated signals and translating the information into digital values. This process does not include a hardware based digital to analog converter; it has been all implemented in code. The FPGA also muxes the digital value from the pulse width modulated signal with a similar value sent by the on-board intelligence. This number is in the same format as the converted PWM signal. This muxed number is an 8 bit number that relates the spread of numbers between 0x00 to 0xFF to the spread of pulse widths between 1ms and 2ms. The 1ms to 2ms pulse width is based on the standard servo PWM format and is generally what motor drivers expect to receive. A pulse width of 1.5ms (or 0x80 in digital) represents the state at which the motors are idle. The state to indicate full-forward is a pulse width of 2ms (or 0xFF in digital), while the state to indicate full-reverse is a pulse width of 1ms (or 0x00 in digital). As we chose to use Xilinx's Spartan3E (XC3S500E) for the project, the FPGA will henceforth be referred to as the Spartan3E.

4.3.1 PCB Design for the FPGA

The Spartan 3E was not in Eagle's standard library, nor was it in SparkFun's parts library, thus we had to generate our own part for it. Its package name was the FGG320, which follows the ball grid array format, with a total of 320 pads. This package's footprint follows the footprint of a square with sides of 19mm in length and has pads throughout the bottom of the chip spaced exactly 1mm from each other horizontally and vertically.

Figure 4.31 - Footprint of the Xilinx Spartan3E



4.3.2 Implementation of Asynchronous Serial

Computers, microprocessors, microcontrollers and FPGAs generally use a more common form of serial communication derived from the RS-232 standard. This derivation generally uses the Rx and Tx lines with a ground wire so that the transmitters and receivers can share the same ground reference. Common baud rates used in the serial communication are 9600, 19200, 38400, 57600, and 115200, we have used 9600 as our chosen rate as we didn't need to query our vitals too much. By requesting data too much we might introduce too many points to process and thus any "noise" or unwanted signals could be interpreted as real data and thus generate false data.

The basis behind asynchronous serial is to have a start byte sequence that has to be recognized by the receiver in order to accept it as a valid packet. We chose to use asynchronous serial as it greatly simplified the design of the system and thus did not require additional hardware implementation on the FPGA. Valid signals for the derived RS-232 protocols can go up to 25V therefore the challenge of using serial communication on an FPGA was to be able to accept such signals without damaging the internal circuitry. This was achieved by using a MAX232 which is a TTL converter. This chip took the regular serial lines and converted them to levels that were safe for the FPGA.

To illustrate how this communication works, assuming that our start byte sequence is a "#%" in ASCII followed by a byte that defines what port (this can be seen in Table 4.5). Our definition of "port" refers to devices attached to the receiver; in the case of the FPGA, ports will be assigned to indicator LEDs, PWM outputs, PWM inputs, microcontrollers and the like. The next set of data after the port was the load, which for us indicated what function, will be performed at that previously defined port. This data load consisted of 4 bytes. The last two bytes were a stop byte followed by a check sum. A valid packet will begin with the "#%" sequence and end with a checksum that correctly represents the sent data. The following diagram illustrates our chosen communication format with odd parity. The checksum basically adds Start0 + Start1 + Data0 + Data1 + Data2 + Data3 + Stop and if both the transmitter and the receiver have the same checksum then the data transmitted was considered to be the intended data.

Table 4.5 - Illustration of the data sent for a given packet

Sent Data	#	%	Data0	Data1	Data2	Data3	Byte
Description	Start0	Start1	Port No.	Load0	Load1	Load3	Stop


4.3.2.1 Oversampling for the Receiver

In order to process the bytes mentioned above, that belong to a single packet, we have to backtrack a little and discuss our method of obtaining a single byte. A given byte consists of a start bit, stop bit, parity bit and load, which is the actual information being transmitted. As the UART was used to emulate it does not receive any clock information via the Rx lines, it synchronizes itself using pre-programmed designators to receive these bits. As the FPGA has a much faster clock rate than the rate at

which the data is coming in, we did not need to use a FIFO (First-In-First-Out) buffer to prevent data overrun as the data will always be processed much faster than the data coming in. We utilized a method known as oversampling to achieve this UART configuration. The most common rate of oversampling is 16 times the baud rate which literally translates to sampling a given bit 16 times. Once the receiving line goes low (or the equivalent of '0'), the sampling counter begins counting, assuming a rate 16 times the baud rate, once the counter reaches 7, we have reached the middle of the start bit and therefore read in the value, reset the counter and start the counter over. However as we needed to progress through the rest of the start bit, we had to count twice as much to get to the middle of the second bit which for all intents and purposes was our first data bit. This means that only when the counter reached 15 did we shift the data into the receiving register and reset the counter. This is illustrated in Figure 4.32. The process of counting 15 and shifting the data into the register was repeated based on the number of data bits being received along with the stop bit plus an extra cycle to accommodate the odd parity check.

With the implementation of the sampling rate, it functioned as a clock signal that was triggered on the rising edge of the FPGA's crystal clock. Using this method meant the receiver had no idea about the exact start of any bit being transferred. Therefore, it can only vary from the midpoint of a given bit by 0.0625 of its pulse width. If the number of samples were to be increased the error would decrease as a factor of its inverse. However, there is a limit to the number of samples that can be taken. If the sample rate is too close the clock rate of the FPGA (or any given processor) the data could be corrupted as the probability of a data overflow increases drastically. Thus, we made sure the sampling rate remains a small fraction of the clock rate.

Figure 4.32 - Sampling the data stream from the receiver



4.3.2.2 Baud Rate Generator

The baud rate generator created a signal that coordinates the transmission and reception of data by the UART on the receiving end. To facilitate flawless operation we generated a sampling frequency of at least 16 times the baud rate. Thus, any increase in the sampling rate would increase as a factor of 2^x as seen in Equation 4.5.

Equation 4.5 - Number of Samples
 $Number\ of\ Samples = 2^x = N$

where x equals an integer that is solved for a given N


The reason behind oversampling was that ideally one would hope to read the stop bit at the center of the pulse to synchronize the receiver with the incoming stream. This was accomplished by sampling on the 8th clock tick of the 16 clock ticks (if the sampling rate is 16 times the baud rate) assigned to one sample of the incoming stream(Figure 4.33), and then wait 16 counts more before reading the next bit. In this case, the USB-to-Serial converter along with the computer was set to transmit with a baud rate of 9600. Therefore, that is what we emulated on the FPGA. Equation 4.6 explains how the oversampling frequency was determined.

Equation 4.6 - Sampling per clock pulse
$$Sampling\ per\ clock\ pulse = \frac{CLK\ Rate}{32 * Baud\ Rate}$$

$$Sampling\ per\ clock\ pulse = \frac{50,000,000\ Hz}{32 * 9600} = 162.76 \approx 163\ samples$$

In a perfect setup where the data stream is completely in sync with the receiver, this oversampling would not be necessary but here the sampling clock is set to 32 times the baud rate to provide more of a buffer. Hence, with this setup we read the pulse at the 16th clock tick and waited 32 clock ticks more before reading in the next data bit.

Figure 4.33 - Flow for data on the receiving UART at 16 times the baud rate




The transmitting component of the UART is very similar to the receiving component. A hardware based UART transmitter generally reads in from the FIFO buffer while the receiving part writes to it, but as we did not need to implement the FIFO buffer, this did not apply to the design. Also there was no need to have the baud rate generator work 16 times as fast as the baud rate during transmission; as it did not need to synchronize anything while sending out information. The general practice in hardware however is to use the same baud rate generator as the receiver to save space and cost on the UART and simply have the transmitter count the rising edges of baud rate generator and send out data for every 16 rising edges it detects.

The flowchart for the transmitter is almost identical to the receiver in that after the Tx_Start flag goes high, it gets out of its idle state and loads the data to be transmitted and sends the data out bit by bit starting with the start bit, the data bits and finally the stop bit with a parity check.

4.4 Communication

The XBee modules required were very temperamental with respects to voltage needs. This particular XBee module requires 3.3V. Figure 4.34 shows how we meet the XBee's required input voltage and reduced any noise from going into the circuit simultaneously.

Figure 4.34 - XBee wireless schematic




4.5 Sensors

4.5.1 Temperature

4.5.1.1 Maxim's DS18S20

The DS18S20 temperature sensor(s) were placed in the MAIN box and the MOTOR box. The circuit used a one wire interface to connect with the microcontroller (refer to Figure 4.35).

Figure 4.35 – DS18S20 temperature sensor schematic



The DS18S20 has a unique 64-bit address that allowed for multiple devices to connect with our microcontroller. Should we have opted to use the TMP100 we would have been restricted to eight devices. In addition these would have had to be addressed on a single I2C interface. The pin logic levels and the addresses required for identification by the I2C bus are described in Table 4.6.

Table 4.6 - Address pins and slave addresses for the TMP100

ADD1	ADD0	SLAVE ADDRESS
0	0	1001000
0	Float	1001001
0	1	1001010
1	0	1001100
1	Float	1001101
1	1	1001110
Float	0	1001011
Float	1	1001111

Courtesy of Texas Instruments


4.5.1.2 Thermistor

The thermistor will run from the MOTOR box to the MAIN box where it will connect and complete a wheat stone bridge. Figure 4.36 shows how the nonlinear characteristics of a thermistor can be modified with basic hardware to have a more linear characteristic, for inclusion into our design.

The design of the thermistor is based on the wheat stone bridge circuit. The advantages of implementing the wheat stone bridge come from its flexibility to resist negative effects that could be caused from small voltage fluctuations into the circuit. To design the wheat stone bridge accurately the natural characteristics of the thermistor selected had to be taken into consideration. For the U.S sensor corporation type J thermistor that we selected, we had to ensure that the maximum power dissipation of $200\mu\text{A}$ was not exceeded in the worst case scenario. To meet this requirement we referenced the temperature table at 100°C and found that the thermistor has a 678.6Ω resistance. By including a $25k\ \Omega$ resistor in the first leg of the wheat stone bridge we assure that our thermistor does not self-heat and hence skew the temperature measurement. The second leg of the wheat stone bridge was designed to satisfy the wheat stones balanced leg requirement. The voltage obtained between the two legs now provides a stable voltage differential that can be fed to the microcontroller. This allows the voltage to reference our circuit instead of ground.

The measurement range for our circuit is from 0°C to 100°C with an accuracy of 0.1°C . We therefore need to be able to measure a1000 points throughout the range of measurement. The wheat stone bridge circuit will provide an analog voltage between 0v and 2.5v , which defines our differential voltage parameter. The A2D converter is a 12 bit converter with an internal voltage reference of 2.5 volts . This indicates that the A2D converter is capable of distinguishing a voltage differential of $.6\text{mv}$. This is 4 times more accurate than we require.

Figure 4.36 - Thermistor temperature sensor schematic



4.5.2 Light

The light sensor assembly shall consist of a square box with a lid on top of it. The light sensor assembly shall consist of a waterproof square box with a lid placed on top of it. The waterproof box assembly shall have four light sensors placed one on each side of the box, excluding the top and bottom. A port shall be drilled in a box at the location of each of the sensors. In this port, a transparent disc shall be embedded in a sealed fashion to maintain the waterproofing of the assembly. The light sensors shall be mounted behind the transparent disc. A cable array consisting of four pairs of data lines and a pair consisting of ground and VDD, shall be routed through the bottom of the box within the post supporting a box above the ASV. The entire assembly shall be maintained watertight due to the marine environment in which it will be operating. The light sensor uses an I2C bus to communicate with the microprocessor. Each device on the I2C bus requires an address, and the address for the light sensor is fixed. This poses a small problem for the design which can be overcome with the use of a multiplexer. The Texas Instruments PCA9545A 4-channel I2C and SMBUS switch was chosen as the multiplexer. It was designed for this exact purpose. The multiplexer uses the SDA and SDL signals that are used as control lines for the I2C bus as the throughput lines for the multiplexer. The signals control both the multiplexer and the light sensors, depending on the address that is sent. By addressing the multiplexer in selecting a single light sensor, each light sensor can be controlled one at a time. The multiplexer even has the ability to select multiple outputs at the same time, but we do not foresee using this ability except to possibly initialize all the light sensors at the same time. The only purpose of light sensor is to read Lux values. Only one light sensor can be read at a time, and this will be accomplished in a round robin fashion.


4.6 Dynamic Fan Control

We chose to use the simple method of using the microcontroller to control a FET driver which in turn drives a FET to control the DC power to the fan. By choosing this design, we simplify a lot of the design and reduce the footprint on the PCB. By picking the simplest design we can eliminate many chances for failure. Also by not going with the buck-boost regulator for fan power we can reduce our power usage. If at any given time our batteries were to drop to 20V, at 100% duty cycle, the max the fan can get is 20V, we chose not to provide a higher voltage thus we won't allow the fan to use up more power if the batteries are losing voltage. In this case we will prioritize the power going to the computer, microcontrollers and FPGA over the fan. In the event that the vehicle should reach a critical temperature in which the overall efficiency begins to drop, we will force the vehicle to push on and risk running out of battery. This will be harmful for the batteries but during competition, completion of the course takes precedence over anything else.

4.7 Displays

In section Figure 4.37 we have discussed the displays in detail. We have compared different technologies, their advantages and disadvantages. As a result we have chosen a display which is shown in Figure 3.31. We have mentioned that we would like to have a single pole six through switch, which we will use to toggle between the information that will be displayed. Also we have mentioned that we would like to have a SP3T switch, which we will use to turn on the display and the backlight, or both of them simultaneously. We have combined all these specifications into a design which is shown in Figure 4.37. As can be seen from the figure we are going to have a simple voltage divider circuit to control the SP6T switch. A 5V voltage source is connected to the switch. Each through of the switch will create a voltage divider circuit. The microcontroller will read a unique voltage value for each position of the switch. We will decide the voltage values for each switch position, use appropriate resistors to achieve those voltages, and according to that information program the microcontroller.

Figure 4.37 - Display, Switch, Microcontroller Connection



5. Building / Test Procedure

Overall building and testing will involve multiple steps. There will be some lab testing of the individual components and systems as well as PCB testing to ensure the PCB is working correctly. This means that we will not be populating the board all at once but in steps to ensure that each component added is working as predicted before adding the more sensitive components and devices that we do not want to damage should there be a malfunction.

5.1 Power

5.1.1 Emergency Stop

We have discussed a few emergency stop circuits. The design that we have decided to implement is given in Figure 4.1. We previously named this design the “Passive E-Stop design”, meaning we don’t have any logic components in this circuit. This circuit can be easily constructed in our work station and tested. The circuit will be built as described in the figure. We will use the resistors and relays available to us to realize this circuit. In addition we will connect a few parallel relay coils as shown in Figure 4.8. This way we will be able to ensure that our source can provide required current for each additional relay coil. Of course, the number of relay coils must be kept reasonable. According to our specifications we shouldn’t have more than 5 external relays. During the testing procedure some of the functional features that must be verified include the “Set” and “Reset” buttons, the Pololu RC Switch, and the LED lights. We have to ensure that our buttons set and reset the system as intended, and the associated red and green LED lights turn on and off, depending on the system state. We will also use the remote control to test whether the Pololu switch disables the E-Stop circuit. These steps can be easily accomplished once the circuit is built.

5.1.2 Reverse Polarity

The reverse polarity circuit that we intend to implement is fairly simple and can easily be tested in the laboratory. Please refer to Figure 3.4 for this design. We will build this circuit using available fuses and diodes. However, we have to note that we are not going to intentionally connect the battery with the wrong polarity, since we don’t want to damage anything. Our design has been around for a long time, and has proven as a reliable Reverse Polarity Protection circuit. In our design it will be extremely rare that the circuit is reverse biased, since we are using DIN and MOLEX connectors. There’s really one situation where reverse polarity would be activated; when the probes are shorted.

5.1.3 Hot Swapping

Our “Hot Swapping” circuit schematic, which is shown in Figure 4.11, was implemented last year and we know that it works. We still will use available components in the laboratory to build and retest this circuit, just to be confident that everything is working as expected.

5.1.4 Voltage Regulators


Our choice of voltage regulators was based on the criteria that they are efficient, low cost, and small PCB size. Other factors include having the FETs internal to the regulator and minimal external components. Our regulators meet these criteria we found that most the regulators all required about 8 external components which are

mostly capacitors, resistors, and one inductor and diode. From this it was easy to test, evaluate, and design our PCB.

5.1.4.1 5 and 8 Volt Regulator


Our five and eight volt regulator is the LM2676 which is capable of delivering 3 amps of total output current. We were easily able to test this regulators performance on the workbench using a DC power supply and the various external components required. WEBENCH provided us with a BOM which specifies the exact parts to buy. We first built the 5V circuit as seen in Figure 5.1 with the input voltage on VIN and monitoring the output with a volt meter on 5VREG. This configuration was for the fixed voltage of 5V DC output so we made sure that we indeed saw 5V and didn't need to reconfigure to be adjustable. We then loaded the circuit with 1 amp and tested its output voltage and ripple as well as tested it with a 3 amp load using power load resistors capable of handling 20 watts. Once this was verified we were able to place the part on the PCB and redo the testing to ensure the regulator was working properly. We also checked that the output voltage ripple was where we expected to verify the circuit was not too noisy.

Figure 5.1 - 5V LM2676 Eagle Schematic



Once we had verified the 5V regulator was working correctly on the workbench, we modified the circuit to accommodate for the extra components for 8V regulation as seen in Figure 5.2. By adding the two extra resistors, R15 and R16, we were able to modify the regulation point by adjusting the feedback. Again we verified the regulation point and determined if adjustments needed to be made to keep the regulated voltage at 8V DC. We then loaded the regulator to test the regulator at 0.5 amp, 1 amp, and 1.5 amps. This verified the output remained at 8V over the load range and also verified the regulator would operate as expected. Once our checks were complete we soldered the components on the PCB. Because the devices connected here are connected some distance away we later verified that at the devices there was no significant voltage loss and if so we adjusted the resistors to ensure the voltage was correct at the devices.


Figure 5.2 - 8V LM2676 Eagle Schematic



5.1.4.2 12 Volt Regulator

The 12V regulator, a LM22677, is similar to the 5 and 8 volt regulator but is not the same part. The package is a little different but will still work. This regulator has the ability to change its frequency of operation by attaching a resistor from RT/SYNC to ground. This regulator was designed to handle our LIDAR(s) which are very sensitive to power fluctuation. Again we used a DC supply with a volt meter and oscilloscope to evaluate the performance of the power IC. It was critical that we tested this device to ensure the proper voltage is outputted and adjusted it to verify the devices were receiving adequate power. WEBENCH has provided us with what it thought were the proper values. We verified these before placing the device on the PCB. The output ripple on the device was another important evaluation point that must remain in within the limits of our devices. Figure 5.3 shows the schematic layout in Eagle as recommended by the datasheet.

Figure 5.3 - 12V LM22677 Eagle Schematic



5.1.5 Voltage Sensing

Due to the simplicity of the circuit we didn't see any reason to prototype the entire design on a breadboard before implementing it on the PCB. The first thing we did was characterizing the zener diode to ensure that the knee of the zener broke down when we were expecting it to. When on the PCB, we individually applied a voltage from a constant DC voltage supply source to the 3 voltage source inputs


respectively. We also applied a voltage meter to the input to ensure accuracy. Using the test point on the output of the voltage divider we adjusted the potentiometer so that the output voltage after scaling didn't exceed 4.7V DC. This also accounted for any losses in the board as well as the voltage drop across the diode. Once adjusted, we recorded the scaling factor so that software could scale the ADC value back up to the actual value. Next we increased the voltage source so that the output tried to read above 5V and determine if the zener diode was correctly sinking the excess current to ground as expected from earlier testing with the zener diode.

5.1.6 Current Sensing

This testing required two tests because the vehicle uses two methods of current sensing. The first method was using the MAX9920 IC followed by the Closed Loop Hall Effect LEM LTS 15-NP.

MAX9920: This device is difficult to test outside a PCB due to the lack of good Kelvin contacts. This means that even if we used the proper sense resistor the wire/leads from the sense resistor to the IC the resistance in the wires would alter the results of the test. Even so we tried our best to use as short of leads as possible when testing. This device has an exposed pad that should be connected to the ground plane for proper thermal and electrical performance. When testing we didn't have this so it was important not to push the part to its limits. For this test we used two DC power sources set to 5V for the IC and 20V for the test source. With their grounds tied together for common grounding. We tested with various loads up to 1.5 amps using power resistors capable of handling this current. The IC's VCC was connected to the 5V supply. Shutdown, ground, and reference voltage in were all connected to ground so that the circuit was active and sensed in the unidirectional forward current range. The sense resistor went across Rsense+ and Rsense- with the input voltage on the positive side and the load on the negative side. The out pin was connected to the feedback pin through R2 and the feedback pin was connected to the voltage reference pin through R1. The out pin was also connected to a voltage meter to view the output. We tested the part with an output current of 1 amp that caused a voltage drop across a 0.005ohm resistor to equal 0.005V. Using Equation 4.2 we used a gain of 60 to determine the proper R1 and R2 values which realized the ratio of R2/R1 to equal 239. Using 1% tolerance resistors with $R1 = 316\Omega$ and $R2 = 75k\Omega$ realized a gain of 59.585 which was close enough as the scaling in software took care of this. We then applied power and applied the load of 20Ω and got a current draw of 1 amp. To verify this we measured and recorded the voltage on the load divided it by its true resistance. Then we measured the output voltage from the IC and divided it by the gain and then divided it by the value of the sense resistor. For the PCB the resistors used needed to have very tight tolerance. This test was then performed on the actual PCB and again we recorded the scaling factors for the microcontroller to use later. Figure 5.4 shows the schematic layout of the MAX9920 with an input capacitor on the IC for a more stable input voltage.

Figure 5.4 - MAX9920 Schematic



LEM LTS 15-NP: This device is much easier to test than the MAX9920 because it has leads that wires can be connected to easily. We tested the device on the workbench using a DC power supply set at 5V DC for powering the device as well as the load. With no load on the device we saw the output of the device at 2.5V DC using a volt meter. Using Equation 4.3 we tested the device at various currents using a power resistor as a load. From this determined the output of the device compared to the formula and adjusted as necessary. We then programmed the analog to digital converter with the appropriate scaling to realize the true current. The In and Out pins were not connected as the wire was soldered directly to the device. The input to the device has a capacitor for voltage filtering close to the sensor for a more stable output. The output of the device was then connected to the analog to digital converter.

5.2 Microcontroller

In order to affirm that we have a working microcontroller and FPGA we devised some procedures to ascertain that our signal processing components are functional according to our specifications.

5.2.1 Power and Signals

On the most basic level, we checked for shorts by using a digital voltmeter. This was accomplished by measuring the resistance across the V_{CC} and GND pins; this ensured that the value being read was not close to 0Ω . If it was, we looked around the board, preferably with a microscope and checked for unintended solder balls, or blots that may have formed during the microcontroller's installation. After this step cleared and the connection was not a short, the negative terminal was kept of the voltmeter on the GND channel and measured the resistance from V_{OUT} to ground. Again in this situation, if the voltmeter registered 0Ω then we had to check for

unwanted connections caused during installation. Another possibility for bad connections could stem from manufacturers defects, it was highly unlikely to encounter this if the board manufacturer was reputable and you've passed all the DRC checks during your PCB design. However, with there being a small chance, it was still a viable possibility. To fix an error caused by the manufacturer we had to cut the unintended connection with an "Exacto" knife. We had to exercise caution however, as we were using a four layer board; if we cut to deep we might sever other connections that didn't need any modification.

The next step to verify was to make sure all the outputs of the microcontroller were reaching their desired locations. We had to use the connectivity aspect of the multimeter to speed up the process as it provides an audible notification of connectivity. The connectivity check on the multimeter functions almost exactly like the resistance function but, the only difference is that if it detects resistance close to 0Ω it will automatically sound a buzzer, which in most cases will be a piezoelectric component.

By connecting each pin of the microcontroller with the positive terminal of the multimeter, and connecting the negative terminal to the destination of the signal, we should be able to assess if the board was made to specifications. In this situation, it was good to get an impedance of 0Ω as it indicated that the signal reached its destination without encountering much resistance. If we got a resistance in the 100Ω range that usually meant that there was a connection that wasn't completely sound and must have been reinforced with extra solder. This could be fixed easily if the connection to be mended was on either the top or bottom layer as those layers were the most accessible. To fix a bad connection broken within the internal layers involved running external wires across the board. This worked well for most applications; however, anytime a wire was used its inductance added the parasitic of the board itself.

Once all the signals and power pins were verified that they were connected properly, the part could then be turned on without fear of accidentally destroying the part. Once powered up, we had to change the multimeter's function over to measuring voltage and ensure that the microcontroller was getting 5V on its power (V_{CC}) pin with respect to ground. If this was not the case, if the voltage read up to 6.5V, this voltage wouldn't damage the microcontroller up it allowed us to investigate why the voltage being supplied was not the regulated 5V we wanted. Usually, there was a drop in voltage and thus in general, it would be okay to investigate the issue with the board powered on. The only thing to stress was to make sure that the multimeter never went into measuring resistance mode, as this could spell disaster for our parts and cause unnecessary shorting problems.

The next thing to check was to ensure that the reference voltage for the integrated ADCs was at 5V. If this value was off by more than 5%, it could skew our voltage readings. If this value was off by more than 5%, we had to check all the resistor values across the board to make sure they were within acceptable tolerances.

5.2.2 Software Check

The next section to check was the software side of the design. This encompassed the communication between the various components (this was different than the hardware based communication like the XBee, it was more of the software emulation of the communication standard). If needed, we intended on using the integrated ADCs should we require additional ports. Thus we needed to check their accuracy as well. This could be done by making one of the internal ADCs read the same voltage value as the hardware based ADC, once each voltage value was read and their difference was determined by the microcontroller, it adjusted its calculations to match the dedicated hardware-based ADC. This was done so that the measurements were uniform across all the ADCs in case we were in a situation that required us to use both the integrated and dedicated ADCs.

From the LCD aspect of software, the microcontroller sends a Ping message to the LCD's microcontroller and when the on-board chip replies with the "Pong" message, the microcontroller from the boat tells the remote chip to display the message "Connection Established" on the LCD Panel. In the event that this didn't occur, there may have been issues in the range of the wireless module we were using, we had to move the wireless box closer to the motherboard and re-try to procedure. Also there might be a possibility that our baud rate was set to a point at which the bandwidth was not enough to support all the data that needed to be transmitted. This could be seen if the connection established message appeared, but there were a lot of packets that kept getting dropped. This was fixed by altering the baud rate to something more tuned to our needs. We did not actually run into this situation as the data we intended on sending to the remote panel only consisted of simple text information. This sort of scenario could only be encountered if we were trying to send all our information from the microcontroller on the motherboard to the remote microcontroller. Another connection established was between the microcontrollers and the FPGA. This was attained using the ping-pong message as well. If the microcontroller sent the ping message, the FPGA responded with the Pong message. In this sense, the microcontroller was the component that assessed whether or not the communication between all the components was actually working. If this was not the case, then the microcontroller sent a message to the LCD panel to display which connection was broken, whether it was the FPGA, or the remote LCD panel. It was important to differentiate between the LCD panels here. There are two panels, one on the vehicle itself and the other in a remote box outside the vehicle, and the error messages were displayed on the vehicle's LCD panel. If the connection between the remote LCD panel and the microcontroller was established then the remote panel also displayed the error messages. Any test procedure relating to the wireless transmission was discussed in another section specifically designated for wireless communication to and from our vehicle.

5.3 Field Programmable Gate Array

5.3.1 Power and Signals

As we decided to use the Nexys2 evaluation board for the Xilinx FPGA we were programming, all we had to do was incorporate the 100 pin FX-2 connector on the motherboard and plug in the FPGA. Therefore our checks for this part consist mainly of tracing the connections from the FX-2 connector itself.

Our checks consisted of using a voltmeter to determine the resistance between the FX-2 connector from the motherboard to the FPGA. This was achieved by programming the FPGA to output a simple PWM output on the output pins and use an oscilloscope to read the FPGA output. This determined if the pins were connected properly. This was extremely important as there are 100 pins on this connector and making sure that the connections were made properly made our testing procedures much less complicated. This was confirmed in Eagle before we sent the board out for fabrication.

5.3.2 Software Check

Once that was complete, we established communication with the on-board computer. This was also accomplished via the ping-pong message. Here the computer initiated the message by sending the ping message and the FPGA responded with the Pong message. Once this handshake was completed the computer proceeded to send other commands anywhere ranging from requests to commands. The computer sent commands that inquired the status of an LED and or the status of a button, it also inquired if the vehicle's e-stop system had been triggered. On the other hand the computer may also ask the FPGA to turn on LEDs or override some button values with its own. Another command we could implement in the future could be to set the motor speed. All these commands must be handled by the FPGA. Successful communication can be seen if all of the LEDs status, motor values, and button positions are reported accurately. If this does not occur, the error lies in the fact that something during the handshake for each message was not being executed correctly. Also, another issue that we have run into in the past has included bad USB to serial converters. Where the converter had no issue send ping and pong messages, but once we requested larger amounts of data, it would refuse to send the packet and rather drop it.

5.4 Communication

5.4.1 Wireless Communication - XBee Test Procedure [5]

In order to perform the XBee range test the procedure was sub-divided into multiple sections. These sections encompassed the basic requirements needed, establishing a ZigBee network, defining the parameter settings, and how to perform a range test for the XBee modules.

5.4.1.1 Basic Requirements

As outlined in the XBee tutorial in order to perform a range test the following must first be satisfied and at your disposal

- One XBee-PRO USB RF Modem (Base unit that will connect to the host)
- One XBee-PRO RS-232 RF Modem (Remote unit)
- A computer running Windows 98 SE, 2000 or an XP environment
- Properly installed and configured X-CTU software
- Properly installed and configured USB drivers
- A Properly installed and configured ZigBee network.

5.4.1.2 Establishing a ZigBee Network

In order for communication between two modules to start, both modules must first recognize and be attached to a ZigBee network. This is accomplished by using the X-CTU software and following the procedures listed below

1. Select function set ZIGBEE COORDINATOR AT
2. Write Parameter and update firmware to one XBee Module
3. Select function set ZIGBEE ROUTER / END DEVICE AT
4. Write Parameter and update firmware to another one XBee
5. Go to Terminal, type in any word will transfer to the other wireless.

5.4.1.3 Parameter Settings

To insure both modules are sharing the same settings they must be matched in the XCTU program. The following items should be configured as described below.


1. ID - PAN ID, must be the same for both modules
2. DL - Destination Address Low
3. Coordinator set to FFFF (broadcast mode)
4. Router set to 0 (The default Address Low for Coordinator)
5. BD - Baud Rate set to 9600 for both XBee modules
6. Flow Control : NONE
7. Data Bits : 8
8. Parity : NONE
9. Stop Bits : 1

5.4.1.4 Range Test

1. Connect the BASE RF modem to the PC using a standard USB cable. Confirmation of a successful connection is depicted with the onset of a small red LED on the BASE RF modem.
2. Included in the Evaluation kit is a serial loopback adapter. This loopback adapter must be attached through the female DB-9 port of the REMOTE RF device.


3. Initiate power to both REMOTE and BASE devices. Power is to be provided to the REMOTE through its connector using a power adapter and the BASE is to receive power via its USB connection.
4. Start the X-CTU Software
5. The software installed contains four tabs across the top of the screen. These include “PC Settings”, “Range Test”, “Terminal”, and “Modem Configuration”. You will need to set the “PC Settings” of the X-CTU software to setup a PC Serial communication port for communications with the BASE RF modem. This is best done by: (refer to Figure 5.5 - X-CTU Program)

Figure 5.5 - X-CTU Program



6. We are now ready to initiate the range test. Click the “Range Test” tab on the top of the screen; refer to Figure 5.6.

Figure 5.6 - X-CTU Range Test



7. Use the "RSSI" (Range Signal Strength Indicator) checkbox to enable the display of the signal strength.
8. Click the "Start" button to begin the range test
9. The REMOTE will then be moved away from the BASE to an approximate distance of 912 feet, which will be displayed on the RSSI indicator box. The location of the range test has been predetermined to take place in the parking lot of the robotics lab.

5.5 Sensors

5.5.1 Temperature Sensor (1-COTS)

The testing of the Temperature Sensor was tested as a fully functional part at the ASV, as it was fully incorporated into the MAIN PCB.

5.5.1.1 Basic Test Equipment Requirements

In order to perform the various tests outlined below the following must first be satisfied and at your disposal

- ASV PCB board
- Multimeter
- Personal computer
- USB to I2C & SPI Converter and Analyzer
- Test lead assembly

5.5.1.2 Functionality Test Procedure

1. Visually inspect the ASV PCB assembly, checking for broken wires, incorrect connections or any other inconsistencies that might be obvious.
2. Verify that the ASV is in a power on state.
3. Using the onboard PC test routine, turn off all addresses using the I2C bus.
4. The remainder of this test procedure has to be completed two times, once for each temperature sensor on the PCB.
5. Using the multimeter, verify that the VSS (ground), VDD (+5.5VDC), SCL, and SDA lines have continuity between the ends of the leads and the corresponding pins on the temperature sensor IC.
6. Set the bus speed to 400kbit/s using the PC.
7. The I2C address for the temperature sensor is fixed between 0x90 and 0x9F (hexadecimal 90 and 9F). Two address pins set the difference in the addresses based on table 11 in the specifications sheet of the Texas Instruments TMP100. The first seven bits are used to address one of eight devices. The LSB is used to configure the device as READ or WRITE. The ASV will use addresses 0x90 for first device WRITE and 0x91 for the first device READ. The ASV will use addresses 0x93 for second device WRITE and 0x94 for the second device READ.
8. Send a90 to set the bus address to the first temperature sensor write mode. In the subsequent test for the other sensor, use a93 to select the second sensor for testing in write mode.
9. Send s 00 p. This sets the sensor to temperature mode.
10. Send a91 to set the bus address to the first temperature sensor read mode. It reads the MSB and LSB of the temperature and displays them on the terminal screen.
11. If there is a response from the temperature sensor it is working. If not, check VDD with a multimeter to verify that it is receiving +5.5VDC and VSS to verify it is connected to ground.
12. There are no user configurable calibrations to the temperature sensor. It is either working or it is not and has to be replaced.

5.5.2 Temperature Sensor (2-Thermistor)

The testing of the Temperature Sensor Thermistor shall be tested as a fully functional part at the ASV, as it is fully incorporated into the MAIN PCB. The Thermistor circuitry is connected to the I2C buss via a Texas Instruments ADS7828 A/D. Note that the thermistor was not implemented into our final design. Therefore, the final Basic Test Equipment Requirements and the Functionality Test Procedure can be skipped.

Basic Test Equipment Requirements

In order to perform the various tests outlined below the following must first be satisfied and at your disposal

- ASV PCB board
- Multimeter
- Personal computer
- USB to I2C & SPI Converter and Analyzer
- Test lead assembly

Functionality Test Procedure

1. Visually inspect the ASV PCB assembly, checking for broken wires, incorrect connections or any other inconsistencies that might be obvious.
2. Verify that the ASV is in a power on state.
3. Using the onboard PC test routine, turn off all addresses using the I2C bus.
4. Using the multimeter, verify that the VSS (ground) and VDD (+5.5VDC) lines on the Op Amp have continuity between the corresponding pins and the bus lines.
5. Using the multimeter, verify that the VSS (ground), VDD (+5.5VDC), SCL, and SDA lines have continuity between the ends of the leads and the corresponding pins on the A/D.
6. Set the bus speed to 400kbit/s using the PC.
7. The I2C address for the A/D is fixed between 0x90 and 0x9F (hexadecimal 90 and 9F). Two address pins set the difference in the addresses based on A0 and A1 as stated in the specifications sheet of the Texas Instruments ADS7828. The first seven bits are used to address one of eight devices. The LSB is used to configure the device as READ or WRITE. The ASV will use addresses 0x94 for device WRITE and 0x95 for the device READ.
8. Send a94 to set the bus address to the first temperature sensor write mode.
9. Send s 0C p. This sets the A/D command byte to use differential input on chan0 and chan1 with the A/D always on.
10. Send a95 to set the bus address to the A/D read mode. It reads the MSB and LSB of the A/D and displays them on the terminal screen.
11. If there is a response from the A/D it is working. If not, check VDD with a multimeter to verify that it is receiving +5.5VDC and VSS to verify it is connected to ground.
12. If the voltage to the A/D is correct troubleshooting will have to be done at the circuitry level to determine the fault condition.

5.5.3 Light

The testing of the light sensor will be completed in two parts. First, the light sensor assembly box shall be tested to verify functionality prior to installation. Second, the light sensor assembly shall be tested as a fully functional part at the ASV.

5.5.3.1 Basic Test Equipment Requirements

In order to perform the various tests outlined below the following must first be satisfied and at your disposal

- ASV PCB board
- Multimeter
- Personal computer
- Test lead assembly

5.5.3.2 Assembly Test Procedure

1. Visually inspect the light sensor assembly, checking for broken wires, incorrect connections or any other inconsistencies that might be obvious.
2. The remainder of this test procedure has to be completed four times, once for each light sensor in the assembly.
3. Using the multimeter, verify that the VSS (ground), VDD (+5.5VDC), SCL, and SDA lines have continuity between the ends of the leads and the corresponding pins on the light sensor IC.
4. Connect the test lead assembly to the VSS, VDD, SCL, and SDA lines. The maximum length of wire between the light sensor IC and the USB to I2C converter shall be no more than 0.5 m.
5. Plug the test lead assembly into the USB to I2C converter.
6. Connect the USB to I2C converter to the personal computer.
7. Run the ByVac terminal program.
8. Type t400000 on the terminal program to set the bus speed to 400kbit/s.
9. The I2C address for the light sensor is fixed at 0x39 (hexadecimal 39). The I2C address for the multiplexor is set to 0xE1 (hexadecimal E1) for read operations and 0xE0 (hexadecimal E0) for write operations. Since the light sensor address is the same for all of the devices, a multiplexor was used to select the data bus of the sensor of interest.
10. Type aE0 to set the bus address to the multiplexor to write mode.
11. Type s 1 to program the select line of the multiplexor to address the first light sensor. In subsequent tests for the other three sensors, use 2, 3 or 4 respectively to select the appropriate sensor for testing.
12. Type a39 to set the bus address to the light sensor.
13. Type s 00 03 43 g 83 g p. This is explained in the documentation of the NAO1302. It reads the MSB and LSB of the ambient light level and displays them on the terminal screen.

14. If there is a response from the light sensor it is working. If not, check VDD with a multimeter to verify that it is receiving +5.5VDC and VSS to verify it is connected to ground.
15. There are no user configurable calibrations to the light sensor. It is either working or it is not and has to be replaced.

5.5.3.3 Functionality Test Procedure

1. Visually inspect the ASV PCB assembly and light sensor assembly, checking for broken wires, incorrect connections or any other inconsistencies that might be obvious.
2. Verify that the ASV is in a power on state.
3. Using the onboard PC test routine, turn off all addresses using the I2C bus.
4. The remainder of this test procedure has to be completed four times, once for each light sensor in the assembly.
5. Using the multimeter, verify that the VSS (ground), VDD (+5.5VDC), SCL, and SDA lines have continuity between the ends of the leads and the corresponding pins on the light sensor IC.
6. Set the bus speed to 400kbit/s using the PC.
7. The I2C address for the light sensor is fixed at 0x39 (hexadecimal 39). The I2C address for the multiplexor is set to 0xE1 (hexadecimal E1) for read operations and 0xE0 (hexadecimal E0) for write operations. Since the light sensor address is the same for all of the devices, a multiplexor was used to select the data bus of the sensor of interest.
8. Send aE0 to set the bus address to the multiplexor to write mode.
9. Send s 1 to program the select line of the multiplexor to address the first light sensor. In subsequent tests for the other three sensors, use 2, 3 or 4 respectively to select the appropriate sensor for testing.
10. Send a39 to set the bus address to the light sensor.
11. Send s 00 03 43 g 83 g p. This is explained in the documentation of the NAO1302. It reads the MSB and LSB of the ambient light level and displays them on the terminal screen.
12. If there is a response from the light sensor it is working. If not, check VDD with a multimeter to verify that it is receiving +5.5VDC and VSS to verify it is connected to ground.
13. There are no user configurable calibrations to the light sensor. It is either working or it is not and has to be replaced.

5.6 Dynamic Fan Control

We have implemented a test mode for fan control, in which the microcontroller will temporarily be fed a string of numbers that represent temperature values. This string of numbers should make the microcontroller fluctuate the fan speed gradually across its whole spectrum. This indicates that the microcontroller is capable of adjusting the fan's pulse width modulation to regulate fan speed.

5.7 Displays

Our schematic for the switch that was used with the display is given in Figure 4.37. After we determined the unique voltage and resistor values that were associated with each throw of the switch, we programmed the microcontroller to understand these voltages. We then calculated the voltage increments between the switch throws. We have six switch positions, and 5V input voltage. Dividing 5V by 6 positions we got a linear increase of 0.8333 V between each throw. After the microcontroller was programmed to recognize the voltages, we tested our display and the switch. This proved to be very easy to accomplish.

6. User Manual

The following instructions already assume that the main electronics board has already had its connectors properly attached to it.

6.1 Turning On the ASV

6.1.1 Connect Batteries to the ASV


This process involves connecting batteries for Logic Power and Motor Power:

- 1) Acquire (1) 4-Cell Lithium Polymer Battery as seen in Figure 6.1 or (1) 6-Cell Lithium Polymer battery as seen in Figure 6.2 for Logic Power. Acquire (1) 6-Cell Lithium Polymer battery as seen in Figure 6.2 for Motor Power.

Figure 6.1 - 4 Cell Battery



Figure 6.2 - 6 Cell Battery




- 2) Test each battery to ensure they are fully charged using a Digital Multi-Meter:
 - a. The 4-Cell Lithium Polymer Battery should read greater than 16 VDC if fully charged. If the battery voltage reads less than 13 VDC then use a different battery and repeat this step.
 - b. The 6-Cell Lithium Polymer Battery should read greater than 25 VDC if fully charged. If the battery voltage reads less than 19.2 VDC then use a different battery and repeat this step.
- 3) Make sure that all switches on the outside of the main box are in the OFF position as seen in Figure 6.3.

Figure 6.3 - Box Switches



- 4) Make sure that the relay switch on the inside of the box as seen in Figure 6.4 is in the OFF position as seen on its label.

Figure 6.4 - Relay Switch




- 5) Plug the Logic Power Battery into the parallel board inside the ASV with the Dean Connector.
- 6) Plug the Motor Power Battery into the other Dean connector not part of the parallel board.

6.1.2 Connect Shore Power to the ASV

This process involves connecting the Shore Power Supply to the ASV.


- 1) Locate the RHINO Power Supply as seen in Figure 6.5.

Figure 6.5 - RHINO Shore Supply



- 2) Ensure that all connections on the RHINO Power Supply are secure.
- 3) Ensure that the output of the RHINO power supply is connected to the ASV shore power cable.
- 4) Make sure the breaker in Figure 6.5 and the inline switch in Figure 6.6 are in the OFF position.
- 5) Make sure that all switches on the outside of the main box are in the OFF (Down) position as seen in Figure 6.3.
- 6) Make sure that the relay switch on the inside of the box as seen in Figure 6.5 is in the OFF position.
- 7) Connect the ASV shore power cable to the ASV Main box and make sure it is secure as seen in Figure 6.6.
- 8) Connect the RHINO Power Supply to a 115 VAC wall outlet.

Figure 6.6 - Shore Power Cable



6.1.3 Powering On with Batteries

If you have not connected the batteries go to Section 6.1.1 and complete all steps before moving to the next step.

- 1) Locate the Main Relay switch as seen in Figure 6.4 in the Main Box and move it to the ON position.
- 2) Locate the Board Switch located on the outside of the main box as seen in Figure 6.3 and move it to the ON (Up) position.

6.1.4 Powering On with Shore Power

If you have not connected Shore Power go to Section 6.1.2 and complete all steps before moving to the next step.

- 1) Move the inline breaker as seen in Figure 6.5 to the ON position.
- 2) Move the inline switch to the ON position as seen in Figure 6.6.
 - a. The red light on the switch should appear.
- 3) Locate the Main Relay switch as seen in Figure 6.4 in the Main Box and move it to the ON position designated by its label.
- 4) Locate the Board Switch located on the outside of the main box as seen in Figure 6.3 and move it to the ON (Up) position.

6.2 Switching Between Power Sources

This process can only be performed given that batteries and shore power has been properly connected per Sections 6.1.1 and 6.1.2.

If the ASV is currently running on batteries:

- 1) Switch the inline breaker on the shore power cable as seen in Figure 6.5 into the ON position.
- 2) Switch the inline switch on the shore power cable as seen in Figure 6.6 into the ON position.

If the ASV is currently running on batteries:

- 1) Switch the inline switch on the shore power cable as seen in Figure 6.6 into the OFF position.
- 2) Switch the inline breaker on the shore power cable as seen in Figure 6.5 into the OFF position.

6.3 Monitoring ASV Vitals

This procedure describes how to use the onboard and remote LCD screens to view system vitals.

In order to continue, the ASV must be powered on and running on either Batteries or Shore Power. If not please refer to Section 6.1.

Each screen has a set of 4 buttons which are used to navigate and control the screen:

Power – Controls LCD Power and Backlight Power.

Misc – Used on certain screens to control functions on the screen.

UP – Moves the screen to the next screen

DOWN – Moves the screen to the previous screen.

6.3.1 Description of LCD Screens

Voltage/Current:

This screen displays the Voltage and Current for Logic Batteries, Shore Power, and Motor Batteries.

Power Consumption:

This screen displays the Power Consumption for Logic Batteries, Shore Power, and Motor Batteries.

Temperature/Humidity:

This screen displays the Board temperature (average of two board temp sensors), Motor Box temperature (temperature inside the motor box), and the Humidity inside the main box.

Runtime:

This screen displays the current Runtime of the ASV since the main board was turned on. The runtime can be reset via the Main Panel only.

Light Sensors:

This screen displays the light sensor data (Main Only) and the direction the light is coming from. It is in reference to the four navigational directions (Forward, Aft, Port, and Starboard)

Battery Status:


This screen, which is only on the Remote Box, displays the current voltage of the battery inside the Remote Box.

6.3.2 Using the On-Board LCD Screen

Figure 6.7 shows the LCD Screen on the outside of the Main Box which is used in the following instructions:

- 1) Close the Main Box.
- 2) Remove the LCD cover if the cover is present.
- 3) Press Power to switch between (LCD Power and Backlight ON) and (LCD Power and Backlight OFF)
- 4) Press UP to move to the next screen.
 - a. If you are on the last screen the UP button will not do anything.
- 5) Press DOWN to move to the previous screen.
 - a. If you are on the first screen the DOWN button will not do anything.
- 6) Press the Misc Button while on the "Runtime Counter" to reset the counter.

Figure 6.7 - Main LCD Screen



6.3.3 Using the Remote LCD Screen

Figure 6.8 shows the LCD Screen on the Remote Box which is used in the following instructions:

This procedure assumes that a fully charged 3 cell lithium polymer battery is installed.

The Misc Button is currently not being used on the Remote Box.

- 1) Turn on the box using the switch located on the outside of the box.
- 2) Press Power to switch between (LCD Power and Backlight ON) and (LCD Power and Backlight OFF)
- 3) Press UP to move to the next screen.
 - a. If you are on the last screen the UP button will not do anything.
- 4) Press DOWN to move to the previous screen.
 - a. If you are on the first screen the DOWN button will not do anything.
- 5) The Green LED indicator on the outside of the box acknowledges that packets are being received. If the light does not change states, this means that there is no wireless connection.

If no wireless connection is established:

- a. Turn the remote box OFF and then back ON.
 - b. Make sure you are at least five feet from the main box.
 - c. Go outside to reduce the amount of interference that may be caused by being indoors.
- 6) The Red LED indicates the battery status.
 - a. Solid = Good
 - b. Flashing = Needs to be replaced (contact engineering)
- 7) The ESTOP button is used to remotely active the Emergency Stop System. Assuming there is a valid wireless connection, holding this button down for more than 350ms will send a command to the main box to trigger the ESTOP system.

Figure 6.8 - Remote LCD Screen



6.4 Emergency Stop System

This procedure describes how to operate the Emergency Stop System on the ASV.

In order to continue, the ASV must be powered on and running on either Batteries or Shore Power. If not please refer to Section 6.1.

6.4.1 Connecting the ESTOP Circuit

In order to prepare the vehicle to enable the ESTOP circuit the following must be complete:

- 1) The operator must have the outside External ESTOP button connected via the back of the Main Box as shown in Figure 6.9.
- 2) The operator must have the FUTABA Transmitter as seen in Figure 6.10.

Figure 6.9 - External ESTOP Button



Figure 6.10 - FUTABA Transmitter



6.4.2 Resetting the ESTOP Circuit


- 1) Ensure Section 6.4.1 is complete.
- 2) Ensure the Motor Switch on the outside of the Main Box is in the ON (Up) position. (refer to Figure 6.3)
- 3) Turn on the FUTABA Transmitter by sliding the middle switch up as seen in Figure 6.10.
- 4) Ensure that Switch G is pointing toward you as seen in Figure 6.11.

Figure 6.11 - FUTABA ESTOP Switch



- 5) Check that the POLOLU RC Switch IC has a solid Red Light as seen in Figure 6.12.

Figure 6.12 - POLOLU RC Switch



- 6) Press and release the RESET Button on the outside of the Main Box as seen in Figure 6.13.

Figure 6.13 - RESET Button



6.4.3 Emergency Stopping the ESTOP Circuit

There are multiple ways to Emergency Stop the vehicle which include:

Method 1:

Press the RED button on the External ESTOP Box on the ASV as seen in Figure 6.9.

Method 2:

Press the ESTOP button located on the outside of the Main Box as seen in Figure 6.13.

Method 3:

Locate the Motor Switch on the outside of the Main Box and move it to the OFF position as seen in Figure 6.3.

Method 4:

With the FUTABA transmitter on, move Switch G away from you as seen in Figure 6.11.

Method 5:

With the Remote LCD Box on and Wireless Link Established, press and hold the ESTOP button for more than 350ms.

6.5 Computer Power

This process describes how to turn on and off the computer on the ASV.

In order to continue, the ASV must be running on either Batteries or Shore Power. If not please refer to Section 6.1.


- 1) To turn on the computer, locate the Computer switch on the outside of the Main Box and move to the ON position as seen in Figure 6.3.
 - a. Press the Power button located on the front of the computer.
- 2) To turn off the computer, power down the computer from LINUX
 - a. Turn the computer switch off on the outside of the Main Box as seen in Figure 6.3.

7. Explicit Design Summary

Figure 7.1 represents the overall ASV's integration. The center of the chart is where the flow of power, communication, and signals begin, starting with the Power PCB and moving outwards. The Power PCB is responsible for delivering power to the vehicles electrical systems. For a more detailed illustration of this section refer to A.2 Shore Power and A.3 Power Distribution. The Logic PCB is responsible for most of the integration concerning data input, which in this case can be either analog or digital. It houses an ATmega328p microcontroller from Atmel that acts as our main processing hub for a majority of our electronic sensory inputs. We also incorporated a Spartan 3E FPGA from Xilinx using Digilent's Nexys2 evaluation board to act as an information relay system between the microcontroller and the on-board artificial intelligence. For more details regarding the logic PCB refer to A.4 Logic Distribution. The emergency stop system was designed to disconnect power from the Power PCB section should any of the remote or on-board E-Stop buttons be triggered; this will cause any moving components of the vehicle to cease operations. This system is completely passive as we need it to be completely independent of the rest of the vehicle. According to the rules of the competition, we are not allowed to have a remote reset button to release the E-Stop, therefore the only button that is capable of bringing the power back online resides on the vehicle itself.

The display controlled via the microcontroller is the NHD-0420D3Z-FL-GVW-ND from Newhaven Display International. We chose this display due to its large 20x4 alphanumerical viewing area. It is the platform in which we display all the information being processed by the microcontroller. We display information including the ambient temperature/humidity, light detection, and current and voltage readings. The above mentioned sensors are displayed both on board and via remote. In order to display the ASV vitals via remote we have incorporated into our design ZigBee's XBee modules. The Xbee modules meet all our design specifications in addition to satisfying our 900 ft range requirement. The inclusion of the XBee modules into our design can be further explained in Figure 4.34.

Figure 7.1 - System Overview



8. Bibliography


- [1] ARC Electronics, "RS232 Data Interface, a Tutorial on Data Interface and cables," 2010, <http://www.arcelect.com/rs232.htm>
- [2] B. Mitchell, "Wireless Standards - 802.11b 802.11a 802.11g and 802.11n, The 802.11 family explained," 2010, <http://compnetworking.about.com/cs/wireless80211/a/aa80211standard.htm>
- [3] Brian Perrett, "Reverse Polarity Protection", 2007 – 2010, <http://highfields-arc.6te.net/constructors/other/revpolepro.htm>
- [4] Britannica.com, "Liquid Crystal Display", 2010, <http://www.britannica.com/EBchecked/topic/343093/liquid-crystal-display>
- [5] C. Diamond, "ZigBee," 2005, <http://homepage.uab.edu/cdiamond/>
- [6] "Compare with Other Technologies." Get Technical. 6 April 2010. Bluetooth 2, October 2010. <http://www.bluetooth.com/English/Technology/Works/Pages/Compare.aspx>
- [7] Digi Making Wireless M2M Easy, "ZigBee Wireless Standard," 2010, <http://www.digi.com/technology/rf-articles/wireless-zigbee.jsp>
- [8] EHow.com, "LED vs. LCD Displays", 1999-2010 http://www.ehow.com/facts_5839894_led-vs_-lcd-displays.html
- [9] Extreme Electronics, "Using the USART of AVR microcontrollers," 2008. <http://extremeelectronics.co.in/avr-tutorials/rs232-communication-the-level-conversion/>
- [10] F. Durda, "Serial and UART Tutorial," 2010, <http://www.freebsd.org/doc/en/articles/serial-uart/>
- [11] Globalspec.com, "Liquid Crystal Display (LCD) Modules Specifications", 1999-2010 http://www.globalspec.com/Specifications/Video_Imaging_Equipment/Meters_Readouts_Indicators/Liquid_Crystal_Display_LCD_Modules
- [12] Honeywell, "Chapter 2 Hall Effect Sensors," <http://content.honeywell.com/sensing/prodinfo/solidstate/technical/chapter2.pdf>
- [13] IDC Technologies, "Industrial Data Communications –RS-232/RS-485," 2010, http://www.idconline.com/technical_references/tutorials/data_communications/tutorial_2.pdf
- [14] Intersil Corporation. (2010, November 13th) Single Digitally Controlled Potentiometer (XDCP). [Online]. Available: <http://www.intersil.com/data/fn/fn8197.pdf>
- [15] J. Starck. *Lessons in Electric Circuits – Volume II*. 2007. [E-book] Available: http://www.ibiblio.org/kuphaldt/electricCircuits/AC/AC_12.html
- [16] J. Sunshine, "What is RS-485," 1 September 2010, <http://www.wisegeek.com/what-is-rs-485.htm>
- [17] Jim, "High Current DC Switch", 2010 http://www.w6pql.com/high_current_solid-state_dc_switch.htm
- [18] LEM, "Current Transducer LAH 25-NP," <http://www.lem.com/docs/products/lah%2025-np%20e.pdf>

- [19] LEM, "Current Transducer LTS 15-NP,"
<http://www.lem.com/docs/products/lts%2015-np%20e.pdf>
- [20] Linear Technology, "Current Sense Circuit Collection,"
http://www.linear.com/ad/01-current_sense_basics.pdf
- [21] Linear Technology, "High Voltage I2C Current and Voltage Monitor," 2008,
<http://cds.linear.com/docs/Datasheet/4151fb.pdf>
- [22] Linx Technologies Wireless Made Simple, "OEM Long Range Handheld Data Guide Description," Linx Technologies Inc, 2008.
<http://www.linxtechnologies.com/Products/OEM-Products/Long-Range-Handheld-Transmitter/>
- [23] MaxAmps, "Lithium Polymer Charging/Discharging & Safety Information,"
<http://www.maxamps.com/lipo-care.php>
- [24] Maxim-IC. (2010, November 13th) Controlling a Variable Voltage Power Supply Using the DS1809 (Pushbutton Control). [Online]. Available:
<http://pdfserv.maxim-ic.com/en/an/AN183.pdf>
- [25] Maxim-IC, "-20V to +75V Input Range, Precision Uni-/Bidirectional, Current-Sense Amplifiers," 2010,
<http://datasheets.maxim-ic.com/en/ds/MAX9918-MAX9920.pdf>
- [26] Maxim-IC, "Linear Regulators in Portable Applications," 2002,
<http://www.maxim-ic.com/app-notes/index.mvp/id/751>
- [27] Maxim-IC, "High-Side Current-Sense Measurement: Circuits and Principles," 2001
<http://www.maxim-ic.com/app-notes/index.mvp/id/746>
- [28] Micrel. (2010, November 13th) Fan Management IC. [Online]. Available:
http://www.micrel.com/_PDF/mic502.pdf
- [29] Microchip Technology, "Single Supply Temperature Sensing with Thermocouples," 2002,
<http://www.jimfranklin.info/microchipdatasheets/00684a.pdf>
- [30] National Instruments, "How to Choose the Right Relay", 2010,
<http://zone.ni.com/devzone/cda/tut/p/id/2774>
- [31] National Semiconductor, "Linear Regulators: Theory of Operation and Compensation," 2000,
<http://www.national.com/an/AN/AN-1148.pdf>
- [32] National Semiconductor, "Switching Regulators,"
<http://www.national.com/appinfo/power/files/f5.pdf>
- [33] NXP Semiconductors, UM10204, I2C-bus specification and user manual, NXP Semiconductors, 2007.
http://www.nxp.com/documents/user_manual/UM10204.pdf
- [34] P. Emerald, "Non-Intrusive Hall-Effect Current-Sensing Techniques," 1998,
<http://www.allegromicro.com/en/Products/Design/non-intrusive-current-sensing/>
- [35] P. Kallstrom. (2010, November 13th) Field Programmable Gate Array Logic Cell. [Online].
Available: http://en.wikipedia.org/wiki/File:FPGA_cell_example.png
- [36] Plc.cwru.edu, "Super Twisted Nematic Displays", 2010,
<http://plc.cwru.edu/tutorial/enhanced/files/lcd/stn/stn.htm>


- [37] Pololu Corporation, "Pololu RC Switch with Digital Output", 2010,
<http://www.pololu.com/catalog/product/752>
- [38] R. G. Keen, "Advanced Power Switching and Polarity Protection for Effects", 1999,
http://www.geofex.com/Article_Folders/mosswitch/mosswitch.htm
- [39] RTI Electronics Inc, "Standard PTC Thermistors,"
<http://www.rtie.com/ptc/ptcindex.htm>
- [40] Tamura Corporation of America, "Current Sensor Information Page,"
<http://www.tamuracorp.com/clientuploads/pdfs/pg76.pdf>
- [41] Tamura Corporation of America, "Current Sensors", 2009,
http://www.tamuracorp.com/clientuploads/TCA-Current_Sensor_Data-REV-E.PDF
- [42] Techradar.com, "Everything you ever wanted to know about LCD monitors", 2006-2010,
http://www.techradar.com/news/computing-components/peripherals/everything-you-ever-wanted-to-know-about-lcd-monitors-511475?artc_pg=2
- [43] Texas Instruments, "6-A, Wide-Input Adjustable Switching Regulator," 2008,
<http://focus.ti.com/lit/ds/symlink/ptn78020w.pdf>
- [44] Texas Instruments, "Traditional High Side Current Sensing,"
<http://focus.ti.com/analog/docs/microsite.tsp?sectionId=560&tabId=2182µsiteId=7>

A System Diagrams


A.1 PCB Layout




A.2 Shore Power



A.3 Power Distribution




A.4 Logic Distribution



B Timeline

Senior Design 1 - Timeline
Fall - 2010



C Copyrights

Maxim IC:

```
=====
| Staff Comment                                2010-12-01 12:20:43 PST
| By: Moe R
|
| My apologies for the delay in answering.
|
| Thanks for asking. Yes, you may use the material from the website.
| Please complete the attached form and return via scan-and-e-mail,
| mail, or fax, as instructed on the form. Please attribute the quoted
| material with: "Copyright Maxim Integrated Products
| (http://www.maxim-ic.com). Used by permission."
|
| You may use the material as soon as you send the form (you do not have
| to wait for reply).
|
|=====
```

Tamura: Pending

Terms of Use Request

Michael Podel [mpodel88@gmail.com]

Sent: Fri 11/26/2010 3:59 PM

To: info-uk@tamura-europe.co.uk

Cc: mpodel88@gmail.com

To whom this may concern,

I am a student at the University of Central Florida in Orlando, Florida and we are writing a paper for our senior design project in which I will would like to use pictures of parts from their respective datasheets. To not infringe on your companies privacy policy I am writing to ask for permission to use pictures from the website/datasheets in our project.

Thank You,
Michael Podel

National Semiconductor Devices:

Permission to reprint.

Trevino, Diane [Diane.Trevino@nsc.com]

Sent: Tue 11/23/2010 1:07 PM

To: Michael Podel

Hello Michael, Sorry this was stuck in my drafts.
You have permission to reprint as shown below:

Date: November 10, 2010

From: National Semiconductor Corporation

Thank you for your interest in National Semiconductor.

Allegro MicroSystems:**RE: Privacy Policy - Using pictures from datasheet in report**

Fennelly, Stephanie [SFennelly@ALLEGROMICRO.com]

Sent: Tue 11/16/2010 8:27 AM

To: Michael Podel

Hi Michael,

Thank you for the clarification – we've approved your request to use our graphics provided you do reference Allegro MicroSystems, Inc. in your paper.

Best of luck with your project,
Stephanie**Stephanie A. Fennelly | Director, Marketing Communications**
Allegro MicroSystems, Inc. | 115 Northeast Cutoff | Worcester, MA 01606
T 508.854.5363 | F 508.853.7895 | E stfennelly@allegromicro.com
www.allegromicro.comThis message and any attachments to it may contain CONFIDENTIAL INFORMATION, may be legally privileged, and is exclusively for the intended recipient(s). Please DO NOT FORWARD OR DISTRIBUTE to anyone else. If you have received this e-mail in error, please contact the sender immediately to report the error and then delete this message from your system. If you have any questions, please call the sender, Stephanie Fennelly at (508) 854-5363.**LEM:****Fw: LEM Website - General Contact**

Stephanie Ferrollet [StF@lem.com]

Extra line breaks in this message were removed.

Sent: Mon 11/15/2010 3:29 AM

To: mpodel88@gmail.com

Dear Sir,

Thanks for addressing us your request, you have the permission to use pictures for your paper.
Wishing you good luck,
Best regardsStephanie Ferrollet
Communication Department
LEM International SA
8 Chemin des Aulx, 1228 Plan-les-OuatesTel: +41 22 706 12 30
Fax: +41 22 794 94 78

Arcelect Technologies:

From: Wayne Ware (wayne@arcelect.com)
To: prism6789@yahoo.com;
Date: Wed, November 3, 2010 11:03:01 AM
Cc:
Subject: RE: Copyright Permission

Sure use what you need

From: Prism6789 [mailto:prism6789@yahoo.com]
Sent: Tuesday, November 02, 2010 7:05 PM
To: arc@arcelect.com
Subject: Copyright Permission

To Whom it may Concern,
I am currently an Electrical Engineering student at the University of Central Florida, and am avidly working on my senior design project. I have found your website extremely helpful and would like permission to reprint and use schematics and or diagrams from your website. The schematics and or drawings come from the RS-232 and RS-485 portions of your web page. I ensure you that all material used will be properly credited and cited.
Sincerely,
Christina Syliva

MC Select:

From: Mark Alberts (mark@mcselec.com)
To: prism6789@yahoo.com;
Date: Wed, November 3, 2010 4:38:03 AM
Cc:
Subject: Re: Copyright Permission

Hello Christina

Sure, no problem. you can copy everything you can find/use. if you add one reference to the site it will do.
Good luck with your study !

best regards
Mark Alberts
MCS

On Tue, 2 Nov 2010 16:57:30 -0700 (PDT), Prism6789 wrote:

> To Whom it may Concern,
> I am currently an Electrical Engineering student at the University of Central Florida, and am avidly working on my senior design project. I have found your website extremely helpful and would like permission to reprint and use schematics and diagrams from your website. The schematics and or drawings come from the I2C protocol, RS 485 and UART sections of your web page. I ensure you that all material used will be given properly credited and cited.
> Sincerely,
> Christina Syliva

Microchip

From: Marc.McComb@microchip.com (Marc.McComb@microchip.com)
To: prism6789@yahoo.com;
Date: Mon, November 22, 2010 1:49:57 PM
Cc:
Subject: RE: copyright permission

Hi Christina:

Thank you for your email. There shouldn't be any problem using these materials provided you follow the guidelines listed on our Legal page:

http://www.microchip.com/stellent/idcplg?IdcService=SS_GET_PAGE&nodeId=99

Regards,

Marc McComb
Academic Program Sales Engineer
2355 West Chandler Blvd., Mailstop 9-B
Chandler, AZ 85224-6199
office: 480-792-4391
mobile: 480-478-5676

Need more information on Microchip's Academic Program or would like to become a Partner? Visit www.microchip.com/academic for more information.

From: Prism6789 <prism6789@yahoo.com>@MICROCHIP
Sent: Sunday, November 21, 2010 8:40 AM
To: University
Subject: copyright permission

To Whom it may Concern,

I am currently an [Electrical Engineering](#) student at the [University of Central Florida](#), and am avidly working on my senior design project. I have found your online AN684 manual extremely helpful and would like permission to reprint and use schematics and or diagrams from your manual. I would specifically like permission to use Fig. 3, Fig.5 and Table 5, from this manual. I ensure you that all material used will be properly credited and cited throughout the documentation.

Sincerely,
Christina Syliva

National Instruments



November 3, 2010

Gor Beglaryan
School of Electrical Engineering and Computer Science
UNIVERSITY OF CENTRAL FLORIDA
4000 Central Florida Boulevard
Orlando, Florida 32816-2450

Re: Permission to Use Certain Copyrighted Materials of National Instruments Corporation
("NI")

Dear Mr. Beglaryan:

In response to your request to use certain copyrighted materials of NI, NI (by this letter) grants you the limited right to reproduce images, specifically Figure 1 and Figure 3 from the NI Developer Zone tutorial entitled "How to Choose the Right Relay" which can be found at:

<http://zone.ni.com/devzone/cda/tut/p/id/2774>

(the "Images"), for distribution by you for use in and submission of your senior design project for the class entitled "EEL 4914-0001 Senior Design 1" for the University of Central Florida.

1. You may use the Images only for the purpose(s) described above (the "Purpose"). Please note that (unless expressly stated above in the Purpose) this is a one-time use right, and any additional uses by you will require the separate prior written authorization of NI. Please also note that your use right will not commence until NI receives a copy of this letter duly countersigned by you.
2. Other than resizing the Images as necessary for the Purpose, you may not revise, modify, or otherwise change the Images in any manner without the prior written authorization of NI. Further, you may distribute the Images solely to the University of Central Florida for use in your senior design project.
3. In no event may you use the Images in a defamatory, libelous, or unlawful manner or in any manner that disparages NI.
4. You must include in your senior design project a copyright notice in prominent type and font indicating: (a) NI's copyright ownership of the Images, and (b) that reproduction of the Images is courtesy of NI.

Please note that your use right is non-exclusive and non-transferable. NI reserves all rights and licenses not expressly granted you in this letter. **THE NI MATERIALS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, AND NO WARRANTIES (EITHER EXPRESS OR IMPLIED) ARE MADE WITH RESPECT TO THE NI MATERIALS, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE OR NON-INFRINGEMENT, OR ANY OTHER WARRANTIES THAT MAY ARISE FROM USAGE OF TRADE OR COURSE OF DEALING. YOU AGREE AND ACKNOWLEDGE THAT NI SHALL NOT BE LIABLE FOR ANY CLAIMS RESULTING FROM OR IN CONNECTION WITH ITS USE OF THE NI MATERIALS, AND YOU AGREE TO INDEMNIFY AND HOLD NI HARMLESS FROM ANY CLAIMS AGAINST OR**

11500 N Mopac Expy # Austin, TX 78759-3504 USA
Sales and Service: (512) 794-0100 # Other Calls: (512) 338-9119 # Fax: (512) 683-8411 # info@ni.com

www.ni.com

POLOLU permission

Hello,

You can use our picture for you project; just make sure to give credit to Pololu Corporation.

Sincerely,
Emily Hartnett
1-877-7-POLOLU (toll-free US)
T: (702) 262-6648
F: (702) 262-6894
www.pololu.com

.....
Pololu Corporation
3095 E. Patrick Ln. #12
Las Vegas, NV 89120
USA

High Current DC switch permission

Permission granted

Best regards, Jim

Sent from my Verizon Wireless Phone

|----- Reply message -----

From: "Gor Beglaryan" <gor.beglaryan@knights.ucf.edu>

Date: Sat, Nov 6, 2010 5:04 pm

Subject: Copyright permission

To: <jim@w6pql.com>

Hello,

My name is Gor Beglaryan, and I am currently working on a senior deign project at the University of Central Florida. I came across the high current DC switch, and would like to get your permission to be able to use this picture in my project report. We are designing E-Stop circuits for our autonomous vehicle, and we would like to use this picture to show an alternative for relays.

Thanks for your time,

Regards,

Gor Beglaryan

gor.beglaryan@knights.ucf.edu

LCD - Display

Gor,

That will be just fine.

Thank You,

Mitchell Scramstad
Digi-Key Corporation
Customer Service
1-800-858-3616 x 2863

From: Gor Beglaryan [<mailto:gor.beglaryan@knights.ucf.edu>]

Sent: Monday, November 22, 2010 07:05 PM

To: Customer Service

Subject: RE: Copyright permission Old_Ref20101122-372644193304

Mitchell,

Thanks for your response. This report is not going to be published, however it will be on a university server for some time, so it will be available for UCF faculty and students to read and check the validity of our project, but again, it is not going to be published. Please let me know if that's acceptable.

Thanks,

Gor Beglaryan

From: Customer Service [<mailto:customer.service@digkey.com>]
Sent: Monday, November 22, 2010 12:48 PM
To: gor.beglaryan@knights.ucf.edu
Subject: RE: Copyright permission Old_Ref20101122-372644193304

>

From: WebMaster [<mailto:webmaster@digkey.com>]
Sent: Monday, November 22, 2010 08:21 AM
To: Customer Service
Subject: FW: Copyright permission Old_Ref20101120-372644189019

Jessica Bolstad
Marketing Communications Specialist
Digi-Key Corporation
701 Brooks Avenue
Thief River Falls, MN 56701
1-800-338-4105 ext 1706

Gor,

I spoke with the product manager for this part and he stated that as long as you do not publish your report or use the [companies logo](#), it is okay to use the image in the manner you described.

Thank You,

Mitchell Scramstad
Digi-Key Corporation
Customer Service
1-800-858-3616 x 2863

From: Customer Service [<mailto:customer.service@digkey.com>]
Sent: Saturday, November 20, 2010 3:17 PM
To: webmaster@digkey.com
Subject: RE: Copyright permission Old_Ref20101120-372644189019

From: Gor Beglaryan [<mailto:>]
Sent: Saturday, November 20, 2010 11:29 AM
To: Customer Service
Subject: Copyright permission

Dear Digikey customer representative,

My name is Gor Beglaryan and I am a senior at the University of Central Florida. I am writing to get copyright permission to use an image of a LCD display (part # -NHD-0420D3Z-FL-GBW-ND) in our senior design project report. We intend to use this part for our project, however we would like to use an image in the report to clarify some technical aspects of this component.

Thanks for your courtesy and time.

Regards,

Gor Beglaryan

From: Kiran [mailto:sbernard@knights.ucf.edu]
Sent: Saturday, November 13, 2010 2:44 AM
To: 'webmaster@intersil.com'
Subject: Referance for Senior Design

Hello,

I am a student from the University of Central Florida studying Electrical Engineering and would like to reference the following datasheet in my undergraduate Senior design report. Just so I don't infringe on your company's policies, I would like to ask permission for using the following information:

The program flow diagram illustrated for I2C communication in the following datasheet:

<http://www.intersil.com/data/fn/fn8197.pdf>

Best Regards,
 Kiran Bernard

Summary

Description	English: An example of how an FPGA logic cell can look like, incl a 4 inp. LUT (or two 3-LUTs), a Full Adder and a D-type Flip Flop. The 2 muxes to the right have their select signal set during the programming of the cell. Svenska: Exempel på hur en logisk cell i en FPGA kan vara uppbyggd, inkl. en 4-LUT (eller två 3-LUTar), en Fulladderare och en D-flip-flop. De två muxarna till höger får sina select-signaler satta vid programmeringen av cellen.
Date	2 maj 2010
Source	Own work
Author	Petter.kallstrom
Permission (Reusing this file)	See below.

Licensing




I, the copyright holder of this work, release this work into the **public domain**. This applies worldwide.
 In some countries this may not be legally possible; if so:

*I grant anyone the right to use this work **for any purpose**, without any conditions, unless such conditions are required by law.*

File history

Click on a date/time to view the file as it appeared at that time.

	Date/Time	Thumbnail	Dimensions	User	Comment
current	17:20, 2 May 2010		957×430 (7 KB)	Petter.kallstrom	{{Information Description={{en 1=An example of how an FPGA logic cell can look like, incl a 4 inp. LUT (or two 3-LUTs), a Full Adder and a D-type Flip Flop. The 2 muxes to the right have their select signal set during the programming of the cell.}} {{sv



[What's New](#) | [Products](#) | [Solutions](#) | [Design](#) | [AppNotes](#) | [Support](#) | [Sales](#) | [About Us](#) | [My Maxim](#)

[Support Center](#)

- [Feedback, Questions](#)
- [Self-Help Resources](#)

[Maxim > Support Center](#)

Contact Us: Other Issues [* Required Value]

Send us your comments and we will respond as soon as possible.

* **Email Address:**

* **E-Mail (Confirm):**

* **First Name:**

* **Last Name:**

* **Company:**

* **Subject:**

* **Comments:**

Hello,

I am a student from the University of Central Florida studying Electrical Engineering and would like to reference the following datasheet in my undergraduate Senior design report. Just so I don't infringe on your company's policies, I would like to ask permission for citing and referencing the following information:

<http://pdfserv.maxim-ic.com/en/an/AN183.pdf>

Best Regards,
Kiran Bernard

Previous SPR Id:

Point of Origin (outside of the Support Center):